

HOW TO RESET DEFAULT FACTORY ON MIKROTIK

1. SOFT RESET

using terminal or ssh on mikrotik



using winbox



2. HARD RESET

using clip tool






press and hold on reset button using clip, then turn on power mikrotik, wait a second.




3. HARD RESET (OPEN CASE)

open mikrotik case, find reset button, press and hold on reset button using screw, then turn on power mikrotik, wait a second.



After point 1,2 or 3 then restart your mikrotik, login to default ip and password, using lan or serial port.



Dok 14/10/2016 padliyulian@ymail.com