

WinDarab V7-Shortcuts			 BOSCH
Navigation	Channels	Display	
←↑↓→ Move crosshairs	Space Set tag	G Toggle Grid	
Ctrl+← Scroll log data	2xSpace Delete tag		
Ctrl+→ Scroll log data	B Blink channel	F4 Activate „shift file“	
+ Zoom in	Ctrl+0 Show Zero line	F5 Show settings	
- Zoom out	Ctrl+9 Show Constant line	(measurement element)	
Ctrl+Z Undo zoom	C Color	F6 Load new config	
A Zoom all	H Hide/unhide	F7 Save config	
F Zoom fast lap	I Channel info	F9 Load desktop	
L Zoom lap	Y Reset Y range	F12 Toggle desktop	
M Zoom marked rg.	Ctrl+A Select all channels	Insert Local add menu	
N Next lap	in area	Delete Local delete menu	
P Previous lap	Ctrl+Shift+A Select all channels in oscilloscope	R Replace	
S Segment	D Display options		
Menu Options	Views		
Ctrl+E Open file	Ctrl+Y Auto Y range	F1 Help	
Ctrl+R Read data	Z Set channel zero	F2 Add Worksheet	
Ctrl+S Close data	D Display options	F3 Filter channel list	

51 mm

75 mm