

Mode	Program	Description
Addr	A001-A512	DMX start address
ChNd	3Ch	DMX Channel mode
	6Ch	
	12Ch	
	24Ch	
	48Ch	
Slav	Mast	Master or Slave selection
	SI 1	
ShNd	Sh 0 - Sh 16	Auto program sound active
Colo	rEd	0-255 Dimmer Red LED 0-100%
	GrEE	0-255 Dimmer Green LED 0-100%
	bLuE	0-255 Dimmer Blue LED 0-100%
vEr	V110	Software version

DMX CHANNELS / DMX KANALEN / DMX-KANÄLE / CANALES DMX / CANAUX DMX / KANAŁY DMX
3 Channels

Channel	Function	Value	Description
1	Master dimmer	000-255	0-100% Red
2	000-255		0-100% Green
3	000-255		0-100% Blue

6 Channels

Channel	Function	Value	Description
1	Master dimmer	000-255	Dimmer all LED's 0-100%
2	Strobe	000-255	Strobe (Fast to slow)
3		000-255	0-100% Red
4	000-255		0-100% Green
5	000-255		0-100% Blue
6	Auto	000-255	Auto program (Fast to slow)

12 Channels

Channel	Function	Value	Description
1	Master dimmer	000-255	Dimmer all LED's 0-100%
2	Strobe	000-255	Strobe (Fast to slow)
3		000-255	0-100% Red
4	000-255		0-100% Green
5	000-255		0-100% Blue
6	Auto	000-255	Auto program (Fast to slow)
7	Master dimmer	000-255	Dimmer all LED's 0-100%
8	Strobe	000-255	Strobe (Fast to slow)
9		000-255	0-100% Red
10	000-255		0-100% Green
11	000-255		0-100% Blue
12	Auto	000-255	Auto program (Fast to slow)

24 Channels

Channel	Function	Value	Description
1	Master dimmer	000-255	Dimmer all LED's 0-100%
2	Strobe	000-255	Strobe (Fast to slow)
3		000-255	0-100% Red
4	000-255		0-100% Green
5	000-255		0-100% Blue
6	Auto	000-255	Auto program (Fast to slow)
7	Master dimmer	000-255	Dimmer all LED's 0-100%
8	Strobe	000-255	Strobe (Fast to slow)
9		000-255	0-100% Red
10	000-255		0-100% Green
11	000-255		0-100% Blue
12	Auto	000-255	Auto program (Fast to slow)

