

Channel	Function		Value	Description
13	Master dimmer		000-255	Dimmer all LED's 0-100%
14	Strobe 000-255 Strobe	(Fast to slow)		
15			000-255	0-100% Red
16	Colour	Section 3	000-255	0-100% Green
17			000-255	0-100% Blue
18	Auto 000-255			Auto program (Fast to slow)
19	Master dimmer		000-255	Dimmer all LED's 0-100%
20	Strobe 000-255 Strobe	(Fast to slow)		
21		Section 4	000-255	0-100% Red
22	Colour		000-255	0-100% Green
23			000-255	0-100% Blue
24	Auto 000-255			Auto program (Fast to slow)

48 Channels

Channel	Function		Value	Description
1	Master dimmer		000-255	Dimmer all LED's 0-100%
2	Strobe		000-255	Strobe (Fast to slow)
3		Section 1	000-255	0-100% Red
4	000-255 Colour			0-100% Green
5	000-255			0-100% Blue
6	Auto		000-255	Auto program (Fast to slow)
7	Master dimmer		000-255	Dimmer all LED's 0-100%
8	Strobe		000-255	Strobe (Fast to slow)
9		Section 2	000-255	0-100% Red
10	000-255 Colour			0-100% Green
11	000-255			0-100% Blue
12	Auto		000-255	Auto program (Fast to slow)
13	Master dimmer		000-255	Dimmer all LED's 0-100%
14	Strobe 000-255 Strobe	(Fast to slow)		
15			000-255	0-100% Red
16	Colour	Section 3	000-255	0-100% Green
17			000-255	0-100% Blue
18	Auto 000-255			Auto program (Fast to slow)
19	Master dimmer		000-255	Dimmer all LED's 0-100%
20	Strobe 000-255 Strobe	(Fast to slow)		
21		Section 4	000-255	0-100% Red
22	Colour		000-255	0-100% Green
23			000-255	0-100% Blue
24	Auto 000-255			Auto program (Fast to slow)
25	Master dimmer		000-255	Dimmer all LED's 0-100%
26	Strobe 000-255 Strobe	(Fast to slow)		
27		Section 5	000-255	0-100% Red
28	Colour		000-255	0-100% Green
29			000-255	0-100% Blue
30	Auto 000-255 Auto program (Fast to slow)			
31	Master dimmer		000-255	Dimmer all LED's 0-100%
32	Strobe 000-255 Strobe	(Fast to slow)		
33		Section 6	000-255	0-100% Red
34	Colour		000-255	0-100% Green
35			000-255	0-100% Blue
36	Auto 000-255 Auto program (Fast to slow)			
37	Master dimmer		000-255	Dimmer all LED's 0-100%
38	Strobe 000-255 Strobe	(Fast to slow)		
39		Section 7	000-255	0-100% Red
40	Colour		000-255	0-100% Green
41			000-255	0-100% Blue
42	Auto 000-255 Auto program (Fast to slow)			
43	Master dimmer		000-255	Dimmer all LED's 0-100%
44	Strobe 000-255 Strobe	(Fast to slow)		
45		Section 8	000-255	0-100% Red
46	Colour		000-255	0-100% Green
47			000-255	0-100% Blue
48	Auto 000-255 Auto program (Fast to slow)			

