














Sheet: /Boot and Debug/
File: boot_debug.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 9.0.7

Rev:

Id: 5/24



Sheet: /Display/
File: display.kicad_sch

Title:

Size: A4




Date:

KiCad E.D.A. 9.0.7

Rev:

Id: 6/24

X1AD
PHYTEC-FPSC-L



Sheet: /Audio/
File: audio.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 9.0.7

Rev:

Id: 7/24



Sheet: /M.2/
File: m2.kicad_sch

Title:


Size: A4


Date:

KiCad E.D.A. 9.0.7


Rev:


Id: 9/24







Sheet: /Micro Controller/Button/ File: buttons.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 9.0.7		Id: 12/24






Sheet: /Micro Controller/Button2/ File: buttons.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 9.0.7		Id: 14/24







Sheet: /Micro Controller/Button5/ File: buttons.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 9.0.7		Id: 17/24

