

JukeBox Specification

Revision 1.0

Contents

JukeBox Specification	1
1. Module	3
1.1. kp_fsm.....	3
1.2. coin_fsm.....	3
1.3. jukebox.....	3
1.4. station.....	4
1.5. test_jukebox	4
1.6. fifo.....	4
1.7. cd.....	4
2. instance1	6
2.1. test_jukebox_total.....	6
2.1.1. test_jukebox	6
2.1.2. cd1.....	6
2.1.3. fifo1.....	6
2.1.4. jb1	7
2.1.5. st0_total.....	7
2.1.6. st1_total.....	8
2.1.7. st2_total.....	8
2.1.8. st3_total.....	9
2.1.9. st4_total.....	10
3. instance2	11
3.1. test_jukebox_total.....	11
3.1.1. test_jukebox	11
3.1.2. cd1.....	11
3.1.3. fifo1.....	11
3.1.4. jb1	12
3.1.5. st0_total.....	12
3.1.6. st1_wild.....	13
3.1.7. st1_multi	13
3.1.8. st1_total.....	13
3.2. coin1_wild.....	14
4. Fun_Cov.....	15
4.1. subplan fun_cov	15
A. Metric Definition	16
B. Attribute Definition.....	16
C. Annotation Definition	16
D. Include File	16

This JukeBox design plays songs from different disks and tracks. Songs cost 25 cents. Quarters, dimes and nickels are the coins allowed to be inputted in the jukebox. When there isn't enough money in the jukebox, the selected song is not played and ignored. When the machine is in reset mode, coins are rejected. If overpaying, additional coins are returned.

1. Module

This section groups all the different modules for checking.

M

HVP Assignment	
owner	John
weight	1
Line	(Line >= 0.9)
Cond	(Cond >= 0.3)

1.1. kp_fsm

HVP Measure m1	
source	module: kp_fsm
Line	
Toggle	
Cond	
FSM	

1.2. coin_fsm

HVP Measure m1	
source	module: coin_fsm
Line	
Toggle	
Cond	
FSM	

1.3. jukebox

HVP Measure m1	
source	module: jukebox

Line	
Toggle	
Cond	
FSM	

1.4. station

HVP Assignment	
Cond	(Cond >= 0.5)

HVP Measure m1	
source	module: station
Line	
Toggle	
Cond	
FSM	

1.5. test_jukebox

HVP Measure m1	
source	module: test_jukebox
Line	
Toggle	
Cond	
FSM	

1.6. fifo

HVP Measure m1	
source	module: fifo
Line	
Toggle	
Cond	
FSM	

1.7. cd

HVP Measure m1	
----------------	--

source	module: cd
Line	
Toggle	
Cond	
FSM	

2. instance1

instance1 description

HVP Assignment	
owner	Bart
weight	2

HVP Measure status	
source	/cfg/data/instance_1
bugs	
fixed	
status	

2.1. test_jukebox_total

2.1.1. test_jukebox

HVP Measure m1	
source	instance: test_jukebox
Line	
Toggle	
Cond	
FSM	

2.1.2. cd1

HVP Measure m1	
source	instance: test_jukebox.cd1
Line	
Toggle	
Cond	
FSM	

2.1.3. fifo1

HVP Measure m1	
source	instance: test_jukebox.fifo1
Line	
Toggle	

Cond	
FSM	

2.1.4. jb1

HVP Measure m1	
source	instance: test_jukebox.jb1
Line	
Toggle	
Cond	
FSM	

2.1.5. st0_total

2.1.5.1. st0

HVP Measure m1	
source	instance: test_jukebox.st0
Line	
Toggle	
Cond	
FSM	

2.1.5.2. coin1

HVP Measure m1	
source	instance: test_jukebox.st0.coin1
Line	
Toggle	
Cond	
FSM	

2.1.5.3. kp1

HVP Measure m1	
source	instance: test_jukebox.st0.kp1
Line	
Toggle	
Cond	
FSM	

2.1.6. st1_total

2.1.6.1. st1

HVP Measure m1	
source	instance: test_jukebox.st1
Line	
Toggle	
Cond	
FSM	

2.1.6.2. coin1

HVP Measure m1	
source	instance: test_jukebox.st1.coin1
Line	
Toggle	
Cond	
FSM	

2.1.6.3. kp1

HVP Measure m1	
source	instance: test_jukebox.st1.kp1
Line	
Toggle	
Cond	
FSM	

2.1.7. st2_total

2.1.7.1. st2

HVP Measure m1	
source	instance: test_jukebox.st2
Line	
Toggle	
Cond	
FSM	

2.1.7.2. coin1

HVP Measure m1	
source	instance: test_jukebox.st2.coin1
Line	
Toggle	
Cond	
FSM	

2.1.7.3. kp1

HVP Measure m1	
source	instance: test_jukebox.st2.kp1
Line	
Toggle	
Cond	
FSM	

2.1.8. st3_total

2.1.8.1. st3

HVP Measure m1	
source	instance: test_jukebox.st3
Line	
Toggle	
Cond	
FSM	

2.1.8.2. coin1

HVP Measure m1	
source	instance: test_jukebox.st3.coin1
Line	
Toggle	
Cond	
FSM	

2.1.8.3. kp1

HVP Measure m1	
source	instance: test_jukebox.st3.kp1

Line	
Toggle	
Cond	
FSM	

2.1.9. st4_total

2.1.9.1. st4

HVP Measure m1	
source	instance: test_jukebox.st4
Line	
Toggle	
Cond	
FSM	

2.1.9.2. coin1

HVP Measure m1	
source	instance: test_jukebox.st4.coin1
Line	
Toggle	
Cond	
FSM	

2.1.9.3. kp1

HVP Measure m1	
source	instance: test_jukebox.st4.kp1
Line	
Toggle	
Cond	
FSM	

3. instance2

HVP Assignment	
owner	Bill
weight	0

HVP Measure Measure_1	
source	/cfg/data/instance_2
bugs	
fixed	
status	

3.1. test_jukebox_total

3.1.1. test_jukebox

HVP Measure m1	
source	instance: test_jukebox
Line	
Toggle	
Cond	
FSM	

3.1.2. cd1

HVP Measure m1	
source	instance: test_jukebox.cd1
Line	
Toggle	
Cond	
FSM	

3.1.3. fifo1

HVP Measure m1	
source	instance: test_jukebox.fifo1
Line	
Toggle	
Cond	

FSM	
-----	--

3.1.4. jb1

HVP Measure m1	
source	instance: test_jukebox.jb1
Line	
Toggle	
Cond	
FSM	

3.1.5. st0_total

3.1.5.1. st0

HVP Measure m1	
source	instance: test_jukebox.st0
Line	
Toggle	
Cond	
FSM	

3.1.5.2. coin1

HVP Measure m1	
source	instance: test_jukebox.st0.coin1
Line	
Toggle	
Cond	
FSM	

3.1.5.3. kp1

HVP Measure m1	
source	instance: test_jukebox.st0.kp1
Line	
Toggle	
Cond	
FSM	

3.1.6. st1_wild

HVP Measure m1	
source	instance: test_jukebox.st1.*
Line	
Toggle	
Cond	
FSM	

3.1.7. st1_multi

HVP Measure m1	
source	instance: test_jukebox.st1.coin1
source	instance: test_jukebox.st1.kp1
Line	
Toggle	
Cond	
FSM	

3.1.8. st1_total

3.1.8.1. st1

HVP Measure m1	
source	instance: test_jukebox.st1
Line	
Toggle	
Cond	
FSM	

3.1.8.2. coin1

HVP Measure m1	
source	instance: test_jukebox.st1.coin1
Line	
Toggle	
Cond	
FSM	

3.1.8.3. kp1

HVP Measure m1	
source	instance: test_jukebox.st1.kp1
Line	
Toggle	
Cond	
FSM	

3.2. coin1_wild

HVP Measure m1	
source	instance: test_jukebox.st*.co*
Line	
Cond	
FSM	
Toggle	
bugs	
fixed	
status	

4. Fun_Cov

HVP Assignment	
owner	Carl

HVP Measure status	
source	/cfg/data/Function_coverage
bugs	
fixed	
status	

4.1. subplan fun_cov

A.Metric Definition

HVP Metric bugs	
type	integer
aggregator	average
goal	(bugs > 10)

HVP Metric fixed	
type	ratio
aggregator	average
goal	(fixed == 1)

HVP Metric status	
type	enum{developing,testing,done}
aggregator	sum
goal	((status.testing + status.developing) == 0)

B.Attribute Definition

HVP Attribute phase	
type	integer
default	1

C.Annotation Definition

HVP Annotation spec	
type	string
default	

D.Include File

HVP Include File	
./HVP_Example_subplan.hvp	