

IC Validator PERC Examples

1/10/2019



Floating Gate Check

Floating Gate Check

Connection Key

- “IN” connector is a top level pad input
- “NC” indicates “no connection”

Error condition

- Gate has no path to power or ground
- Top level pad inputs are excluded

