

coreAssembler Help

Help: IP-XACT Information

IP-XACT is an XML-based standard for describing IP and IP packaging, as well as plug-in to IP tools and flows, to enable more efficient and cost-effective integration of IP from multiple sources.

You can access the *coreAssembler User Guide* appendix that contains information on using IP-XACT compliant component and designs by clicking on the following links:

[Using IP-XACT Components and Designs](#)

[IP-XACT Features](#)

[IP-XACT User Interface](#)

[IP-XACT Batch Mode Interface](#)

[IP-XACT Licensing and Keys](#)

[IP-XACT Examples](#)

[Glossary of IP-XACT Terminology](#)