
## King Mongkut's University of Technology Thonburi





# **Experiment:** introduction to Nu\_LB-002 (Cortex<sup>™</sup>-M0)

# **Objectives**


- To be familiar with Nu\_LB-002 (Nuvoton learning board)
- Introduction to Keil
- How to use the NuMicro™ NUC100 series driver to do the fast application software development
- How to use GPIO/LCD

## **Background Theory**

Nu LB-002

The NUC100 series is 32-bit microcontrollers with embedded ARM® Cortex™-M0 core for industrial control at a cost equivalent to a traditional 8-bit microcontroller.

The NUC1XX series with Cortex<sup>™</sup>-M0 core runs up to 50MHz, up to 32K/64K/128K-byte embedded flash, and 4K/8K/16K-byte embedded SRAM, it also integrates Timers, Watchdog Timer, RTC, PDMA, UART, SPI/SSP, I2C, PWM Timer, GPIO, LIN, CAN, USB 2.0 FS Device, 12-bit ADC, Analog Comparator, Low Voltage Detector and Brown-out detector.



## **Equipment required**

- Nu\_LB-002 (Nuvoton learning board)


#### Reference:

- 1. Nu\_LB-002 Rev 2.1 User's Manual
- 2. NuMicro™ NUC130\_140 Technical Reference Manual EN V2.02
- 3. NuMicro™ NUC100 Series Driver Reference Guide V1.05.002


#### Procedure 1: the first example project


- After installation of the software according to the procedure on the web-page
   (<a href="http://webstaff.kmutt.ac.th/~dejwoot.kha/CalenderYear/Year2556/ene335/index.html">http://webstaff.kmutt.ac.th/~dejwoot.kha/CalenderYear/Year2556/ene335/index.html</a>
   : HowTO install Nu tools), there are subdirectories under drive C:
- Download the zip file (<u>Smpl\_Start\_Kit.zip</u>) and save in the directory ("C:\Nuvoton\BSP Library \NUC100SeriesBSP\_CMSIS\_v1.05.003 \NuvotonPlatform\_Keil\Sample\NUC1xx-LB\_002\").
- Unzip the file into the same directory. And rename the new directory to your preference, so you can work on your own.

(Smpl\_Start\_Kit\_ENE335\_secXX)




- 4. Open the project file by going to the new subdirectory that contain 3 files. Double click Smpl\_Start\_Kit.uvproj (Vision4 Project).
- 5. The Keil window will show up.
- Compile the project to create the executable file by click at 'Rebuild' icon.





- 8. To run the program, reset the Nu\_LB-002. (Use the reset button on the board)
- 9. Or download and debug the program by clicking at the



'Start/Stop Debug' icon.

10. Look at the 'Smpl\_Start\_Kit.c' and answer the following questions.

```
8 #include <stdio.h>
9 #include "NUC1xx.h"
10 #include "Driver\DrvSYS.h"
11 #include "Driver\DrvGPIO.h"
12 #include "LCD Driver.h"
13 #include "Seven_Segment.h"
14
15 □void delay loop(void) {
16 | uint32_t i, j;
17 for (i=0;i<3;i++) {
18 for (j=0;j<60000;j++);
19 }
20
21
Interrupt subroutine
23
24
                                -----*/
25 static unsigned char count = 0;
26 static unsigned char loop = 12;
28 - void TMR0 IRQHandler(void) { // Timer0 interrupt subroutine
    unsigned char i = 0;
     TIMERO->TISR.TIF = 1;
30
31
     count++;
32 if (count == 5) {
      DrvGPIO_ClrBit(E_GPC,loop);
loop++;
34
35
       count=0;
      if (loop == 17) {
36 🖨
       for(i=12;i<16;i++) {
37 ់
         DrvGPIO_SetBit(E_GPC,i);
38
          }
       loop = 12;
}
40
41
42
      1
43
    }
44
45 -void Timer initial (void) {
     /* Step 1. Enable and Select Timer clock source */
     SYSCLK->CLKSEL1.TMR0 S = 0; // Select 12Mhz for Timer0 clock source
47
     SYSCLK->APBCLK.TMR0 EN = 1; // Enable Timer0 clock source
48
49
50
     /* Step 2. Select Operation mode */
51
     TIMERO->TCSR.MODE = 1; // Select periodic mode for operation mode
52
53 /* Step 3. Select Time out period
54
     = (Period of timer clock input) * (8-bit Prescale + 1) * (24-bit TCMP) */
     TIMERO->TCSR.PRESCALE = 0; // Set Prescale [0~255]
55
56
57
     /* Step 4. Enable interrupt */
     TIMERO->TCSR.IE = 1;
58
     TIMERO->TISR.TIF = 1;
                            // Write 1 to clear for safty
59
     NVIC_EnableIRQ(TMRO_IRQn); // Enable Timer0 Interrupt
60
61
62
     /* Step 5. Enable Timer module */
     TIMERO->TCSR.CRST = 1; // Reset up counter
63
     TIMERO->TCSR.CEN = 1;
                              // Enable Timer0
64
65
     TIMERO->TCSR.TDR EN = 1;
                              // Enable TDR function
67
68
```

```
69 ☐ int main(void) {
     int i = 0, j = 0;
 71
      /* Unlock the protected registers */
72
      UNLOCKREG();
73
      /* Enable the 12MHz oscillator oscillation */
74
     DrvSYS SetOscCtrl(E SYS XTL12M, 1);
      /* Waiting for 12M Xtal stalble */
75
76
     SysTimerDelay(5000);
      /* HCLK clock source. 0: external 12MHz; 4:internal 22MHz RC oscillator */
77
78 DrvSYS SelectHCLKSource(0);
79
     /*lock the protected registers */
80
     LOCKREG();
81
82 DrvSYS_SetClockDivider(E_SYS_HCLK_DIV, 0); /* HCLK clock frequency
83
     = HCLK clock source / (HCLK N + 1) */
84
85 for (i=12;i<16;i++) {
86
      DrvGPIO_Open(E_GPC, i, E_IO_OUTPUT);
87
88
89
      Initial pannel(); //call initial pannel function
90
      clr all pannal();
91
92
      print lcd(0, "Welcome! Nuvoton");
      print lcd(1, "This is LB test ");
93
      print_lcd(2, "Nu_LB-002");
94
      print lcd(3, "1234567890123456");
95
96
      Timer_initial();
97
98  while (1) {
99 🗀
       for(i=0;i<9;i++) {
100 🗀
         for(j=0;j<4;j++) {
101
          close_seven_segment();
102
           show seven segment(j,i);
103
           delay_loop();
104
105
         }
106 -
107
       }
107
      }
108
```

#### Questions (the first example project)

- What does the function on line 33 (DrvGPIO\_ClrBit(E\_GPC,loop);) do? When loop =
   (Try set Breakpoint on line 33, then 'Run' and 'Step over the current line' in Debug mode)
- 2. What does the function on line 38 (DrvGPIO\_SetBit(E\_GPC,i);) do? When i = 14.

3. What does the function on line 102 (show\_seven\_segment(j,i);) do? When j = 1 and i = 3.

4. What is the time out period of Timer0? (Show how to get the result)


5. How long does the LED (GPC12) turn 'ON'? (Show how to get the result)

## General Purpose I/O (GPIO)

NuMicro™ NUC130/NUC140 has up to 80 General Purpose I/O pins can be shared with other function pins; it depends on the chip configuration. These 80 pins are arranged in 5 ports named with GPIOA, GPIOB, GPIOC, GPIOD and GPIOE. Each port equips maximum 16 pins. Each one of the 80 pins is independent and has the corresponding register bits to control the pin mode function and data.

The I/O type of each of I/O pins can be configured by software individually as input, output, and open-drain or quasi-bidirectional mode. After reset, the I/O type of all pins stay in quasi-bidirectional mode and port data register GPIOx\_DOUT[15:0] resets to 0x0000\_FFFF. Each I/O pin equips a very weakly individual pull-up resistor which is about 110 K $\Omega^{\sim}$ 300 K $\Omega$  for VDD is from 5.0 V to 2.5 V.

LED: GPC8-GPC15 to control LED function.



#### Procedure 2: LED: GPC8-GPC15 to control LED function.


- 1. Replace the content of the 'Smpl\_Start\_Kit.c' with the 'LED' lab file.
- 2. Compile the project, and run the program.
- 3. Study the program and answer the following questions.

```
// Nu LB-002: L00 01 LED GPC 12 15.c
2
   // use function, macro and directly at Register to turn 'ON' & 'OFF' LED
3
4
   // Smpl GPIO LED : GPC12 ~ 15 to control on-board LEDs
   //
                      output low to enable red LEDs
7
   //
8
   /*
                                                                                 */
9
10
                                                                                 */
   /* Copyright (c) Nuvoton Technology Corp. All rights reserved.
   /* edited: june 2014: dejwoot.kha@mail.kmutt.ac.th
11
12
13
14
   #include <stdio.h>
15 #include "NUC1xx.h"
   #include "Driver\DrvGPIO.h"
16
   #include "Driver\DrvSYS.h"
17
18
   #define DELAY300ms 300000 // The maximal delay time is 335000 us.
19
20
21 // Initial GPIO pins (GPC 12,13,14,15) to Output mode
22 ⊟void Init LED() {
     // initialize GPIO pins
23
     DrvGPIO_Open(E_GPC, 12, E_IO_OUTPUT); // GPC12 pin set to output mode
24
25
     DrvGPIO_Open(E_GPC, 13, E_IO_OUTPUT); // GPC13 pin set to output mode
26
      DrvGPIO_Open(E_GPC, 14, E_IO_OUTPUT); // GPC14 pin set to output mode
     DrvGPIO Open(E GPC, 15, E IO OUTPUT); // GPC15 pin set to output mode
27
28
      // set GPIO pins to output Low
     DrvGPIO SetBit(E GPC, 12); // GPC12 pin output Hi to turn off LED
29
     DrvGPIO SetBit(E GPC, 13); // GPC13 pin output Hi to turn off LED
30
     DrvGPIO_SetBit(E_GPC, 14); // GPC14 pin output Hi to turn off LED
31
     DrvGPIO SetBit(E GPC, 15); // GPC15 pin output Hi to turn off LED
32
33
34
35 ⊟int main (void) {
36
      Init_LED(); // Initialize LEDs (four on-board LEDs below LCD panel)
37
38
     while (1) { // forever loop to keep flashing four LEDs one at a time
39 🗀
       DrvGPIO_ClrBit(E_GPC, 12); // Function -> output Low to turn on LED DrvSYS_Delay(DELAY300ms); // delay (The maximal delay time is 335000 us
40
41
       DrvGPIO SetBit(E GPC, 12); // output Hi to turn off LED
42
43
       DrvSYS Delay(DELAY300ms);
                                     // delay
44
                                     // Macro -> Turn 'On' LED
45
       GPC 13 = 0;
       DrvSYS_Delay(DELAY300ms); // delay
46
47
       GPC 13 = 1;
                                     // Macro -> Turn 'OFF' LED
48
       DrvSYS Delay(DELAY300ms);
                                     // delay
49
50
         DRVGPIO_DOUT (E_GPC, 14) = 0; // Macro -> Turn 'On' LED
        DrvSYS_Delay(DELAY300ms); // delay
_DRVGPIO_DOUT (E_GPC, 14) = 1; // Macro -> Turn 'OFF' LED
51
        DrvSYS Delay(DELAY300ms);
52
53
        DrvSYS Delay(DELAY300ms);
                                        // delay
54
        //DrvGPIO ClrBit(E GPC, 15);
                                       // output Low to turn on LED
55
       GPIOC->DOUT &= 0x7FFF; // turn on only LED GPC 15 DrvSYS_Delay(DELAY300ms); // delay
56
57
58
       //DrvGPIO_SetBit(E_GPC, 15); // output Hi to turn off LED
        59
60
61
        }
62
      3
63
```

# Q

uestions (LED)	
1.	What is the difference between Function on line 40 and Macro on line 45?
2.	From previous question, which one is execute faster and why?
3.	What is the difference between Macro on line 45 and Macro on line 50?
4.	From previous question, which one is execute faster and why?

#### **RGBLED**: GPA12-GPA13 to control RGB LED function



#### Procedure 3: RGBLED: GPA12-GPA13 to control RGB LED function


- 1. Replace the content of the 'Smpl\_Start\_Kit.c' with the 'RGB-LED' lab file.
- 2. Compile the project, and run the program.
- 3. Study the program and answer the following questions.

```
11
    #include <stdio.h>
12
    #include "NUC1xx.h"
    #include "Driver\DrvSYS.h"
13
14
    #include "Driver\DrvGPIO.h"
15
16
    #define DELAY300ms 300000 // The maximal delay time is 335000 us.
17
18
    // Initial GPIO pins (GPA 12,13,14) to Output mode
19 ⊟void Init RGB LED() {
      // initialize GPIO pins
20
21
      DrvGPIO_Open(E_GPA, 12, E_IO_OUTPUT); // GPA12 pin set to output mode
22
      DrvGPIO_Open(E_GPA, 13, E_IO_OUTPUT); // GPA13 pin set to output mode
      DrvGPIO Open(E GPA, 14, E IO OUTPUT); // GPA14 pin set to output mode
23
      // set GPIO pins output Hi to disable LEDs
24
      DrvGPIO_SetBit(E_GPA, 12); // GPA12 pin output Hi to turn off Blue LED
25
      DrvGPIO_SetBit(E_GPA, 13); // GPA13 pin output Hi to turn off Green LED
26
27
      DrvGPIO_SetBit(E_GPA, 14); // GPA14 pin output Hi to turn off Red
28
29
30 ⊟int main(void) {
31
      Init RGB LED();
32
      // GPA12 = Blue, 0 : on, 1 : off
33
      // GPA13 = Green, 0 : on, 1 : off
34
      // GPA14 = Red,
35
                         0 : on, 1 : off
36 🖨
      while(1) {
         // set RGBled to Blue
37
        DrvGPIO ClrBit(E GPA,12); // GPA12 = Blue, 0 : on, 1 : off
38
39
        DrvGPIO_SetBit(E_GPA, 13);
        DrvGPIO_SetBit(E_GPA,14);
40
41
        DrvSYS Delay(DELAY300ms);
                                        // delay
42
43
        // set RGBled to Green
44
        DrvGPIO SetBit(E GPA, 12);
        DrvGPIO_ClrBit(E_GPA,13); // GPA13 = Green, 0 : on, 1 : off
45
46
        DrvGPIO SetBit(E GPA, 14);
47
        DrvSYS Delay(DELAY300ms);
                                        // delav
48
49
        // set RGBled to Red
        DrvGPIO_SetBit(E_GPA, 12);
50
51
        DrvGPIO_SetBit(E_GPA,13);
        DrvGPIO_ClrBit(E_GPA,14); // GPA14 = Red,
52
                                                      0 : on, 1 : off
53
        DrvSYS Delay(DELAY300ms);
                                        // delav
54
55
        // set RGBled to off
56
        \label{eq:condition} {\tt DrvGPIO\_SetBit(E\_GPA,12); // GPA12 = Blue, 0 : on, 1 : off}
        DrvGPIO_SetBit(E_GPA,13); // GPA13 = Green, 0 : on, 1 : off
DrvGPIO_SetBit(E_GPA,14); // GPA14 = Red, 0 : on, 1 : off
57
58
59
        DrvSYS Delay(DELAY300ms);
                                       // delav
60
61
```

## **Questions** (RGBLED)

- 1. What is an alternate function for the GPA12
- 2. What Macros functions can we replace the function on line 38? (2 answers)

## 7-SEGMENT: GPE0-GPE7, GPC4-GPC7 control



# Procedure 4: 7-SEGMENT: GPE0-GPE7, GPC4-GPC7 control


- 1. Replace the content of the 'Smpl\_Start\_Kit.c' with the '7SEG' lab file.
- 2. Compile the project, and run the program.
- 3. Study the program and answer the following question.

```
12 #include <stdio.h>
13 #include "NUC1xx.h"
14 #include "DrvSYS.h"
15 #include "Seven Segment.h"
16
17 #define DELAY300ms 300000 // The maximal delay time is 335000 us.
18 #define scanDelay 4000
19
20 // display an integer on four 7-segment LEDs
21 - void seg display(int16 t value) {
     int8 t digit;
22
23
     digit = value / 1000;
24
      close seven segment();
      show seven segment (3, digit);
26
      DrvSYS Delay(scanDelay);
27
28
    value = value - digit * 1000;
    digit = value / 100;
29
30
    close seven segment();
     show_seven_segment(2,digit);
31
     DrvSYS Delay(scanDelay);
32
33
34
    value = value - digit * 100;
35
     digit = value / 10;
36
    close seven segment();
37
     show seven segment (1, digit);
     DrvSYS Delay(scanDelay);
38
39
40
      value = value - digit * 10;
     digit = value;
41
42
     close seven segment();
     show seven segment(0,digit);
44
      DrvSYS Delay(scanDelay);
45
      }
46
47 ⊟int32 t main (void) {
48
      int32 t i = 0;
49
50 \( \hat{\text{while}} \) \( (1) \) \( \)
       seg_display(i/10); // display i on 7-segment display
51
                              // increment i
        i++;
52
        if (i == 100000) i = 0;
53
54
55
    }
```

## **Questions** (7-SEGMENT)

1. What is the function to display the left most digit with '7'.

## KEYBOARD: GPAO-GPA5 to control KEYBOARD function



#### Procedure 5: KEYBOARD: GPA0-GPA5 to control KEYBOARD function

- 1. Replace the content of the 'Smpl\_Start\_Kit.c' with the 'KeyPad-7SEG' lab file.
- 2. Compile the project, and run the program. (Add ScanKey.c to the project, from "C:\Nuvoton\BSP Library\NUC100SeriesBSP\_CMSIS\_v1.05.003\NuvotonPlatform\_Keil\Src\NUC1xx-LB\_002\ScanKey.c")
- 3. Study the program and answer the following question.


```
18
   #include <stdio.h>
19
    #include "NUC1xx.h"
    #include "DrvSYS.h"
20
    #include "Seven Segment.h"
21
22
    #include "scankey.h"
23
24 = int32 t main (void) {
      int8_t number;
25
26
27
      OpenKeyPad();
28
29 🖨
      while(1) {
30
        number = Scankey();
                                       // scan keypad to get a number (1~9)
31
        show_seven_segment(0,number); // display number on 7-segment LEDs
32
        DrvSYS Delay(5000);
                                      // delay time for keeping 7-segment display
33
        close seven segment();
                                       // turn off 7-segment LEDs
34
35
```

```
#include <stdio.h>
    #include "Driver\DrvGPIO.h"
    #include "ScanKey.h"
 8
10
    void delay (void)
11
      int j;
12
13
      for(j=0;j<1000;j++);
14
15
16
    void OpenKeyPad(void)
17
      uint8_t i;
1.8
19
       /* Initial key pad */
20
      for (i=0;i<6;i++)
21
      DrvGPIO_Open(E_GPA, i, E_IO_QUASI);
22
23
     void CloseKeyPad(void)
24
25
       uint8_t i;
26
27
28
      for (i=0; i<6; i++)
29
      DrvGPIO_Close(E_GPA, i);
30
31
32
     uint8_t Scankey(void)
33
       uint8_t act[4]={0x3b, 0x3d, 0x3e};
34
35
       uint8_t i, temp, pin;
36
37
       for(i=0;i<3;i++)
38
39
         temp=act[i];
40
         for(pin=0;pin<6;pin++)
41
42
           if((temp&0x01) == 0x01)
43
             DrvGPIO_SetBit(E_GPA,pin);
44
45
             DrvGPIO_ClrBit(E_GPA,pin);
46
           temp>>=1;
47
48
       delay();
49
       if (DrvGPIO_GetBit(E_GPA, 3) == 0)
50
           return(i+1);
        if (DrvGPIO_GetBit(E_GPA, 4) == 0)
51
          return(i+4);
52
53
       if (DrvGPIO_GetBit(E_GPA, 5) == 0)
54
          return(i+7);
55
     }
56
         return 0:
57
```

#### Questions (KEYBOARD)

1. What is going to happen if the code on line 34 are changed from 0x3b, 0x3d, 0x3e to 0x3F, 0x3F, and 0x3d, respectively?

#### LCD: GPD8-GPD11 connect to LCD function.



## Procedure 6: LCD: GPD8-GPD11 connect to LCD function.

- 1. Replace the content of the 'Smpl\_Start\_Kit.c' with the 'LCD' lab file.
- 2. Compile the project, and run the program.
- 3. Study the program and do the assignment in the class.

```
10 #include <stdio.h>
11 #include "NUC1xx.h"
12 #include "LCD Driver.h"
13 #include "Driver\DrvGPIO.h"
14 #include "Driver\DrvUART.h"
    #include "Driver\DrvSYS.h"
15
16
17
    #define DELAY300ms 300000 // The maximal delay time is 335000 us.
18
19 - int main (void) {
      char 1cd3 buffer[18];
20
21
      uint32 t lcdDemoCounter = 0;
22
      Initial pannel(); //call initial pannel function
23
24
      clr_all_pannal();
25
26
      print lcd(0, "LCD demo");
      print lcd(1, "12345678901234567890");
27
28
      sprintf(lcd3 buffer, "count up = ");
29
30  while (1) {
        sprintf(lcd3 buffer+11, "%d", lcdDemoCounter);
31
32
        print_lcd(2, lcd3 buffer);
        DrvSYS Delay(DELAY300ms); // delay
33
        1cdDemoCounter++;
34
35
36
      }
```

# Assignment(s)

Summarize what you suppose to learn in this class.