

WM100 Front Load Washing Machine

User Manual Version 2.0

Product Overview

The WM100 Version 2 includes enhanced diagnostics and energy-efficient washing modes.

Error Codes

E21

E21 indicates a drain pump fault.

Steps:

1. Disconnect power.
2. Check pump wiring.
3. Remove debris from the pump housing.
4. Contact service if issue persists.

SUDS

SUDS indicates excessive detergent or restricted drainage.

Steps:

1. Reduce detergent quantity.
2. Inspect drain hose.
3. Run Tub Clean cycle.

Child Lock

To enable Child Lock:

1. Press and hold Start/Pause for 5 seconds.
2. Confirm lock symbol appears.

Maintenance

- Run Tub Clean every 20 cycles.
- Inspect pump filter monthly.