



Partner Dashboard

Adding users and building
from Partner Admin Role
(Vendor side)

Login

- Login with registered Partner Admin Role mobile number and OTP
- Make sure you get your number registered as Partner Admin from Mygate Tech Team



mygate

Login with OTP

Enter your Phone Number

Get OTP

🔔 You will receive an OTP via SMS and Email

New User? [Sign Up](#)



mygate

Enter OTP

A 6 digit OTP has been sent to your registered email Address and Phone Number(XXXXXXXX919).

1 2 3 4 5 6




Verify

[Resend OTP](#)




Add New Building

- Click on the “**Add Building**” Button.
- Add building details.
- Click on the view button to start adding more details for building like rooms and connect locks to rooms




Add Building Details

- Add the **building manager**.
Select from the list or add new from “Manager” section
- Click on “**Add room**” to keep adding new rooms.
- After adding the rooms, click on the “**Connect Lock**” button to attach the Serial number of the lock installed on the door of the room.
You can find the serial numbers pasted inside lock battery panel.








- Make sure that the lock is already setup and is present in the system before you start mapping it to the room.



How to Setup Lock from App

- Install “**Mygate Smart Devices**” app and register with user who will be having the **Super Admin Role** on all the locks configured by that mobile number.
- Click on “**+Add**” button, then select “Smart Lock” and follow the steps shown on the screen to setup your lock.
- Ensure that you are near the lock while performing this action and lock is installed and has battery put in.







Partner Dashboard

Create and Manage PINs
(Vendor side)


Add New PIN Access

- Click on the “**Properties**” from the side bar.
- Select the tab “**Manage PINs**”
- OR Select “**Manage PINs**” from the Side bar.
- Click on “**Create New PIN**”.



Add New PIN Access

- Enter PIN Label i.e identifier for the access.
- Select the user you are creating the access for.
- Choose the property and room for which access is being created.
- Select the PIN type. (Note for Custom PIN, your lock should be connected to Gateway).
- Select the Validity period and then click on Create PIN to generate the access.
- Please note that One-time validity is not available for custom PIN.



The screenshot shows a mobile application interface for creating a new PIN. The form is titled "Create New PIN" and includes a close button (X) in the top right corner. The form is divided into several sections:

- PIN Label:** A text input field with the placeholder "Enter a label for this PIN". Below it, a smaller text input field with the placeholder "Enter a name or description to identify this PIN".
- Assign to (Optional):** A dropdown menu with the placeholder "Select a user".
- Property:** A dropdown menu with the placeholder "Choose a property".
- Room:** A dropdown menu with the placeholder "Choose a property first".
- PIN Type:** Two radio button options:
 - Auto PIN:** Selected by default. Description: "PIN automatically generated by the app".
 - Custom PIN:** Description: "Create a PIN by entering 6-9 digit numeric code".
- Validity Period:** Two radio button options:
 - Permanent:** Selected by default. Description: "This PIN will remain active until manually deleted".
 - Timed:** Description: "This will provide access within the specified time period".

At the bottom right of the form, there is a yellow button labeled "+ Create PIN".



Partner Dashboard

Create and Manage App
Access
(Vendor side)

Add New App Access

- Click on the “**Manage Access**” from the side bar.
- Select the tab “**App Access**” to view the list of App accesses created.
- Click on “**Create New Access**”, Select “**App Access**”

The image displays two screenshots of the mygate web application interface, showing the 'Manage Access' section for the 'B2B Product Testing Property'.

Top Screenshot: The 'Manage Access' section is active, showing the 'App Access' tab. The interface indicates 'No App Access Created Yet' and provides a '+ Create App Access' button. The sidebar shows 'Properties', 'Managers', 'Locks', and 'Manage Access' (selected). The top right shows 'Total Buildings: 2' and 'Active Locks: 1'.


Bottom Screenshot: The 'Manage Access' section is active, showing the 'App Access' tab. The interface displays a table of existing app accesses. The sidebar shows 'Properties', 'Managers', 'Locks', and 'Manage Access' (selected). The top right shows 'Total Buildings: 2' and 'Active Locks: 1'. A '+ Create New Access' button is visible in the top right corner of the main content area.

LABEL	PROPERTY	ROOM	VALIDITY	ASSIGNED TO	STATUS	CREATED ON
Test app access - anil	B2B Product Testing HSR	Room 2	Permanent	Anil Mishra	Active	Jan 30, 2026

Results: 1-1 of 1 | Prev | Next

Add New App Access

- Enter App Label i.e identifier for the access.
- Select the user you are creating the access for.
- Choose the property and room for which access is being created.
- Select the Validity period.
- By-default the make-authorized admin toggle is turn ON, i.e. when you create the app access user will get the admin access for the lock.
- If you wish not to provide admin access, turn OFF the toggle.



The screenshot shows a 'Create New App Access' modal window. It contains several input fields: 'App Access Label' with a placeholder 'Enter a label' and a hint 'Enter a name or description to identify this Access.', 'Assign to' with a 'Select user' dropdown, 'Property' with a 'Choose property' dropdown, and 'Room' with a 'Select property first' dropdown. The 'Validity Period' section has two radio button options: 'Permanent' (selected) with the description 'This PIN will remain active until manually deleted', and 'Timed' with the description 'This will provide access within the specified time period'. At the bottom, there is a 'Make authorised admin' toggle switch which is currently turned ON, with the text 'Authorised admins can create new keys but cannot add new admins' below it. A yellow button labeled '+ Create App Access' is at the bottom right.

Create New App Access

App Access Label

Enter a label

Enter a name or description to identify this Access.

Assign to

Select user

Property

Choose property

Room

Select property first

Validity Period

☒ Permanent
This PIN will remain active until manually deleted

☐ Timed
This will provide access within the specified time period

Make authorised admin

Authorised admins can create new keys but cannot add new admins

+ Create App Access