

Field Service — Frequently Asked Questions

Quick answers for AF-series field and support staff

Document No: FAQ-FS-REV-2 | Updated: March 2026

Q: What lubricant should I use for AF-4500 bearing housings?

A: Atlas HydraSeal AH-220 only. Using a non-approved lubricant voids the warranty (see the Warranty & Service Policy).

Q: How often should mechanical seals be replaced?

A: Annually as part of scheduled maintenance, or immediately upon leakage. Follow SOP-114.

Q: Who do I call for parts outside business hours?

A: The Houston Technical Support desk (+1 713 555 0198) operates 24/7 for critical customer downtime.

Q: What's the standard warranty period?

A: 24 months from commissioning, or 30 months from shipment, whichever occurs first.

Q: Where do I log a completed service visit?

A: In the Atlas FieldOps app, under the equipment's serial number, within 24 hours of the visit.

Q: What's the maximum impeller wear ring clearance before replacement?

A: 0.75 mm for AF-4510/AF-4520, 0.80 mm for AF-4530. See Section 7 of the IOM manual.

Q: Can I substitute a non-Atlas mechanical seal kit?

A: No. Only RSK-4500 series kits are warranty-approved for AF-4500 series pumps.

Q: What should I do if a pump won't reach rated flow after installation?

A: Check for suction air leaks, confirm motor rotation direction, and verify wear ring clearance — see the AF-4500 Troubleshooting Guide.

Q: How do I request an Atlas CarePlus upgrade for a customer?

A: Submit a request via the Customer Success portal; response SLAs are listed in the Warranty & Service Policy.

Q: Who approves warranty claims?

A: Technical Support opens the claim; an Atlas-certified technician inspects and issues the determination within 10 business days.

SYNTHETIC DOCUMENT — created for a portfolio project simulation.