







3V3 power - 1 2 • 5V power GPIO 2 (SDA) - 3 4 • 5V power GPIO 3 (SCL) - 6 6 Ground GPIO 4 (GPCLK0) - 7 3 • GPIO 14 (TXD) Ground - 9 10 GPIO 15 (RXD) GPIO 17 - 10 12 GPIO 18 (PCM\_CLK) GPIO 27 - (3) (4) Ground GPIO 22 - (5) (6) GPIO 23 3V3 power - 17 (8) GPIO 24 GPIO 10 (MOSI) - 19 20 o Ground GPIO 9 (MISO) - 20 20 o GPIO 25 GPIO 11 (SCLK) → ② ② • GPIO 8 (CEO) Ground - 25 26 GPIO 7 (CE1) GPIO 0 (ID\_SD) - 27 20 • GPIO 1 (ID\_SC) GPIO 5 - 29 30 Ground GPIO 6 - 3 3 o GPIO 12 (PWM0) GPIO 13 (PWM1) - 33 34 • Ground GPIO 19 (PCM\_FS) - 35 36 • GPIO 16 GPIO 26 - 37 39 O GPIO 20 (PCM\_DIN)

Ground - 99 40 GPIO 21 (PCM\_DOUT)

| Raspberry Pi Configuration • • • × |                                 |            |                           |              |  |  |
|------------------------------------|---------------------------------|------------|---------------------------|--------------|--|--|
| System                             | Display                         | Interfaces | Performance               | Localisation |  |  |
| Camera:                            | O E                             | ○ Enable   |                           | Disable      |  |  |
| SSH:                               | ○ E                             | ○ Enable   |                           | Disable      |  |  |
| VNC:                               | <ul><li>● E</li></ul>           | nable      | O Disable                 |              |  |  |
| SPI:                               | ○ E                             | nable      | Disable                   |              |  |  |
| I2C:                               | 2C: • Enable                    |            | O Disable                 |              |  |  |
| Serial Port: Enable                |                                 | nable      | <ul><li>Disable</li></ul> | Disable      |  |  |
| Serial Console:   • Enab           |                                 | nable      | ○ Disable                 | ○ Disable    |  |  |
| 1-Wire:                            | ○ Enable                        |            | Disable                   |              |  |  |
| Remote GPIO: Enable                |                                 |            | Disable                   |              |  |  |
| Cancel OK                          |                                 |            |                           |              |  |  |
| pi@raspberr<br>0 1                 | r <b>ypi:∼ \$</b> i2<br>2 3 4 5 |            | 1<br>9 a b o              | d e f        |  |  |
| 00:                                |                                 |            |                           |              |  |  |
| 10:<br>20:                         |                                 |            |                           |              |  |  |
| 30:                                |                                 |            |                           |              |  |  |
| 40:                                |                                 |            |                           |              |  |  |
| 50:                                |                                 |            |                           |              |  |  |
| 60:                                |                                 | 77         |                           |              |  |  |

git clone https://github.com/adafruit/Adafruit-Raspberry-Pi-Python-Code.git cd Adafruit-Raspberry-Pi-Python-Code/git checkout 9ff733d59242a02f7ccd0222001ce80f6090a978 cd Adafruit\_BMP085

sudo python Adafruit\_BMP085\_example.py