

## Door/Window Enter Alarm

**323**



**323A**



**323B**



**333**



**358(LED LIGHT)**



\*When the thief enter, it will give 105 DB high alarm sound

\*Power: LR-44 AG13 batteries three included

\*Fixing convenience.consume fewness battery

333:AAA batteries two(not included)



**Private Alarm**

**Door Handle Alarm**

**324**



**326**



**328**



**151**



Power: LR-44 AG13 batteries three included

\*105 DB high alarm sound

DC9V (not included)

**Key Pad Alarm**

**353**



**PIR Key Pad Alarm**

**107**



DC 4.5V 3AA batteries(not included)

**Vibration Alarm**

**525**



DC 4.5V 3AG13 batteries( included)

\*With CE & ROHS