Exp.7 Dimonstrate to show the working of PIR surson. Mardware Required: CED Ben, Andureno Board, Bredhoard, Resistor, Sinsor. PIR Susor. Code: Put sussenstate = 0; aduted blow senMode (2, INPUT); penMode (13, OUTPUT); Sural "byen (9600); vold loop () smoon state = degetal Read (2); of (surson state = = HIGH) degetal Weste (13, HIGH); Directle prently ("Sunsor activisted"); degetal Write (13, LOW);
delay (10);

