Spatial XRD patterns by sulfurization condition (no vertical offset)

Measurement position
phi0(0,-15) phi0(0,-7) phi0(0,0) phi0(0,7) phi0(0,15) phi90(-15,0) phi90(-7,0) phi90(0,0) phi90(7,0) phi90(15,0)

1 min Sulfurization
2 min Sulfurization
5 min Sulfurization
10 min Sulfurization

Intensity (counts)
2θ (degrees)

Theoretical reference peaks
CuS reference
ZnS reference