Spatial XRD patterns by sulfurization condition

Measurement position
phi0(0,-15) phi0(0,-7) phi0(0,0) phi0(0,7) phi0(0,15) phi90(-15,0) phi90(-7,0) phi90(0,0) phi90(7,0) phi90(15,0)

1 min Sulfurization

2 min Sulfurization

5 min Sulfurization

10 min Sulfurization

Intensity (counts) + vertical offset

2θ (degrees)

Theoretical reference peaks
CuS reference
ZnS reference