

Chemistry Lab Floor Storage Shelf A

COMPLETE PARTS LIST WITH IDS

Overall Dimensions: 92" Wide × 23.25" Deep × 25.5" High (including base skids)

Part ID	Part Name	Qty	Material	Dimensions	Function
P1	Top Panel	1	3/4" Plywood	92" × 23.25"	Top exterior cover cap
P2	Bottom Panel	1	3/4" Plywood	92" × 23.25"	Bottom exterior base
P3	Back Panel	1	3/4" Plywood	92" × 24"	Full rear panel (locks box square)
P4	Left Side Panel	1	3/4" Plywood	22.5" × 23.25"	Left outer wall
P5	Right Side Panel	1	3/4" Plywood	22.5" × 23.25"	Right outer wall
P6	Center Divider	1	3/4" Plywood	22.5" × 23.25"	Main vertical divider
P7	Long Shelf	1	3/4" Plywood	60.25" × 23.25"	Right section shelf
P8	Small Shelves	3	3/4" Plywood	29.5" × 23.25"	Left section shelves (P8a, P8b, P8c)
P9	Shelf Stiffener	1	1×2 Pine	56" × 1.5"	Anti-sag reinforcement under P7 (centered, 2" clearance)
P10	Shelf Cleats	8	1×2 Pine	20" × 1.5"	Support ledges on inside walls (4 per section)
P11	Base Skids (Feet)	3	2×4 Pine	23.25" × 3.5"	Floor elevation (left, center, right - 1.5" height)

CABINET LAYOUT BREAKDOWN:

LEFT SECTION: P4 (left side) + P6 (left face of divider) + 3 small shelves (P8a, P8b, P8c) + 6 cleats

CENTER: P6 (center divider) separates left and right sections

RIGHT SECTION: P5 (right side) + P6 (right face of divider) + 1 long shelf (P7 with P9 stiffener) + 2 cleats

HORIZONTAL: P1 (top), P2 (bottom with P11 skids), P3 (back panel)

ASSEMBLY SEQUENCE (Quick Reference):

- 1■■■ Glue P9 stiffener to P7 long shelf
- 2■■■ Attach P11 base skids to P2 bottom panel
- 3■■■ Mount 8× P10 cleats on vertical panels (P4, P5, P6)
- 4■■■ Position shelves (P8 & P7) on cleats
- 5■■■ Attach P1 (top) and P2 (bottom) panels to frame
- 6■■■ Attach P3 (back panel) to lock cabinet square
- 7■■■ Sand, prime, and paint