

ALL PARTS AT A GLANCE

P1 - P11 Complete Reference

FRAME PANELS (Plywood)

ID	Name	Size	Purpose	Material
P1	Top Panel	92" × 23.25" × 3/4"	Exterior top cover (horizontal)	Plywood
P2	Bottom Panel	92" × 23.25" × 3/4"	Exterior base (horizontal)	Plywood
P3	Back Panel	92" × 24" × 3/4"	Full rear backing (locks square)	Plywood
P4	Left Side Panel	22.5" × 23.25" × 3/4"	Left exterior wall (vertical)	Plywood
P5	Right Side Panel	22.5" × 23.25" × 3/4"	Right exterior wall (vertical)	Plywood
P6	Center Divider	22.5" × 23.25" × 3/4"	Main vertical divider (vertical)	Plywood

SHELVES (Plywood)

ID	Name	Size	Purpose	Material
P7	Long Shelf	60.25" × 23.25" × 3/4"	Right section shelf with stiffener	Plywood
P8	Small Shelves (×3)	29.5" × 23.25" × 3/4"	Left section shelves (P8a, P8b, P8c)	Plywood

SUPPORT STRUCTURE (Pine)

ID	Name	Size	Purpose	Material
P9	Shelf Stiffener	56" × 1.5" × 0.75"	Anti-sag lip under P7 (centered)	Pine 1×2
P10	Shelf Cleats (×8)	20" × 1.5" × 0.75"	Support ledges on vertical panels	Pine 1×2
P11	Base Skids (×3)	23.25" × 3.5" × 1.5"	Feet (L/C/R) elevate cabinet 1.5"	Pine 2×4

QUICK SUMMARY

Category	Quantity	Total Count
Plywood Panels (P1-P8)	8 pieces	3 sheets @ 3/4"
Support Structure (P9-P10)	9 pieces	2 boards 1×2, various lengths
Base Skids (P11)	3 pieces	1 board 2×4, cut into 3
TOTAL PARTS	20 pieces	3 plywood sheets + 3 lumber boards

KEY FACTS:

Assembly Sequence: P9→P7 | P11→P2 | P10→Panels | Shelves→Cleats | P1→Frame | P2→Frame | P3→Back

Total Weight: Approximately 150-180 lbs when fully assembled

Total Fasteners Used: ~100+ (wood screws, finish nails, brad nails)

Glue Used: 1 bottle of Titebond II (16 oz)

Clamping Time: 24-48 hours total during assembly

Build Time: 6-8 hours (not counting primer/paint drying)