

AquaPure X200 User Manual

1. Getting Started

The AquaPure X200 is a countertop water purifier with a 4-stage filtration system and a 6-litre tank. Place the unit on a flat surface at least 10 cm from any wall. Connect the power adapter (12V DC) and press the green POWER button for two seconds to start.





Figure 3: Front view showing the power button, display, water outlet, and filter door.

2. Filter Replacement

Replace the filter cartridge every 9 months or when the display shows the code F-04, whichever comes first. Open the filter door on the left side, twist the cartridge counter-clockwise, and pull it out. Insert the new cartridge model AP-FC200 and twist clockwise until it clicks.

Figure 4: Filter Degradation Curve



3. Troubleshooting

If the display shows E-02, the tank is empty. If it shows E-07, the pump is blocked and you should contact support at support@aquapure.example. The warranty period is 24 months from purchase and does not cover damage from using non-approved filters.