

목차



- ▶ 기초 학습
 - > TIME 함수
- ▶ Touch 감지
 - ▶ 개요
 - > 예제
- > 응용 실습

1채널 FND




• FND란?

- Flexible Numeric Display(가변 숫자 표시기)의 약자로 7-segment라고도 함
- 주로 숫자를 표시하기 위해 만들어진 LED 조합으로 수치데이터와 시간 등을 보기 위해 사용됨
- LED의 각 핀은 a∼g의 기호가 붙어 있으며, 이것들을 세그먼트라 함
- 이들 a~g에 해당하는 핀에 High와 Low를 인가하여 LED를 점등함으로써 숫자 표현



- Commom-Anode(+) 종류: 공통이 5V 전원이고 0V 입력하면 켜짐
- Common-Cathod(-) 종류: 공통이 GND이고 5V 입력하면 켜짐



애노드와 캐소드 핀맵

1채널 FND 사용하기



- 아두이노와 애노드타입의 1채널 FND를 이용하여 1~9까지 출력
 - 애노드는 LOW를 넣어야 선에 불이 들어옴
- 캐소드 타입은 전장의 핀맵을 확인하셔서 회로 구성
- 준비물
 - 아두이노 & 케이블
 - 1채널 FND(애노드)
 - 220옴 저항
 - 브레드보드
 - 점퍼케이블

















- 애노드에서는 신호를 LOW로 주었을때 불이 들어옴
- 1채널 FND 회로 구성
 - g D3
 - f D2
 - vcc 220옫 vcc
 - a D5
 - b D6
 - e D8
 - d D9
 - c D11
 - dp D12







```
void setup(){
          pinMode(3, OUTPUT); //디지털 핀 출력 정의
          pinMode(2, OUTPUT);
          pinMode(5, OUTPUT);
          pinMode(6, OUTPUT);
          pinMode(8, OUTPUT);
          pinMode(9, OUTPUT);
          pinMode(11, OUTPUT);
          pinMode(12, OUTPUT);
void loop(){
          digitalWrite(3, HIGH);
                                         digitalWrite(2, HIGH);//1
          digitalWrite(5, HIGH);
                                         digitalWrite(6, LOW);
          digitalWrite(8, HIGH);
                                         digitalWrite(9, HIGH);
          digitalWrite(11, LOW);
                                         digitalWrite(12, HIGH);
          delay(1000);
          digitalWrite(3, LOW);
                                         digitalWrite(2, HIGH);//2
          digitalWrite(5, LOW);
                                         digitalWrite(6, LOW);
          digitalWrite(8, LOW);
                                         digitalWrite(9, LOW);
          digitalWrite(11, HIGH);
                                         digitalWrite(12, HIGH);
          delay(1000);
```



```
digitalWrite(2, HIGH);//3
digitalWrite(3, LOW);
                              digitalWrite(6, LOW);
digitalWrite(5, LOW);
digitalWrite(8, HIGH);
                              digitalWrite(9, LOW);
digitalWrite(11, LOW);
                              digitalWrite(12, HIGH);
delay(1000);
digitalWrite(3, LOW);
                              digitalWrite(2, LOW);//4
                              digitalWrite(6, LOW);
digitalWrite(5, HIGH);
digitalWrite(8, HIGH);
                              digitalWrite(9, HIGH);
                              digitalWrite(12, HIGH);
digitalWrite(11, LOW);
delay(1000);
digitalWrite(3, LOW);
                              digitalWrite(2, LOW);//5
                              digitalWrite(6, HIGH);
digitalWrite(5, LOW);
digitalWrite(8, HIGH);
                              digitalWrite(9, LOW);
digitalWrite(11, LOW);
                              digitalWrite(12, HIGH);
delay(1000);
digitalWrite(3, LOW);
                              digitalWrite(2, LOW);//6
digitalWrite(5, LOW);
                              digitalWrite(6, HIGH);
digitalWrite(8, LOW);
                              digitalWrite(9, LOW);
digitalWrite(11, LOW);
                              digitalWrite(12, HIGH);
delay(1000);
```



```
digitalWrite(3, HIGH);
                                digitalWrite(2, HIGH);//7
digitalWrite(5, LOW);
                                 digitalWrite(6, LOW);
digitalWrite(8, HIGH);
                                 digitalWrite(9, HIGH);
digitalWrite(11, LOW);
                                 digitalWrite(12, HIGH);
delay(1000);
digitalWrite(3, LOW);
                                digitalWrite(2, LOW);//8
digitalWrite(5, LOW);
                                 digitalWrite(6, LOW);
digitalWrite(8, LOW);
                                digitalWrite(9, LOW);
digitalWrite(11, LOW);
                                digitalWrite(12, HIGH);
delay(1000);
digitalWrite(3, LOW);
                                digitalWrite(2, LOW);//9
digitalWrite(5, LOW);
                                digitalWrite(6, LOW);
digitalWrite(8, HIGH);
                                 digitalWrite(9, HIGH);
digitalWrite(11, LOW);
                                 digitalWrite(12, HIGH);
delay(1000);
digitalWrite(3, HIGH);
                                digitalWrite(2, LOW);//0
digitalWrite(5, LOW);
                                digitalWrite(6, LOW);
digitalWrite(8, LOW);
                                 digitalWrite(9, LOW);
                                digitalWrite(12, HIGH);
digitalWrite(11, LOW);
delay(1000);
```

응용 실습

도전



- 버튼을 두 개 만들어 하나의 버튼을 누르면 숫자를 증가시키고, 다른 하나의 버튼은 숫자 감소시키기
- 시리얼 창에서 입력받은 숫자를 1채널 FND로 표현하기