IN-CABIN CHECK		FUSELAGE & EMPANNAGE	
Aircraft Papers ARROW		Skin	CHECK
Hobbs	VERIFY	Antennas	CHECK
Control Lock	REMOVE	Baggage Door	LOCK
Ignition	KEY OUT	Gust Lock	REMOVE
Avionics	OFF	Elevator/Rudder	CHECK
Beacon	ON	Trim tabs	CHECK
Circuit Breakers	IN	Tie down	REMOVE
Master Switch	ON	RIGHT MAIN GEAR	
Fuel Quantity	CHECK	Strut	CHECK
Wing Flaps	DOWN	Tire (30 psi)	CHECK
External Lights	CHECK	Brake system	CHECK
External Lights	OFF	Chocks	CHECK
Master Switch	OFF		
		RIGHT WING	
FUEL AND OIL		Flaps	CHECK
Sump Left & Right Tanks		Aileron	
Use Ladder to Return Fuel to Tank		Wing tip & lights	
Verify Fuel Level on Both sides		Wing leading edge	CHECK
Fuel Strainer on Cowling (2 sec)		Wing Strut	CHECK
Check Oil - add if 4qt "cold"		Tie down	
		Cabin ventilation	CHECK
LEFT MAIN GEAR			
Strut		NOSE	
Tire (30 psi)		Windscreen	
Brake system		Right Cowling	CHECK
Chocks	CHECK	Muffler	
		Air Intakes(bird plugs)	
LEFT WING		Alternator Belt	
Cabin Ventilation		Air Filter	
Wing Strut		Propeller	
Pitot mast		Spinner	
Stall Warning		Landing Lights	
Fuel Tank Vent		Nose Strut & Steering CHECK	
Tie down		Nose Tire (30 psi)	
Wing Leading Edge		Chocks	
Wing Tip & Lights		Left Cowling	
Aileron		Static Source	CHECK
Flaps	CHECK		