

1. list 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

Issue	Possible Solution
1. Keyboard or mouse is not detected.	Reconnect the device or try a different USB port.
2. Device works intermittently.	Check for loose connections and replace a damaged USB cable if necessary.
3. Keyboard keys or mouse buttons are not responding.	Clean the device and restart the laptop.
4. Device driver is missing or outdated.	Update or reinstall the USB keyboard/mouse driver through Device Manager.
5. Wireless USB mouse or keyboard is not working.	Replace the batteries and ensure the USB receiver is properly connected.

2. Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Step 1: Check Battery Level

- Ensure that the Bluetooth headphones are charged.
- Verify that the power indicator light is on.

Step 2: Turn On Bluetooth

- Open **Settings > Bluetooth** on the phone.
- Make sure Bluetooth is enabled.

Step 3: Put Headphones in Pairing Mode

- Press and hold the power or Bluetooth button on the headphones.
- Check if the indicator light starts blinking, showing that pairing mode is active.

Step 4: Search for the Headphones

- In the phone's Bluetooth settings, tap **Scan** or **Available Devices**.
- Select the name of the headphones from the list.

Step 5: Remove Previous Pairing

- If the headphones appear but do not connect, tap **Forget Device**.
- Put the headphones back into pairing mode and reconnect them.

Step 6: Restart Devices

- Turn off the phone and headphones.
- Turn them back on and try connecting again.

Step 7: Check Distance and Interference

- Keep the headphones close to the phone.
- Move away from other Bluetooth devices that may cause interference.

Step 8: Update Software

- Check for phone software updates.
- Install any available updates and try connecting again.

Step 9: Reset the Headphones

- Follow the manufacturer's instructions to reset the headphones.
- Pair them with the phone again.

Step 10: Test with Another Device

- Try connecting the headphones to another phone or computer.
- If they still do not connect, the headphones may require repair or replacement.

3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Hint: Consider device manager, privacy settings, and app permissions.

Checklist for Fixing an External Webcam Not Detected in Zoom on Windows 10

1. Check the USB Connection

- Ensure the webcam is properly connected to the USB port.
- Try a different USB port if necessary.

2. Verify Device Manager

- Open **Device Manager** and check if the webcam appears under **Cameras** or **Imaging Devices**.
- Update or reinstall the webcam driver if there is a warning icon.

3. Check Windows Privacy Settings

- Go to **Settings > Privacy > Camera**.
- Make sure **Camera access for this device** is turned on.

4. Allow App Permissions

- Under **Settings > Privacy > Camera**, ensure that **Allow desktop apps to access your camera** is enabled.
- Verify that Zoom has permission to use the camera.

5. Check Zoom Camera Settings

- Open Zoom and go to **Settings > Video**.
- Select the external webcam from the camera drop-down menu.

6. Restart Devices and Update Software

- Restart the computer and reconnect the webcam.
- Make sure Windows 10 and Zoom are updated to the latest version.

4. You are helping a friend whose printer is showing 'offline' status on their PC.
Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Using Windows Troubleshooter to Fix a Printer Showing 'Offline'

Step 1: Open Settings

- Click the **Start** button and select **Settings**.
- Go to **Update & Security > Troubleshoot**.

Step 2: Open Additional Troubleshooters

- Click **Additional Troubleshooters**.
- Select **Printer** from the list.

Step 3: Run the Troubleshooter

- Click **Run the Troubleshooter**.
- Choose the printer that is showing the **Offline** status.

Step 4: Allow Windows to Scan

- Windows will automatically check for common problems such as:
 - Printer connection issues
 - Incorrect printer settings
 - Missing or outdated drivers
 - Problems with the Print Spooler service
 - Network connectivity issues (for wireless printers)

Step 5: Apply Recommended Fixes

- If Windows finds a problem, it will display the issue and suggest a solution.
- Click **Apply this fix** if prompted.

Step 6: Verify the Printer Status

- After the troubleshooting process is complete, check whether the printer status has changed from **Offline** to **Online**.
- Print a test page to confirm that the printer is working properly.

Information Provided by the Troubleshooter

During the process, the Windows Troubleshooter provides:

- The name of the printer being diagnosed.
 - The status of each test being performed.
 - Details about any problems detected.
 - Recommended fixes or actions taken automatically.
 - A final report showing whether the issue was fixed or if further action is required.
- .