



austriamicrosystems AG

is now

ams AG

The technical content of this austriamicrosystems datasheet is still valid.

Contact information:

Headquarters:

ams AG
Tobelbaderstrasse 30
8141 Unterpremstaetten, Austria

Tel: +43 (0) 3136 500 0

e-Mail: ams_sales@ams.com



Please visit our website at www.ams.com



AS3935 Franklin Lightning Sensor IC

1 General Description

The AS3935 is a programmable fully integrated Lightning Sensor IC that detects the presence and approach of potentially hazardous lightning activity in the vicinity and provides an estimation on the distance to the head of the storm. The embedded lightning algorithm checks the incoming signal pattern to reject the potential man-made disturbers.

The AS3935 can also provide information on the noise level and inform the external unit (e.g. microcontroller) in case of high noise conditions, with the noise floor generator and noise floor evaluation blocks.

The AS3935 can be programmed via a 4-wire standard SPI or an I²C. Also, in case the latter is chosen, it is possible to choose among four different addresses. Two clocks are internally generated by two different RC-Oscillators: TRCO and SRCO. An automatic procedure can increase the precision of those oscillators. The AS3935 can be either supplied by an internal voltage regulator or directly by VDD.


2 Key Features

■ Lightning sensor warns of lightning storm activity within a radius

- Distance estimation to the head of the storm down to 1km in 14
- Detects both cloud-to-ground and intra-cloud (cloud-to-cloud)
- Embedded man-made disturber rejection algorithm
- Programmable detection levels enable threshold setting for optimal controls
- SPI and I2C interface is used for control and register reading
- Antenna Tuning to compensate variations of the external
- Supply voltage range 2.4V to 5.5V
- Power-down, listening, and active mode
- Package: 16LD MLPQ (4x4mm)

3 Applications

AS3935 is ideal for Weather Stations, Clocks, Sports Equipment, Portables, Pool Safety, Uninterruptible Power Supply (UPS), Global Positioning System (GPS), Cellular phones, Watches, and Golf Equipment.






Contents

1	General Description	1
2	Key Features	1
3	Applications	1
4	Pin Assignments	3
	4.1 Pin Descriptions	3
5	Absolute Maximum Ratings	4
6	Electrical Characteristics	5
	6.1 Operating Conditions	;
	6.2 DC/AC Characteristics for Digital Inputs and Outputs	4
	6.3 Detailed System and Block Specification	;
7	Typical Operating Characteristics	7
8	Detailed Description	8
	8.1 Circuit	11
	8.2 Operating Modes	11
	8.3 System and Block Specification	11
	8.3.1 Register Table	11
	8.3.2 Register Table Description and Default Value	12
	8.4 Serial Peripheral Interface (SPI)	
	8.4.1 SPI Command Structure	
	8.4.2 Writing of Register Data	
	8.4.3 Reading of Data from Addressable Registers (READ Mode)	
	8.4.4 Send Direct Command Byte	
	8.5 I ² C	
	8.5.2 I ² C Register Read	
	8.5.3 Direct Command	
	8.6 Voltage Regulator	
	8.7 Analog Front-end (AFE) and Watchdog	
	8.8 Noise Floor Generator and Evaluation	
	8.9 Lightning Algorithm	20
	8.9.1 Signal Validation	
	8.9.2 Energy Calculation	2 ²
	8.9.3 Statistical Distance Estimation	2′
	8.9.4 Interrupt Management	
	8.10 Antenna Tuning	
	8.11 Clock Generation	
9	Package Drawings and Markings	24
1(0. Ordering Information	26



4 Pin Assignments

Figure 2. Pin Assignments (Top View)



4.1 Pin Descriptions

Table 1. Pin Descriptions

Pin Number	Pin Name	Pin Type	Description
1	ACG	0	AC-Ground
2	INN	Analog I/O	Antenna ground
3	INP		Antenna positive input
4	GND		Ground
5	VDD	Supply pad	Positive supply voltage
6	VREG		Positive supply voltage / Regulated voltage
7	EN_VREG		Voltage Regulator Enable
8	CS	Digital input	Chip Select (active low)
9	SI		Select Interface (GND \rightarrow SPI or VDD \rightarrow I 2 C)
10	IRQ	Digital output	Interrupt
11	I2CL/SCL	Digital input	I ² C clock bus or SPI clock bus (according to SI setting)
12	MISO	Digital output	SPI data output bus
13	I2CD/MOSI	Digital I/O with pull-up / Digital input	I ² C data bus or SPI data input bus (according to SI setting)
14	NC		Not connected
15	ADD0	Digital input	I ² C address selection LSB
16	ADD1	Digital input	I ² C address selection MSB
E	xposed pad	Supply pad	Connect to Ground via the GND plan and pin 4



5 Absolute Maximum Ratings

Stresses beyond those listed in Table 2 may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated in Electrical Characteristics on page 5 is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

Table 2. Absolute Maximum Ratings

Input pin v Input current (latch Electrostatic Discharge Electrostatic d Continuous Power Dis	lischarge (ESD)	-0.5 -0.5 -100	7 5 100	V V mA	Norm: Jedec 78
Input pin v Input current (latch Electrostatic Discharge Electrostatic d Continuous Power Dis	oltage (VIN) n up immunity), (I _{scr}) e lischarge (ESD)	-0.5 -100	5	V	Norm: Jedec 78
Input current (latch Electrostatic Discharg Electrostatic d Continuous Power Dis	n up immunity), (I _{scr}) e lischarge (ESD)	-100			Norm: Jedec 78
Electrostatic Discharge Electrostatic d Continuous Power Dis	e lischarge (ESD)		100	mA	Norm: Jedec 78
Electrostatic d	lischarge (ESD)	±2			
Continuous Power Dis		±2			
		1		kV	Norm: MIL 883 E method 3015 (Human Body Model)
	sipation	- 1			
Total powe (all supplies a	r dissipation nd outputs), (P _t)		0.1	mW	
Temperature Ranges a	nd Storage Conditions	•			
Storage temp	perature (T _{strg})	-65	150	°C	M. 3
Package body te	emperature (T _{body})		260	°C	Norm: IPC/JEDEC J-STD-020 The reflow peak soldering temperature (boo temperature) is specified according IPC/JEDE STD-020 "Moisture/Reflow Sensitivity Classificating Non-hermetic Solid State Surface Mount Device Normal Property State Surface Mount Device Normal Normal Property State Surface Normal N
Humidity no	n-condensing	5	85	%	0
Moisture Sensit	tivity Level (MSL)		3		Represents a maximum floor life time of 168
	· C				
(e C)					



6 Electrical Characteristics

6.1 Operating Conditions

In this specification, all the defined tolerances for external components need to be assured over the whole operation conditions range and also over lifetime.

Table 3. Operating Conditions

Symbol	Parameter	Conditions	Min	Тур	Max	Units
VDD	Positive supply voltage	In case the voltage regulator is ON	2.4		5.5	V
VDD	Fosilive supply vollage	In case the voltage regulator is OFF	2.4		3.6	V
Тамв	Ambient temperature		-40		85	°C

6.2 DC/AC Characteristics for Digital Inputs and Outputs

Table 4. CMOS Input

Symbol	Parameter	Conditions	Min	Тур	Max	Units
VIH	High level input voltage		0.6*VDD	0.7*VDD	0.9*VDD	٧
VIL	Low level input voltage		0.125*VDD	0.2*VDD	0.3*VDD	٧

Note: On ALL outputs, use the cells with the smallest drive capability which will do the job, in order to prevent current/spikes problems.

Table 5. CMOS Output

Symbol	Parameter	Conditions	Min	Тур	Max	Units
Voн	High level output voltage	With a load current of 1mA	VDD-0.4			٧
Vol	Low level output voltage	With a load current of fina			VSS+0.4	V
CL	Capacitive load	For a clock frequency of 1MHz			400	pF

Table 6. Tristate CMOS Output

Symbol	Parameter Conditions		Min	Тур	Max	Units
Voн	High level output voltage	With a load current of 1mA	VDD-0.4			V
Vol	Low level output voltage	With a load current of TillA			VSS+0.4	V
loz	Tristate leakage current	To VDD and VSS			400	nA

6.3 Detailed System and Block Specification

Table 7. Electrical System Specifications

Symbol	Parameter	Min	Тур	Max	Units	Note
Input Characte						
Rin	Input AC impedance		200		kΩ	
Current Consu	umption					
IPWDROFF	Power-down current when VREG is OFF		1	2	μΑ	
IPWDRON	Power-down current when VREG is ON 8 15 μA		μΑ			
ILSMROFF	Current consumption in listening mode when VREG is OFF		60	80	μΑ	
ILSMRON	Current consumption in listening mode when VREG is ON		70		μA	
Isvm	ISVM Current Consumption in signal verification mode 350 µA		μА			



Table 7. Electrical System Specifications

Symbol	Parameter	Min	Тур	Max	Units	Note
LCOsut	OSUT LCO Start-up Time			2	ms	Time needed by the LCO to start- up
Tsrco	TSRCO SRCO frequency after calibration		1.125	1.19	MHz	Assuming FLCO = 500 kHz
TTRCO	TRCO frequency after calibration	30.5	32.26	34.0	kHz	Assuming FLOO - 500 km2
TRCOcal	Calibration time for the RC oscillators 2 ms		The calibration of the RC oscillators starts after the LCO settles			
VRout	Voltage regulator output voltage	2.7	3.0	3.3	V	

7 Typical Operating Characteristics

Figure 3. Power-down current if Voltage Regulator is OFF over Supply Voltage (VREG)




Figure 5. Current Consumption in Listening Mode if Voltage Regulator is OFF over Supply Voltage (VREG)




Figure 7. Output Regulated Voltage (VREG) @VDD=5V over Temperature




Figure 4. Power-down Current if Voltage Regulator is OFF @3V over Temperature




Figure 6. Current Consumption in Listening Mode if Voltage Regulator is OFF over Temperature (@ VREG=3V)





Figure 8. Output Regulated Voltage (VREG) @ Room Temperature over Supply Voltage






8 - 27

8 Detailed Description

The AS3935 can detect the presence of an approaching storm with lightning activities and provide an estimation of the distance to the leading edge of the storm, where the leading edge of the storm is defined as the minimum distance from the sensor to the closest edge of the storm. The embedded hardwired distance estimation algorithm of the AS3935 issues an interrupt on the IRQ pin (see Interrupt Management on page 22) every time a lightning is detected. The estimated distance which is displayed in the distance estimation register does not represent the distance to the single lightning but the estimated distance to the leading edge of the storm. A graphical representation is shown in the Figure 9.

Figure 9. Storm



As shown in Figure 10, Figure 11, Figure 12, and Figure 13, the system integration consists mainly of the AS3935 and an external control unit (e.g. MCU) for the IC initialization and interrupt management (IRQ).

The choice of interface type (SPI vs. I²C) is accomplished using pin 9, SI (Select Interface). When the SI is connected to GND, the SPI is selected. When the SI is connected to VDD, the I²C is selected. Pins ADD0 and ADD1 are used to select among 4 different I²C address.

The internal voltage regulator can be enabled by connecting EN_VREG to VDD. If the internal regulator is not used, capacitor C3 is not needed and VREG must be connected to VDD. In this case, the AS3935 can be directly supplied by VREG and VDD (EN_VREG to GND).

AS3935 needs the following external components:

- Power supply capacitor CBAT 1µF
- Load capacitor on the ACG and VREG pins; the latter is needed only in case the voltage regulator is enabled
- One, RLC resonators for the antenna
- One resistor on the I2CL pin to VDD, if I²C is active (R2 > 10kΩ)



Figure 10. AS3935 Application Diagram (Voltage Regulator OFF, SPI Active)




Figure 11. AS3935 Application Diagram (Voltage Regulator OFF, I²C Active)






Figure 12. AS3935 Application Diagram (Voltage Regulator ON, SPI Active)





Figure 13. AS3935 Application Diagram (Voltage Regulator ON, I²C Active)





8.1 Circuit

Figure 1 shows a block diagram of the AS3935. The external antenna is directly connected to the Analog Front-end (AFE), which amplifies and demodulates the received signal. The watchdog continuously monitors the output of the AFE and alerts the integrated lightning algorithm block in the event of an incoming signal. The lightning algorithm block validates the signal by checking the incoming signal pattern, calculates the energy and then the AS3935 provides the MCU with an estimate of the distance to the head of the storm. The lightning algorithm block, processing the demodulated signal, can distinguish between lightning signal and man-made disturbers. If the received signal is classified as a man-made disturber, then the event is rejected and the system automatically goes back into listening mode to minimize current consumption. If the incoming signal identifies a lightning event, then the statistical distance estimation block performs an estimation of the distance to the head of the storm (Typical time needed 2ms).

The LC oscillator together with the calibration block can calibrate both the TRCO and the SRCO clock generator to compensate process variations.

8.2 Operating Modes

Power-down Mode.

In Power-down Mode, the entire AS3935 is switched off to reduce the current consumption to minimum (typ 1µA).

Listening Mode.

In listening mode the AFE, the watchdog, the noise floor level generation, the bias block, the TRCO, and the voltage regulator (in case it is enabled) are running. In this mode the system can push down the power consumption to a minimum (typ 60µA). In case the maximum voltage supply does not exceed 3.6V, it is possible to switch off the voltage regulator to save power.

Signal Verification.

The AS3935 enters in this mode every time the watchdog detects dynamic activity picked up by the antenna. Threshold can be set in WDTH **REG0x01[3:0]**. The IC will leave this mode either if the incoming signal is classified as disturber or if the analysis of the single event (lightning) is finished. If the received signal is classified as a disturber, then the AS3935 will automatically go back to listening mode without any needed action from outside and an interrupt will be generated (with option bit this interrupt can be masked). If the received pattern matches all requirements, the energy calculation is performed and the AS3935 provides distance estimation.

8.3 System and Block Specification

8.3.1 Register Table

Table 8. Register Table

Register #	7	6	5	4	3	2	1	0	
0x00	Rese	erved		AFE_GB PWI					
0x01	Reserved		NF_LEV	WDTH					
0x02	Reserved	CL_STAT	MIN_NU	JM_LIGH		SF	REJ		
0x03	LCO_	FDIV	MASK_DIST	Reserved		11	NT		
0x04				S_LIG_L					
0x05				S_LIG_M					
0x06		Reserved		S_LIG_MM					
0x07	Rese	erved			DISTANCE				
0x08	DISP_LCO	DISP_SRCO	DISP_TRCO	Reserved	TUN_CAP				
0x09	5)	•			•				
			l imbénio	a Detection Leal	r un Tabla				
			Lightning Detection Look-up Table						
0x32									



8.3.2 Register Table Description and Default Value

Table 9. Detailed Register Map

Address	Register Name	Bit	Туре	Default Value	Description
	Reserved	[7:6]		0	reserved
0x00	AFE_GB	[5:1]	R/W	10010	AFE Gain Boost
	PWD	[0]		0	Power-down
0x01	NF_LEV	[6:4]	R/W	010	Noise Floor Level
UXUT	WDTH	[3:0]	F/W	0001	Watchdog threshold
	Reserved	[7]		1	reserved
0x02	CL_STAT	[6]	R/W	1	Clear statistics
UXUZ	MIN_NUM_LIGH	[5:4]	R/W	00	Minimum number of lightning
	SREJ	[3:0]		0010	Spike rejection
	LCO_FDIV	[7:6]		00	Frequency division ration for antenna tuning
002	MASK_DIST	[5]	R/W	0	Mask Disturber
0x03	Reserved	[4]		0	reserved
	INT	[3:0]	R	0000	Interrupt (see Table 18)
0x04	S_LIG_L	[7:0]	R	00000000	Energy of the Single Lightning LSBYTE
0x05	S_LIG_M	[7:0]	R	00000000	Energy of the Single Lightning MSBYTE
0.00	Reserved	[7:5]			reserved
0x06	S_LIG_MM	[4:0]	R	00000	Energy of the Single Lightning MMSBYTE
007	Reserved	[7:6]			reserved
0x07	DISTANCE	[5:0]	R	000000	Distance estimation
	DISP_LCO	[7]		0	Display LCO on IRQ pin
000	DISP_SRCO	[6]	DAM	0	Display SRCO on IRQ pin
0x08	DISP_TRCO	[5]	R/W	0	Display TRCO on IRQ pin
	TUN_CAP	[3:0]		0000	Internal Tuning Capacitors (from 0 to 120pF in steps of 8pf)
0x09	LDLUT1	[7:0]	R/W	10101101	
0x0A	LDLUT2	[7:0]	R/W	00000000	
0x0B	LDLUT3	[7:0]	R/W	00100101	
0x0C	LDLUT4	[7:0]	R/W	00000011	
0x0D	LDLUT5	[7:0]	R/W	0000001	
0x0E	LDLUT6	[7:0]	R/W	00100010	
0x0F	LDLUT7	[7:0]	R/W	10000011	Lightning Detection Look-up table
0x10	LDLUT8	[7:0]	R/W	0000001	
0x11	LDLUT9	[7:0]	R/W	00011111	
0x12	LDLUT10	[7:0]	R/W	01000011	
0x13	LDLUT11	[7:0]	R/W	00000010	
0x14	LDLUT12	[7:0]	R/W	00011011	
0x15	LDLUT13	[7:0]	R/W	01100011	



Table 9. Detailed Register Map

Address	Register Name	Bit	Туре	Default Value	Description
0x16	LDLUT14	[7:0]	R/W	00000011	
0x17	LDLUT15	[7:0]	R/W	00011000	
0x18	LDLUT16	[7:0]	R/W	00010100	
0x19	LDLUT17	[7:0]	R/W	00000101	
0x1A	LDLUT18	[7:0]	R/W	00010100	
0x1B	LDLUT19	[7:0]	R/W	10011101	
0x1C	LDLUT20	[7:0]	R/W	00000111	
0x1D	LDLUT21	[7:0]	R/W	00010001	
0x1E	LDLUT22	[7:0]	R/W	01101010	
0x1F	LDLUT23	[7:0]	R/W	00001011	
0x20	LDLUT24	[7:0]	R/W	00001110	
0x21	LDLUT25	[7:0]	R/W	00011101	
0x22	LDLUT26	[7:0]	R/W	00010001	
0x23	LDLUT27	[7:0]	R/W	00001100	
0x24	LDLUT28	[7:0]	R/W	10101011	Lightning Detection Look-up table
0x25	LDLUT29	[7:0]	R/W	00011001	
0x26	LDLUT30	[7:0]	R/W	00001010	
0x27	LDLUT31	[7:0]	R/W	01111111	
0x28	LDLUT32	[7:0]	R/W	00100110	
0x29	LDLUT33	[7:0]	R/W	00001000	
0x2A	LDLUT34	[7:0]	R/W	10111101	
0x2B	LDLUT35	[7:0]	R/W	00111001	
0x2C	LDLUT36	[7:0]	R/W	00000110	
0x2D	LDLUT37	[7:0]	R/W	10011011	
0x2E	LDLUT38	[7:0]	R/W	01010110	
0x2F	LDLUT39	[7:0]	R/W	00000101	
0x30	LDLUT40	[7:0]	R/W	11100111	
0x31	LDLUT41	[7:0]	R/W	10000001	
0x32	LDLUT42	[7:0]	R/W	0000001	



8.4 Serial Peripheral Interface (SPI)

This 4-wire standard SPI interface (Mode 1) can be used by the Microcontroller (μ C) to program the AS3935. To enable the SPI as data interface, the Select Interface (SI) has to be set to low (GND).

The maximum clock operation frequency of the SPI is 2MHz.

Note: The clock operation frequency of the SPI should NOT be identical to the resonance frequency of the antenna (500kHz), in order to minimize the on board 500kHz noise.

Table 10. Serial Data Interface (SDI) Pins

Name	Signal	Signal Level	Description
CS	Digital Input	CMOS	Chip Select (Active Low)
MOSI	Digital Input	CMOS	Serial data input from the external unit to the AS3935
MISO	Digital Output	CMOS	Serial data output from the AS3935 to the external unit
SCLK	Digital Input	CMOS	Clock for serial data read and write

Note: MISO is set to tristate if CS is high. In this way more than one device can communicate on the same MISO bus.

8.4.1 SPI Command Structure

To activate this SPI, the CS has to be set to low. A SPI command consists of two bytes serial command and the data are sampled on the falling edge of SCLK (CPHA=1). The next table shows command structure, from the MSB (B15) to LSB (B0). The command stream has to be sent to the SPI from the MSB (B15) to the LSB (B0).

MC	DDE	R	egister /	Address	/ Direct (Comman	d				Regist	er Data			
B15	B14	B13	B12	B11	B10	В9	B8	B7	В6	B5	B4	В3	B2	B1	В0

The first two bits (B15 and B14) define the operating mode. There are two modes available - Read and Write/Direct command.

Table 11. Bits B15, B14

B15	B14	Mode
0	0	WRITE / DIRECT COMMAND
0	1	READ

In case a write or read command happens, then the next 5 bits (B13 to B9) define the register address, which has to be written respectively read, as shown in the table below. The direct command is performed with a write operation (see Send Direct Command Byte on page 16).


Table 12. Bits B13 to B9

B13	B12	B11	B10	В9	B8	Read / Write Register
0	0	0	0	0	0	0x00
0	0	0	0	0	1	0x01
0	0	0	0	1	0	0x02
0	0	0	0	1	1	0x03
0	0	0	1	0	0	0x04
0	0	0	1	0	1	0x05
0	0	0	1	1	0	0x06
0	0	0	1	1	1	0x07
1	1	0	0	0	1	0x31
1	1	0	0	1	0	0x32



8.4.2 Writing of Register Data

Figure 14. SPI Page Write




8.4.3 Reading of Data from Addressable Registers (READ Mode)

Once the address has been sent via SPI, the data can be fed through the MISO pin out to the microcontroller.

A CS high toggling high-low-high has to be performed after finishing the read mode session, in order to indicate the end of the READ command and prepare the Interface to the next command control Byte.

To transfer bytes from consecutive addresses, SPI master has to keep the CS signal low and the SCLK clock has to be active as long as data need to be read.

Figure 15. SPI Read Byte





8.4.4 Send Direct Command Byte

It is possible to send direct commands by writing 0x96 in the registers REG0x3C and REG0x3D, as shown in the table below:

Table 13. Registers 0x3C, 0x3D

Direct Command	Register	Description		
PRESET_DEFAULT	0x3C	Sets all registers in default mode		
CALIB_RCO	0x3D	Calibrates automatically the internal RC Oscillators		

8.5 I2C

An I²C slave interface is implemented for read/write access to the internal registers and to send direct commands. To enable the I²C as interface, the Select Interface pin has to be set to the positive voltage supply (SI=VDD). The I2CL is the clock bus, while the I2CD is the data bus. An external pull-up resistor on the I2CL pin is needed.

The device addresses for the AS3935 in read or write mode are defined by:

0-0-0-0-a1-a0-0: write mode device address (DW)

0-0-0-0-a1-a0-1: read mode device address (DR)

Where a0 and a1 are defined by the pins 5 (ADD0) and 6 (ADD1).

Figure 16. I2C Timing Diagram




Table 14. I²C Parameters

Symbol	Parameter	Conditions	Min	Тур	Max	Units
TSP	Spike intensity		50	100		ns
THI	High Clock Time	400 kHz Clock apond	330			ns
TLO	Low Clock Time	400 kHz Clock speed	660			ns
Tsu	G,	I2CD has to change Tsetup before rising edge I2CL	30			ns
THD		No hold time needed for I2CD relative to rising edge of I2CL	-40			ns
THD;STA	Within start condition, after low going I2CD, I2CL has to stay constant for specified hold time		300			ns
TSU;STO	After high going edge of I2CL, I2CD has to stay constant for the specified setup		100			ns
TSU;STA	time before STOP or rep	peated start condition is applied	100			ns



8.5.1 I²C Byte Write

The transmission begins with a START condition (S), which consists of a high-to-low transition of the I2CD bus when I2CL is high. The START condition is followed by the Device Write mode (DW), word address (WA: register address to write into) and the register data (reg_dat). Until the stop condition (P) the word address is automatically incremented at any register data.

Figure 17. I²C Byte Write





Figure 18. I2C Page Write




Symbol	Description		
S	START condition after STOP		
Sr	Repeated START		
DW	Device Address for write		
DR	Device Address for read		
WA	Word address		
A	Acknowledge		
N	No acknowledge		
P	STOP condition		
WA++	Internal address increment		



8.5.2 I2C Register Read

To read data from the slave device, the master has to change the transfer direction. This can be done either with a repeated START condition followed by the device-read address, or simply with a new transmission START followed by the device-read address, when the bus is in IDLE state. The device-read address is always followed by the 1st register byte transmitted from the slave. In Read Mode, any number of subsequent register bytes can be read from the slave. The word address is incremented internally.

Figure 19. I2C Page Read



Random Read and Sequential Read are combined formats. The repeated START condition is used to change the direction after the data transfer from the master.

The word address transfer is initiated with a START condition issued by the master while the bus is idle. The START condition is followed by the device-write address and the word address.

In order to change the data direction, a repeated START condition is issued on the 1st CLK pulse after the ACKNOWLEDGE bit of the word address transfer. After the reception of the device-read address, the slave becomes the transmitter. In this state, the slave transmits register data located by the previous received word address vector. The master responds to the data byte with a NOT ACKNOWLEDGE, and issues a STOP condition on the bus.

In contrast to the Random Read, in a sequential read the transferred register-data bytes are responded by an acknowledge from the master. The number of data bytes transferred in one sequence is unlimited (consider the behavior of the word-address counter). To terminate the transmission, the master has to send a NOT ACKNOWLEDGE following the last data byte and subsequently generate the STOP condition.

8.5.3 Direct Command

It is possible to send direct commands writing 0x96 in the registers REG0x3C and REG0x3D, as shown in the table below:

Direct Command	Register
PRESET_DEFAULT	0x3C
CALIB_RCO	0x3D

8.6 Voltage Regulator

The AS3935 can be either supplied by a voltage regulator or directly.

If the voltage regulator is used, an additional current consumption (around $5\mu A$) will have to be considered. In this case the pin EN_VREG must be connected to VDD and the AS3935 is supplied by the pin VDD, while the regulated voltage is at the pin VREG (output of the voltage regulator). In order to fulfil the stability requirements of the voltage regulator a capacitance greater than $1\mu F$ on the pin VREG to ground is needed. The nominal output regulated voltage is 3V.

If the voltage regulator is not used, the pin EN_VREG must be connected to ground and the pins VDD and VREG must be connected together to the supply voltage (e.g. battery).



8.7 Analog Front-end (AFE) and Watchdog

The AFE amplifies and demodulates the AC-signal picked up by the antenna. Since the AS3935 is a lightning sensor based on narrowband receiving technique (center frequency of 500kHz and a bandwidth of about 33kHz), the AFE bandwidth is meant to be greater than the antenna bandwidth. In this way, it is possible to consider that the gain within the antenna bandwidth as constant.

The gain of the AFE by default is optimized to operate indoor (e.g. inside a building). If the AS3935 operates outdoor, then the AFE gain setting has to be set to a lower value, as shown in the Table 15. Indoor and Outdoor setting must be selected according to the type of the application.


Table 15. AFE Setting, Outdoor vs. Indoor

AFE Setting	REG0x00[5:1]
Indoor	10010
Outdoor	01110

The output signal of the AFE is monitored by the watchdog, which enables the signal validation (see Signal Verification on page 11) in case the input signal crosses a certain threshold. The AS3935 is automatically set back to Listening Mode once the Signal Validation block has made an assessment on the nature of the received signal (lighting or disturber). With register **REG0x01[3:0]** it is possible to change the level of this threshold to increase the robustness to disturbers. If higher thresholds are used, the AS3935 would loose sensitivity for very far lightning events, with an improvement of the man-made disturber rejection as benefit.

Figure 20 shows the degradation of the detection efficiency (sensitivity of lightning detection) over the distance for different threshold settings.

Figure 20. Detection Efficiencies vs. Distance for Different Settings for WDTH, if SREJ=0000





8.8 Noise Floor Generator and Evaluation

The output signal of the AFE is also used to generate the noise floor level. The noise floor is continuously compared to a reference voltage (noise threshold). Whenever the noise floor level crosses the noise threshold, the AS3935 issues an interrupt (INT_NH) to inform the external unit (e.g. MCU) that the AS3935 cannot operate properly due to the high input noise received by the antenna (e.g. blocker). It is possible to set the threshold for the noise floor limit with the bits **REG0x01[6:4]**, as defined in the table below.

Table 16. Settings for the Noise Floor Threshold

Continuous Input Noise Level [µVrms] (outdoor)	Continuous Input Noise Level [µVrms] (indoor)	REG0x01[6]	REG0x01[5]	REG0x01[4]
390	28	0	0	0
630	45	0	0	1
860	62	0	1	0
1100	78	0	1	1
1140	95	1	0	0
1570	112	1	0	1
1800	130	1	1	0
2000	146	1	1	1

INT_NH is displayed as long as the input noise level (blocker) is higher than the noise floor threshold. By default the setting **REG0x01[6:4]** =010 is used.

8.9 Lightning Algorithm

The lightning algorithm consists of hardwired logic. False events (man-made disturbers) which might trigger the AS3935 are rejected, while lightning events initiate calculations to estimate the distance to the head of the storm.

The Lightning algorithm is broken up into three sub blocks:

- 1. Signal validation: Verification that the incoming signal can be classified as lightning.
- 2. Energy calculation: Calculation of the energy of the single event.
- 3. Statistical distance estimation: According to the number of stored events (lightning), a distance estimate is calculated.

If the signal validation fails (the incoming signal does not have the characteristics of lightning), the energy calculation and statistical distance estimation do not happen and the event is classified as disturber.

8.9.1 Signal Validation

The watchdog enables the lightning algorithm block in the event any activities are detected at the antenna. As this happens the output signal of the AFE is evaluated by the Signal Validation block, which checks the pattern of the received signal. The signal validation checks the shape of the received signal. In particular, the AS3935 can reject the impulse signals, like spikes, picked up by the antenna. The AS3935 has the ability to improve the spike rejection with the register **REG0x02[3:0]**. By default, register **REG0x02[3:0]** =0010. Larger values in **REG0x02[3:0]** correspond to more robust disturber rejection, with a decrease of the detection efficiency, as shown in the Figure 21.



60% **SREJ** 0000 < Detection Efficiency [%] 0001 40% 0010 0011 0100 0101 0110 0111 1000 1001 1010 20% 1011 0 20 30 40 Radius [km]

Figure 21. Detection Efficiencies vs. Distance for Different Setting of SREJ, if WDTH=0001

At the end of the signal verification, the AS3935 automatically returns to listening mode.

8.9.2 Energy Calculation

If the received signal is classified as lightning, the energy is calculated. The result of the energy calculation is then stored in the registers **REG0x06[4:0]**, **REG0x05[7:0]** and **REG0x04[7:0]**. This value is just a pure number and has no physical meaning.

8.9.3 Statistical Distance Estimation

The AS3935 generates an assessment of the estimated distance to the head of an approaching storm. This assessment is done based on statistical calculation. The energy of the single event (lightning) provided by the Energy Calculation block is stored in an internal memory, together with timing information, in the AS3935. The events stored in the memory are then correlated with a look-up table by the statistical distance estimation block, which provides a final estimation of the distance to the head of the storm. The algorithm automatically deletes events, which are older than a certain time. R7=0x01 means that the storm is right overhead, while R7=0x3F is displayed when the storm is out of range. This algorithm is hardwired and not accessible from outside.

The estimated distance is directly represented in km in the register **REG0x07[5:0]** (binary encoded). The distance estimation can change also if no new event triggers the AS3935, as older events can be purged.

Table 17. Distance Estimation

REG0x07[5:0]	Distance [km]
111111	Out of range
101000	40
100101	37
100010	34



Table 17. Distance Estimation

REG0x07[5:0]	Distance [km]
011111	31
011011	27
011000	24
010100	20
010001	17
001110	14
001100	12
001010	10
001000	8
000110	6
000101	5
000001	Storm is Overhead

The calculated energy is stored in registers REG0x04[7:0], REG0x05[7:0] and REG0x06[4:0].

8.9.4 Interrupt Management

Whenever events happen, the AS3935 pulls the IRQ high and displays the interrupt in the REG0x03[3:0]. Table 18 shows the interrupt register.

Table 18. Interrupts

Interrupt Name	REG0x03[3:0]	Description
INT_NH	0001	Noise level too high
INT_D	0100	Disturber detected
INT_L	1000	Lightning interrupt

The INT_NH is issued if the received noise exceeds the maximum acceptable noise. INT_NH persists until the noise is again back to low.

In case the signal validation block assesses the received signal as disturber, the INT_D is displayed. It is possible to mask the disturber interrupts INT_D with MASK_DIST (**REG0x03[5]** =1).

If the MASK_DIST option is enabled, the signal on the pin IRQ never goes high if a disturber is detected.

The interrupt bus IRQ is set back to low whenever the interrupt register is read out.

The AS3935 issues a lightning interrupt (INT_L) if a new event is detected. All new events are stored in the internal memory and build up a lightning statistic used by the distance estimation algorithm. If the AS3935 issues an interrupt and the Interrupt register is **REG0x03[3:0]** =000 the distance estimation has changed due to purging of old events in the statistics, based on the lightning distance estimation algorithm.

Whenever an interrupt is issued, the external unit should wait 2ms before reading the Interrupt register.

In addition, it is possible to allow the AS3935 to issue lightning interrupts only if a minimum number of events (lightning) have been detected in the last 15 minutes. The minimum number of lightning events can be set with register **REG0x02[5:4]**.

Table 19. Minimum Number of Lightning Detection

Minimum Number of Lightning	REG0x02[5]	REG0x02[4]	
1	0	0	
5	0	1	
9	1	0	
16	1	1	

When this feature is utilized, a minimum number of events must occur to trigger a valid lightning event. This eliminates false triggers by manmade disturbers that may pass the validation algorithm. It is possible to clear the statistics built up by the lightning distance estimation algorithm block by just toggling the bit **REG0x02[6]** (high-low-high).



8.10 Antenna Tuning

The AS3935 uses a loop antenna based on a parallel LC resonator. The antenna has to be designed to have its resonance frequency at 500kHz and a quality factor of around 15. With a register setting it is possible to display on the IRQ pin the resonance frequency of the antenna as a digital signal with the register **REG0x08[7]** =1. The external unit can measure this frequency and tune the antenna adding or removing the internal capacitors with the register **REG0x08[3:0]**. It is necessary to tune the antenna with an accuracy of ±3.5% to optimize the performance of the signal validation and distance estimation. The resonance frequency is internally divided by a factor, which is programmable with the register **REG0x03[7:6]**. Table 20 shows the division ratio.

Table 20. Frequency Division Ratio for the Antenna Tuning

Division Ratio	REG0x03[7]	REG0x03[6]
16	0	0
32	0	1
64	1	0
128	1	1

8.11 Clock Generation

The clock generation is based on two different RC oscillators: a system RCO (SRCO) and a timer RCO (TRCO). The SRCO will run at about 1.1MHz and provides the main clock for the whole digital part. The TRCO is a low power low frequency oscillator and runs at 32.768 kHz. Frequency variations in these two oscillators, due to temperature change, are automatically compensated.

The output frequency of those oscillators can be displayed on the IRQ pin with register setting (**REG0x08[5]** =1 TRCO, while **REG0x08[6]** =1 SRCO). Due to process variations, the frequency of both oscillators can be different from the nominal frequency. Therefore, it is possible to calibrate both with a direct command. The precision of the calibration will depend on the accuracy of the resonance frequency of the antenna. It is recommended to first trim the receiver antenna before the calibration of both oscillators is done.

The result of calibration of the 3 oscillators is stored in a volatile memory and needs to be done every time after POR (e.g. battery change) but all oscillators are internally compensated in temperature and voltage supply variations.

If the AS3935 is set in power-down mode, the TRCO needs to be recalibrated using the following procedure:


- 1. Send Direct command CALIB_RCO
- 2. Modify REG0x08[5] = 1
- 3. Wait 2ms
- 4. Modify REG0x08[5] = 0



9 Package Drawings and Markings

The device is available in a 16LD MLPQ (4x4mm) package.

Figure 22. Drawings and Dimensions



(DATUM A)—	D2	→ fff@ C A B
	13	16
+ fff@ C A B	UUU	PIN 1# I.D
12		
E2 (
	ľ	141
<u> </u> /9	9	4 \ (5.4.7)(14.5)
SEE DETAIL B		(DATUM B)
	8	5
NX L		-NX b b bbb CAB

Notes:

- 1. Dimensions & tolerancing conform to ASME Y14.5M-1994.
- 2. All dimensions are in millimeters. Angles are in degrees.
- 3. Coplanarity applies to the exposed heat slug as well as the terminal.
- 4. Radius on terminal is optional.
- 5. N is the total number of terminals.

Symbol	Min	Nom	Max	
Α	0.70	0.75	0.80	
A1	0	0.02	0.05	
A3		0.20 REF		
L	0.30	0.40	0.50	
b	0.25	0.30	0.35	
D	4.00 BSC			
Е	4.00 BSC			
е	0.65 BSC			
D2	2.55 2.70 2.8			
E2	2.55 2.70		2.80	
aaa	-	0.15	-	
bbb	-	0.10	-	
CCC	- 0.10		-	
ddd	- 0.05 -			
eee	-	0.08	-	
fff		0.10	-	
N	16			

Marking: YYWWQZZ.

YY	ww	Q	ZZ	@
Year	Manufacturing Week	Plant identification letter	Traceability code	Sublot identifier



Revision History

Revision	Date	Owner	Description
1.0	30 Apr, 2012	rlo.	Initial release
1.1	14 May, 2012	rlc	Corrected error in marking code
1.2	10 Jul, 2012	jpe / msc	Updated info for exposed pad in Table 1, current consumption in Table 7, Section 8.1, Section 8.2, Figure 19, Section 8.7, dimensions info in Section 9.

Note: Typos may not be explicitly mentioned under revision history.



10 Ordering Information

Table 21. Ordering Information

Ordering Code	Package Type	Marking	Delivery Form	Quantity
AS3935-BQFT	MLPQ 4x4 16LD	AS3935	7 inches Tape & Reel	1000 pcs

Note: All products are RoHS compliant and austriamicrosystems green.

Buy our products or get free samples online at ICdirect: http://www.austriamicrosystems.com/ICdirect

Technical Support is available at http://www.austriamicrosystems.com/Technical-Support

For further information and requests, please contact us mailto: sales@austriamicrosystems.com or find your local distributor at http://www.austriamicrosystems.com/distributor



Copyrights

Copyright © 1997-2012, austriamicrosystems AG, Tobelbaderstrasse 30, 8141 Unterpremstaetten, Austria-Europe. Trademarks Registered ®. All rights reserved. The material herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner.

All products and companies mentioned are trademarks or registered trademarks of their respective companies.

Disclaimer

Devices sold by austriamicrosystems AG are covered by the warranty and patent indemnification provisions appearing in its Term of Sale. austriamicrosystems AG makes no warranty, express, statutory, implied, or by description regarding the information set forth herein or regarding the freedom of the described devices from patent infringement. austriamicrosystems AG reserves the right to change specifications and prices at any time and without notice. Therefore, prior to designing this product into a system, it is necessary to check with austriamicrosystems AG for current information. This product is intended for use in normal commercial applications. Applications requiring extended temperature range, unusual environmental requirements, or high reliability applications, such as military, medical life-support or life-sustaining equipment are specifically not recommended without additional processing by austriamicrosystems AG for each application. For shipments of less than 100 parts the manufacturing flow might show deviations from the standard production flow, such as test flow or test location.

The information furnished here by austriamicrosystems AG is believed to be correct and accurate. However, austriamicrosystems AG shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interruption of business or indirect, special, incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data herein. No obligation or liability to recipient or any third party shall arise or flow out of austriamicrosystems AG rendering of technical or other services.

This product is intended to be used as an early warning indicator for lightning related storms. It does not guarantee accuracy or predict exact strike locations. By using the part, the user shall be aware that s/he cannot just rely on the indication in order to prevent accidents caused by lightning strikes. austriamicrosystems explicitly states that the user must follow the generally known and recommended instructions on how to behave in the event of lightning strikes. In no event shall austriamicrosystems or its suppliers be liable for any direct, indirect, incidental, special, exemplary or consequential damages (including, but not limited to procurement of substitute goods or services, loss of use, data or profits, or business interruption) arising out of user's disregard to such warnings and instructions.



Contact Information

Headquarters

austriamicrosystems AG Tobelbaderstrasse 30 A-8141 Unterpremstaetten, Austria

Tel: +43 (0) 3136 500 0 Fax: +43 (0) 3136 525 01

For Sales Offices, Distributors and Representatives, please visit:

http://www.austriamicrosystems.com/contact