



Scanned By Camera Scanner




Scanned By Camera Scanner




Scanned By Camera Scanner







Scanned By Camera Scanner



Scanned By Camera Scanner




Scanned By Camera Scanner



Scanned By Camera Scanner

memory e) Flash Deard - A flash memory cond is a small storage device that uses non-volatile senticonduction memory to stone data on partable/ memote computing devices. It includes text, pictures, audio & Video. =) Flash momory-It is a long-life & non-volatile Storage thip that is widely used in embedded systems. It Can keep Storred data & information even when the Power is off. It can be electrically enased & Teprogrammed. Flash memory was developed from EEpRom (electronically erasable programmable read only memory). 2) Synchronous & Random Access memory: operations of Spritm are Controlled by a clock signal. REF


Scanned By Camera Scanner



Scanned By Camera Scanner

Cache memory in - Locality of Reference; The references to memory at any given time interval hand to be confined within a located ATMUS: The area contains a set of Info & the membership changes gradually as time goes by. -> Temporal Locality: -The Info which will be used in near future, is likely to be in the already -) Spatial Locality: If a word is accessed, additiont words one likely accessed soon. Act of the standards a Gacher The Property of Locality of Reference makes the the new Cache memory Systems work. - Cache is a fast small capacity memory that Can be Should hold those Info which one most likely Luce to be accessed. en main h of cta his =) periformance of cache; All the memory accesses one directed Se of memory Access ome? y


Scanned By Camera Scanner




Scanned By Camera Scanner

Associative mapping: anopping function - Specification of convergendence blue main memory blocks & Eache blocks. or Any black location in cache can stone any black in memory -> most flexible. b) mapping Table is implemented in an associative memory - ) Fast, very Expensive. c) mapping Talkble -> stones both admesses & the Content of the memory word. address (15 bits) Argument orgister K- Address \_ de Data > 0 000 Content memory


Scanned By Camera Scanner



Scanned By Camera Scanner




Scanned By Camera Scanner



Scanned By Camera Scanner

	Sem  Sem  Dit  Both	en to electronic cincuitry built wir sconductors. Explace hand disk drives (HDPs). as Internal & External Second	
to in	pile copy/ write speed pover draw/ battery life Storage capacity	Less power draw, overages 2-3 watts, And spesulting in 30+	aptop 1 HD 120 mbps  orre power transporterings verrages 6-twatts, therefore was more battery.  Typically around Soogh & 2TB move for notabook Size drives; 4TB max for desktops.
	ast	= \$0.50 pen 613 fests a 1-TB Drive.	for a 4-TB drive


Scanned By Camera Scanner




Scanned By Camera Scanner

xunite though protocol, cache bleks uplated, words her gog har pratoral early approved -> to treduce 2 st-associative mayping processor waiting mosts through .. 3) Shiplest & most commonly used procedure is to whate main memory & every memory write goration. -) eache memory being updated in parallel, if it Contains the world at the specified address, i.e. write through adhesis, -) Holentage: - main memory always contain the some data as the tache. -) This characteristic is important in systems with the direct memory occess, transfers. -3+ ; Data residing in main money are wild at all times so that on the device communicating through and waild encience the most melant updated dita. =) write-back/lopy-back:--) The god procedure is called the write-back method. -) In this method, only the cache location is updated during a write operation. fly So, that laten when


Scanned By Camera Scanner



Scanned By Camera Scanner



Scanned By Camera Scanner



Scanned By Camera Scanner