
Run 152115 | emergency setting 80 cu
Run 155015 | emergency setting 20 cu
All modes
IDM straight
Spacing flag
Sensor flag
Logged bumper gap (cu)
Sent speed command (record units)
Time from run start (s)
0
200
400
600
800
1000
20
40
60
80
100
120
140