Overshot

SERIES 150 RELEASING AND CIRCULATING OVERSHOT

FISHING

GENERAL DESCRIPTION

EXTERNAL-CATCH FISHING TOOL THAT ENGAGES, PACKS OFF AND PULLS TWISTED-OFF OR LOST TUBING, DRILL PIPE, COUPLINGS, TOOL JOINTS, CASING AND OTHER SMOOTH-O.D. FISH. A SPIRAL OR BASKET GRAPPLE GRIPS THE FISH OVER A LONG SECTION, SO HEAVY PULLING, TORSION AND JARRING LOADS ARE TAKEN WITHOUT DAMAGING THE TOOL OR THE FISH. ENGAGING AND RELEASING BOTH USE RIGHT-HAND ROTATION ONLY.

FULL STRENGTH SIZES


Overshot O.D.	Max. catch, spiral	Max. catch, basket	Type	Wt (lb)*
3-5/8	2-1/2	2	FS	55
4-1/8	3-1/8	2-5/8	FS	70
5-9/16	4-1/4	3-11/16	FS	130
5-5/8	4-5/8	4-1/8	FS	130
5-3/4	4-3/4	4-1/4	FS	138
7-7/8	6-1/4	5-1/2	FS	261
8-1/8	6-1/2	5-3/4	FS	274
8-1/4	6-5/8	5-7/8	FS	280
9-5/8	8	7-1/4	FS	337
10-1/8	8-1/2	7-3/4	FS	358
10-5/8	9	8-1/4	FS	401
11-1/4	9-5/8	8-7/8	FS	520
11-3/4	10-1/8	9-3/8	FS	642

* Assembly dressed with spiral parts. Inches. FS = full strength. Slim-hole and semi full strength types also exist; undersize parts fit smaller fish.

WIDE CATCH VERSION

Tool O.D.	Catch range	Max. catch, spiral	Max. catch, basket	Load, spiral (lb)
4-11/16	1/4	3-21/32	3-1/16	332,100
5-3/4	5/16	4-3/4	4-1/8	407,100
7-3/8	3/16	6-1/2	5-7/8	435,200
8-1/8	5/16	7	6-1/4	548,900
9-1/8	5/16	8	7-1/4	548,900
11-3/4	1/2	10-1/8	9	969,000

Same design with an extended catch range, up to four times that of a standard overshot, to reach heavily worn fish. Standard or high-pressure seals, full flow through the fish, coarse top-sub threads with set screws, 18 in. fish neck. Can cut grapple inventory by up to 75%.



DESIGN FEATURES

- **Spiral or basket grapple:** spiral for fish near maximum catch size, basket for smaller fish.
- **Pack-off:** sleeve packer with spiral grapple; double-lip mill control packer (field-replaceable seals) with basket grapple.
- **Circulation** through the fish to help free it.
- **Right-hand only:** no left-hand rotation to engage or release.
- **Accessories:** oversize, wall hook and mill guides, extension subs, lock rings; coarse-thread version for easier assembly.

OPERATION

- **Engage:** rotate slowly right while lowering over the fish, let the twist slack out, then pull.
- **If the fish stays:** start the pumps and keep an upward strain.
- **Release:** bump down, then rotate right while slowly raising.
- **Precautions:** stop the pumps before lowering over the fish; bump full string weight before releasing; no left-hand rotation without upward strain.

HOW TO ORDER

Please specify: 1. tool name and assembly number 2. size and type of fish 3. top connection 4. O.D. if other than standard. Spares (spiral): 3 packers, 2 grapples per size, 1 control. Spares (basket): 2 grapples, mill control packers per size.