RCJB

REVERSE CIRCULATION JUNK BASKET

FISHING

GENERAL DESCRIPTION

JUNK BASKET THAT USES REVERSE CIRCULATION TO RECOVER SMALL JUNK THAT OTHER BASKETS WOULD MISS. FLUID IS JETTED OUT AND DOWN AGAINST THE FULL CIRCUMFERENCE OF THE HOLE, SWEEPS LOOSE OBJECTS TOWARD THE CENTRE AND RETURNS UP THROUGH THE BARREL AND OUT OF PORTS AT ITS UPPER END. A DRAIN THROUGH THE TOOL PREVENTS PULLING A WET STRING EVEN IF THE INNER BARREL IS PLUGGED BY CORE. IT RECOVERS BIT CONES AND BEARINGS, BROKEN SLIPS, WIRELINE, HAND TOOLS, MILLING CUTTINGS AND DEBRIS, AND CAN BE CONVERTED INTO A FISHING MAGNET.

TECHNICAL CHARACTERISTICS


STANDARD TYPE (popular bit cone sizes)

Hole size	Barrel OD	Max. fish Ø	Top conn.	Teeth	Wt (lb)
3-3/4 - 4	3-5/8	2-1/4	2-3/8	6	85
4-1/8 - 4-1/2	4	2-1/2	2-3/8	6	98
4-5/8 - 5	4-1/2	3-1/16	2-7/8	8	108
5-1/8 - 5-1/2	4-7/8	3-9/16	2-7/8	8	128
5-5/8 - 6	5-1/8	3-3/4	3-1/2	8	142
6-1/8 - 6-1/2	5-3/4	4-3/8	3-1/2	8	185
6-5/8 - 7-3/8	6-1/4	4-3/4	4-1/2	8	238
7-1/2 - 8-1/4	7	5-1/8	4-1/2	8	293
8-3/8 - 9-1/2	7-7/8	6-1/16	5-1/2	8	374
9-5/8 - 10-5/8	9-1/8	7-1/16	6-5/8	10	441
10-3/4 - 11-5/8	10-1/8	7-5/8	6-5/8	10	576
11-3/4 - 12-1/2	11	8-5/16	6-5/8	12	665
12-5/8 - 13-5/8	11-7/8	8-1/2	6-5/8	12	797
13-3/4 - 16	13	9-13/16	6-5/8	14	932
16 - 17-1/2	15	11	6-5/8	16	1,563

W7R TYPE (W7R and other oversize cones)

Hole size	Barrel OD	Max. fish Ø	Top conn.	Teeth	Wt (lb)
3-3/4 - 4-1/8	3-5/8	2-3/4	2-3/8	6	78
4-1/4 - 4-1/2	4-1/8	3	2-3/8	6	85
4-5/8 - 5	4-1/2	3-3/8	2-3/8	8	95
5-1/8 - 5-1/2	4-7/8	3-5/8	2-7/8	8	108
5-5/8 - 6	5-3/8	4-1/16	2-7/8	8	141
6-1/8 - 7	5-7/8	4-5/8	3-1/2	8	173
7-1/8 - 7-1/2	6-3/4	5-1/4	3-1/2	8	223
7-5/8 - 8-1/2	7-5/16	5-5/8	4-1/2	8	280
8-5/8 - 9-1/2	8-3/16	6-1/2	4-1/2	10	380
9-5/8 - 10-3/8	9-1/8	7-1/8	5-1/2	10	407
10-1/2 - 11-5/8	9-7/8	7-3/4	5-1/2	10	484
11-3/4 - 13-3/8	11	8-5/8	6-5/8	12	597
13-1/2 - 15	12-3/4	9-15/16	6-5/8	14	794

Dimensions in inches, weights in lb (approximate). Hole size is the range the tool is designed for; max. fish Ø applies to the mill shoe.



DESIGN FEATURES

- **Reverse circulation:** a steel ball dropped down the string seats in the valve and sends flow through the barrel passages, out against the hole wall and back up the barrel.
- **Junk catcher:** spring-loaded fingers fold back to admit core and fish, then dig in on pulling to cut off the core.
- **Mill shoes:** type A with side wings (standard); type B hard-faced with sintered tungsten carbide; type C flat-bottomed, hard-faced, for cutting cores.
- **Finger shoe:** for loose or larger junk; fingers close beneath the fish; replaceable fingers.
- **Magnet insert:** fits the catcher recess, converts to a fishing magnet and keeps reverse circulation.

OPERATING PARAMETERS

Before dropping ball	Circulate a few minutes about 10 ft off bottom
Mill shoe	Cut a core of at least 10 in.; 1 ton on hard-faced shoes, 50 - 150 rpm
Finger shoe	Rotate slowly, lower to about 2 tons on bottom
Precaution	String tool-joint IDs must pass the steel ball; keep the ball at surface while running in

Add a junk sub above the top sub if small junk is prevalent. Wash the tool after each job, paying attention to the space between inner and outer barrels.

HOW TO ORDER

Please specify: 1. tool name and type (standard or W7R) 2. OD and type of shoe 3. top connection 4. recommended spares: 2 junk catchers, 2 mill shoes, 1 valve cup, 1 valve seat, 1 steel ball 5. accessories: 2 finger shoes, 4 finger shoe replacements, 1 magnet insert.