

connection-translation-destination-host string Defaults to "

This is the connection's translation destination host. This typically comes from the connection-orig-match-pattern. Defaults to "

connection-translation-request-user string Defaults to "

This is the connection's translation request user. This is typically set to [*]. Defaults to ""

connection-translation-destination-user string Defaults to "

This is the connection's translation destination user. This is typically set to [*]. Defaults to ""

connection-translation-source-user string Defaults to "

This is the connection's translation source user. This is typically set to [*]. Defaults to ""

connection-source-ip-checking-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes no

connection-include-server-header-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes no

connection-relay-comfort-noise-enabled string Defaults to system-default

This will set whether there is an RTP Relay comfort noise. Can be set to yes or no. If not set will be set to system-default

connection-pcmu-only-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes no

connection-enforce-minimum-duration-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes n

connection-bind-to-alternate-interface-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes n

connection-block-video-in-sdp-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

ves no

connection-sip-get-new-dialog-destination-from string Defaults to default-ip

This will set the new dialog destination. Values available are contact-header or via-header. Default would be default-ip

connection-sip-get-response-destination-from string Defaults to default-ip

This will set the response desination. Values available will be contact-header or via-header. Default will be default-ip

connection-require-encrypted-audio-enabled string Defaults to no

This will set whether audio encryption is required. Options availabe are "optional" and "yes". Defaults to no

connection-sip-transport-protocol string Defaults to UDP

This will set the SIP transport protocol. Options are "TCP and "TLS". Default will be UDP

connection-check-orig-matching-sip-header string Defaults to from

This will set whether to check whether the origination matches the SIP header. Options are "to", "request", or "contact". Default will default to "from"

$\textbf{connection-sip-session-timer-enabled} \ \ \textbf{string} \quad \textbf{Defaults to system-default}$

This will set the SIP session timer. Options are setting to "no" or not setting at all, which will default to the system-default

connection-prevent-rtp-port-change-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes n

connection-hide-post-dial-delay-with-ringback-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes n

connection-remote-ringback-handling string Defaults to allowed

This will set the remote ringback handling. Options are "no-ringback" and "local-only". Default will be set to "allowed".

connection-block-media-in-sip-180-ringing string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

yes no

connection-allow-mid-call-uri-updates-enabled string enum Defaults to no

This setting when enable will request caller id blocking on outbound calls requesting privacy settings. This may lower the ability to connect certain calls if not setup properly to support privacy settings.

