PROCESS CELL: PC_ANT_BAKE — ANT Baking Oven Process Cell (EU / Antwerp)

EQUIPMENT LIST — PC_ANT_BAKE

EXT ID	NAME	TYPE	MANUFACTURER	PARENT EM

BAKING ZONE — OVEN 1

EQ_AUX_010 — Temp Sensor 10 [RTD / Pilz]

EQ_AUX_024 — Temp Sensor 24 [RTD / Pilz]

TT 011 — TEMP_DEGC

TDT 012 — ZONE_DELTA_DEGC

FT 013 — AIRFLOW_M3H

HT 014 — HUMIDITY_PCT

TT 010 — EXHAUST_TEMP_DEGC

FUEL GAS

EXHAUST

COMB. AIR

EQ_ANT_014

ANT Oven 1

(Tunnel Oven)

OS 030 — OPERATING_STATE

AS 031 — ALARM_STATE

Mfr: GEA

FROM PC_ANT_FORM

(FORMED DOUGH)

DOUGH TRANSFER BELT

PT 015 — PRESSURE_BAR

BT 016 — BURNER_LOAD_PCT

ST 017 — SPEED_MPM

IT 018 — MOTOR_CURRENT_A

VT 019 — VIBRATION_MM_S

PLC CABINET — UNIT_ANT_BAKE / EM_ANT_BAKE

CM_COOKIE_033 — Oven Zone — Ctrl 5 — *[Interlock]* — PLC-01/DB1232

CM_COOKIE_034 — Oven Burner — Mgmt 5 — *[MotorCtrl]* — PLC-02/DB1233

CM_COOKIE_041 — Oven Zone — Ctrl 6 — *[Safety]* — PLC-09/DB1240

BAKING ZONE — OVEN 2

EQ_AUX_038 — Temp Sensor 38 [RTD / SEW]

EQ_AUX_052 — Temp Sensor 52 [RTD / Omron]

TT 021 — TEMP_DEGC

TDT 022 — ZONE_DELTA_DEGC

FT 023 — AIRFLOW_M3H

HT 024 — HUMIDITY_PCT

TT 020 — EXHAUST_TEMP_DEGC

FUEL GAS

EXHAUST

COMB. AIR

EQ_ANT_015

ANT Oven 2

(Tunnel Oven)

OS 030 — OPERATING_STATE

AS 031 — ALARM_STATE

Mfr: ABB

TO PC_ANT_COOL

(BAKED PRODUCT)

PT 025 — PRESSURE_BAR

BT 026 — BURNER_LOAD_PCT

ST 027 — SPEED_MPM

IT 028 — MOTOR_CURRENT_A

VT 029 — VIBRATION_MM_S

PLC CABINET — UNIT_ANT_BAKE / EM_ANT_BAKE

CM_COOKIE_042 — Oven Burner — Mgmt 6 — *[BatchCtrl]* — PLC-10/DB1241

CM_COOKIE_049 — Oven Zone — Ctrl 7 — *[PID]* — PLC-01/DB1248

CM_COOKIE_050 — Oven Burner — Mgmt 7 — *[Sequence]* — PLC-02/DB1249

NOTES:

1. All instrument tags reference ISATimeSeries external IDs (isString = false / numeric).
2. CMs CM_COOKIE_033/034/041/042/049/050 assigned to EM_ANT_BAKE (3 module sets × 2 CMs).
3. EQ_ANT_014 (Oven 1, GEA) and EQ_ANT_015 (Oven 2, ABB) run in series.
4. VT = Vibration Transmitter (mm/s) — ANT-specific bearing/gearbox health monitoring.
5. State encoding: 0=STOPPED 1=RUNNING 2=IDLE 3=STARTUP 4=ALARM 5=MAINTENANCE.
6. Hierarchy: PC_ANT_BAKE → UNIT_ANT_BAKE → EM_ANT_BAKE (EU / Antwerp site).

LEGEND

- TT — Temperature Transmitter
- TDT — Zone ΔTemp Transmitter
- FT — Airflow Transmitter
- PT — Pressure Transmitter
- HT — Humidity Transmitter
- BT — Burner Load Transmitter
- ST — Speed / Belt Transmitter
- IT — Motor Current Indicator
- VT — Vibration Transmitter
- OS — Operating State
- AS — Alarm State