



SPARE PARTS CATALOG FOR RT100 ROUGH TERRAIN CRANE

December, 2013 Edition: 1

To Users

We appreciate your choice of our machine for your application. We will try our best to provide you with thoughtful and quality service.

This catalog introduces the structural and assembling features of spare parts.

Carefully reading and understanding of the material presented in this catalog will save your repair and ordering time.

For your better use of this spare parts catalog, the following symbols are meant to:

SYMBOL	REMARKS
▲	Optional 1
△	Optional 2
▼	Optional 3
▽	Optional 4
●	Optional
H	Used in high-temperature region
L	Used in low-temperature region
A	Exchangeable
B	Displaceable
C	Non-removable
D	Removable
E	The part not directed in the drawing
F	Unsellable part

Declaration

Our products and technical documents are subject to technical improvements and changes without notice. Therefore, please acquaint yourself with our updated technology information.

CONTENTS

CHAPTER I CRANE

1.1 RT100 Rough terrain crane D00755910000010000Y.....	1-2
--	-----

CHAPTER 2 BOOM SYSTEM

2.1 Basic boom assy. D00756308500000000Y.....	2-2
2.2 Telescopic section 1 assy. D00756308600000000Y.....	2-4
2.3 Telescopic section 2 assy. D00756308700000000Y.....	2-6
2.3.1 Pulley assy. D00755908600400000Y.....	2-8
2.4 Telescopic section 3 assy. D00756308800000000Y	2-10
2.4.1 Pulley assy. D00755908700400000Y	2-14
2.5 Telescopic section 4 assy. D00756308900000000ZY	2-16
2.5.1 Pulley assy. D00756308900600000Y.....	2-20
2.6 Rooster sheave D00756301200000000Y	2-22
2.6.1 Pulley assy. D00756308900600000Y	2-24
2.7 Rooster sheave installation D00756304700800000Y.....	2-26
2.8 Main boom assy. D00755900230000000Y	2-28
2.8.1 Rope guide assy. D00756300100600000Y.....	2-32
2.9 Main boom installation D00756304700200001Y.....	2-34
2.10 Jib D00756300200000000Y.....	2-36
2.10.1 Pulley assy. D00755900202000000Y.....	2-40
2.10.2 Pulley assy. DD00756308900600000Y.....	2-42
2.11 Jib installation D00756304700400000Y.....	2-44
2.12 Telescoping mechanism D00756301800000000Y	2-46
2.12.1 Guide seat D00756301801000000Y	2-50
2.12.2 Roller head assy. D00756301801400000Y.....	2-52
2.12.3 Wire rope support D00756301802200000Y.....	2-54
2.13 Telescoping cylinder I D00756308400100000_6400Y.....	2-56
2.14 Telescoping cylinder II D00756308400200000_6400Y.....	2-58
2.15 Derricking cylinder installation D00756304700600000Y.....	2-60
2.16 Derricking cylinder D00756308400300000_6400Y.....	2-62
2.17 Securing device for hook D00756304300000000Y.....	2-64

2.18 Name plate (Chinese and English versions) D00756307020000000Y.....	2-66
2.19 Name plate (English version) D00756307010000000Y.....	2-72

CHAPTER 3 CHASSIS

3.1 Engine and transmission installation D00758301700000001Y.....	3-2
3.1.1 PTO operating valve system D00758301701000000Y.....	3-4
3.2 Engine attachments installation D00758301000000002Y.....	3-6
3.2.1 Air filter D1000100162_30507Y	3-10
3.3 Engine housing and its installation D00758305100000001Y.....	3-12
3.4 Fuel supply system D00758301100000001Y.....	3-14
3.5 Propeller shaft layout D00758302200000001Y.....	3-16
3.6 Front suspension D00758302900000000Y.....	3-18
3.7 Front axle D00758111720400000Y.....	3-20
3.8 Rear suspension D00758303300000000Y.....	3-36
3.8.1 Suspension cylinder D00758308401100000_6400Y.....	3-38
3.9 Rear axle D1030100816_102213Y.....	3-40
3.10 Wheel and rim D00758303100000000Y	3-54
3.11 Steering system D00758303400000000Y	3-56
3.11.1 Steering cylinder D00758308400900000_6400Y.....	3-58
3.12 Toolbox and platform assy. D00758309400000001Y	3-60
3.12.1 Toolbox D00758309400400001Y.....	3-62
3.13 Mudguard and stair installation D00758305200000002Y.....	3-64
3.14 Outrigger and its cylinder installation D00756304701000000Y.....	3-68
3.15 Horizontal cylinder D00756308400500000_6400Y.....	3-70
3.16 Vertical cylinder D00756308400700000_6400Y	3-72
3.17 Outrigger D00755901310000000Y.....	3-74

CHAPTER 4 ELECTRICAL SYSTEM

4.1 Schematic diagram - electrical system (Hirschmann) D00756306120000000Y.....	4-2
4.2 Electrical system (Hirschmann) D00756306220000000Y.....	4-38

CHAPTER 5 HYDRAULIC SYSTEM

5.1 Centre revolving joint installation D00756304810200001Y.....	5-2
5.1.1 Centre revolving joint D1140109716_6500Y	5-4

5.2 Hydraulic oil tank installation D00756304810400000Y	5-6
5.2.1 Hydraulic oil tank D00756303000000001Y.....	5-8
5.2.2 Radiator D1010400111_100026Y	5-10
5.3 Oil pump drive device D00756303910000000Y	5-12
5.4 Chassis frame valve installation D00756304810800000Y.....	5-14
5.4.1 Relief control valve block D1010302066_102440Y.....	5-32
5.4.2 Steering control valve block D1010302514_101227Y.....	5-34
5.4.3 Outrigger control valve block D1010302790_101227Y.....	5-36
5.4.4 2-wheel / 4-wheel drive changeover valve D1010302467_102440Y.....	5-38
5.4.5 Locking solenoid valve D1010302064_101227Y.....	5-40
5.5 Outrigger hydraulic lock installation D00756304811400000Y.....	5-42
5.6 Turntable valve installation D00756304811000000Y.....	5-44
5.6.1 Slewing cushion valve D1010301847_6500Y.....	5-66
5.6.2 Slewing brake valve D1010303988_6500Y.....	5-78
5.6.3 Solenoid valve block D1010303673_101227Y	5-80
5.6.4 Pilot-operated control valve block D1010302511_101227.....	5-82
5.6.5 Pilot-operated valve D1010303710_101227Y.....	5-84
5.6.6 Solenoid valve block D1010302784_101227Y	5-86
5.6.7 Electro-hydraulic directional control valve D1010302101_6500.....	5-88
5.7 Telescoping balance valve installation D00756304812000000Y.....	5-96
5.8 Derricking balance valve installation D00756114821800000Y.....	5-98
5.9 Hoisting balance valve installation D00756114821600000Y	5-100
5.10 Counterweight balance valve installation D00756114822200000Y	5-102
5.11 Cab valve installation D00756304810600000Y	5-104
5.12 Schematic diagram - hydraulic system D00756301510000000Y.....	5-109

CHAPTER 6 SLEWING SYSTEM

6.1 Slewing mechanism D00755904400000000Y.....	6-2
6.1.1 Swing reducer D1030200682_100013Y	6-4
6.2 Slewing bearing assy. D00756304500000000Y	6-6
6.3 Swing locking device D00755915900000000Y.....	6-8
6.3.1 Swing locking cylinder D00755708401000000_6400Y.....	6-10
6.4 Main winch D00756303501000000Y.....	6-12
6.5 Auxilairy winch D00756303500800000Y.....	6-14


6.6 Driver's cab assembly D0075570500000000Y.....	6-16
6.7 Driver's cab D1130000414_100037Y.....	6-18
6.8 Air conditioning D00631267600000000Y.....	6-40
6.8.1 Special A/C D1130100319_100026Y.....	6-42
6.9 Cab heater D00755907510000001Y.....	6-44
6.9.1 Heater D1200300013_102208Y.....	6-46
6.10 Counterweight handler D00756303200000001Y.....	6-48
6.10.1 Lifting cylinder D00756308401300000_6400Y.....	6-50
6.11 Rope guard bracket installation D00756304701200000Y.....	6-52



SPARE PARTS CATALOG FOR ROUGH TERRAIN CRANE

CHAPTER I CRANE




RT100 ROUGH TERRAIN CRANE
D00756300000000000Y


RT100 ROUGH TERRAIN CRANE
D00756300000000000Y

POS.	CODE	DESCRIPTION	QTY.	REMARK
	007563000000000000	RT100 rough terrain crane		
1	007563089000000000	•Telescopic boom section 4 assy.	1	
2	007563088000000000	•Telescopic boom section 3 assy.	1	
3	007563087000000000	•Telescopic boom section 2 assy.	1	
4	007563086000000000	•Telescopic boom section 1 assy.	1	
5	007563085000000000	•Basic boom assy.	1	
6	007563001000000000	•Main boom assy.	1	E
7	007563018000000000	•Telescoping mechanism	1	E
8	007563084001000000	•Telescoping cylinder I	1	E
9	007563084002000000	•Telescoping cylinder II	1	E
10	007563084003000000	•Derricking cylinder	1	
11	1991800130	•Angle indicator	1	
12	1130000414	•Driver's cab	1	
13	007557050000000000	•Driver's cab assembly	1	E
14	007563047000000000	•Structural element assembled	1	E
15	007559076000000000	•Air conditioning	1	E
16	007563082000000000	•Hoist rope	1	E
17	007563035000000001	•Hoist mechanism	1	
18	007563006000000001	•Counterweight	1	
19	007559044000000000	•Swing mechanism	2	E
20	007559159000000000	•Swing locking device	1	E
21	007563084007000000	•Vertical cylinder	4	
22	007563084005000000	•Horizontal cylinder	4	E
23	007563008000000000	•Outtrigger beam	4	
24	007559013100000000	•Outtrigger	4	
25	007563039100000000	•Oil pump drive device	1	E
26	007563045000000000	•Swing bearing installation	1	E
27	1140109716	•Centre revolving joint	1	E
28	007563030000000001	•Hydraulic oil tank	1	E
29	1090400136	•Auxiliary hook	1	E
30	1090400137	•Main hook	1	E
31	007563002000000000	•Jib	1	
32	007563012000000000	•Rooster sheave	1	
33	007563015100000000	•Schematic diagram - hydraulic system	1	E

RT100 ROUGH TERRAIN CRANE
D0075630000000000Y



RT100 ROUGH TERRAIN CRANE
D00756300000000000Y


POS.	CODE	DESCRIPTION	QTY.	REMARK
34	00756301610000000	•Pipe layout - superstructure hydraulic system	1	E
35	00756301710000000	•Pipe layout - chassis hydraulic system	1	E
36	00756304810000000	•Hydraulic element installation	1	E
37	00756303200000001	•Counterweight handler	1	
38	00755907510000001	•Cab heater	1	E
39	204060043	•Hydraulic oil	1600L	E
40	00756306210000000	•Electrical system	1	▲
41	00756306220000000	•Electrical system (Hirschmann)	1	△
42	00756306300000000	•Electrics intallation illustration	1	E
43	00756306110000000	•Schematic diagram - electrical system	1	▲
44	00756306120000000	•Schematic diagram - electrical system (Hirschmann)	1	△
45	00756304300000000	•Securing device for hook	1	E
46	00756303400000000	•Turntable and its attachments welded assy.	1	
47	00758303100000000	•Wheel and rim	4	
48	00758302300000000	•Front steer and drive axle	1	E
49	00758303400000000	•Steering system	1	E
50	00758302900000000	•Front suspension	1	E
51	00758305200000002	•Mudguard and stair installation	1	
52	00758301100000001	•Fuel supply system	1	E
53	00758309400000001	•Toolbox and platform	1	E
54	00758301700000001	•Engine and transmission installation	1	E
55	00758302200000001	•Drive shaft arrangment	1	E
56	00758302400000000	•Rear steer and drive axle	1	E
57	00758301000000002	•Engine attachments installation	1	E
58	00758305100000001	•Engine housing and its installation	1	E
59	00758303300000000	•Rear suspension	1	E
60	00758307400000000	•Chassis frame and its attachments welded ass y.	1	



SPARE PARTS CATALOG FOR ROUGH TERRAIN CRANE


CHAPTER 2 BOOM SYSTEM



**BASIC BOOM ASSY.
D00756308500000000Y**



**BASIC BOOM ASSY.
D00756308500000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756308500000000	Basic boom assy.		
1	00756308500200001	•Basic boom welded	1	
2	1050100062	•Automatic lubricating bearing	2	
3	00756308500001010	•Plate	2	
4	00756308500001020	•Pin	4	
5	1040500298	•Pin	4	
6	00756308500001030	•Slide block	2	
7	00755908700001150	•Bolt	6	
8	1040200110	•Nut	6	
9	204040017	•Molybdenum disulfide grease	3.5kg	E
10	00756308500001040	•Slide block	33	
11	00756308500001050	•Pad	2	
12	1040000094	•Bolt	14	
13	1040300054	•Washer	14	
14	00756308500001070	•Baffle	2	
15	1040000082	•Bolt	4	
16	1040300065	•Washer	4	
17	006340000056	•Baffle 120	2	
18	00756308500001100	•Pin	1	
19	00756308500001110	•Spacer sleeve	2	
20	00756308500001120	•Slide block	4	▽
21	00756308500001130	•Slide block	4	▽

**TELESCOPIC BOOM SECTION 1 ASSY.
D00756308600000000Y**


**TELESCOPIC BOOM SECTION 1 ASSY.
D00756308600000000Y**


POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756308600000000	Telescopic boom section 1 assy.		
1	00756308600200001	•Telescopic boom section 1 welded	1	
2	00756308600001010	•Side slide block	2	
3	1040100079	•Screw	8	
4	00756308600001020	•Rear slide block	2	
5	1019900312	•Oil cup	2	
6	00756308600001030	•Sheath	2	
7	204110014	•Lithium base grease	1L	E
8	00756308600001040	•Plate	2	
9	00756308600001050	•Plate	2	
10	00756308600001060	•Plate	2	E
11	00756308600001070	•Slide block	2	
12	00756308600001080	•Plate	2	
13	00756308600001090	•Pin	4	
14	1040500298	•Pin	4	
15	00756308600001100	•Slide block	2	
16	00755908700001150	•Bolt	6	
17	1040200110	•Nut	6	
18	00756308500001120	•Slide block	4	
19	204040017	•Molybdenum disulfide grease	1L	E
20	00756308500001130	•Slide block	4	
21	00756308600001120	•Pad	2	
22	00756308500001040	•Slide block	30	
23	00756308600001130	•Baffle	2	
24	1040000094	•Bolt	14	
25	1040300054	•Washer	14	
26	00756308600001110	•Slide block	2	

**TELESCOPIC BOOM SECTION 2 ASSY.
D00756308700000000Y**


**TELESCOPIC BOOM SECTION 2 ASSY.
D00756308700000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756308700000000	Telescopic boom section 2 assy.		
1	00756308700200001	•Telescopic boom section 2 welded	1	
2	00756308700001020	•Side slide block	4	
3	1040100080	•Screw	12	
4	00756308700001010	•Rear slide block	2	
5	1019900312	•Oil cup	2	
6	00756308600001030	•Sheath	2	
7	204110014	•Lithium base grease	1kg	E
8	00756308700001030	•Adjusting pad	2	
9	00756308700001040	•Adjusting pad	2	
10	00756308700001050	•Adjusting pad	2	
11	00755908600400000	•Pulley assy.	2	
12	00755908600001110	•Pin	2	
13	1040300096	•Retainer ring	2	
14	00756308600001070	•Slide block	2	
15	00756308700001060	•Plate	2	
16	00756308700001070	•Pin	4	
17	1040500298	•Pin	4	
18	00756308700001080	•Slide block	2	
19	00755908700001150	•Bolt	6	
20	1040200110	•Nut	6	
21	204040017	•Molybdenum disulfide grease	1kg	E
22	00756308500001120	•Slide block	2	▽
23	00756308500001130	•Slide block	2	▽
24	00756308700001090	•Pad	2	
25	00756308500001040	•Slide block	27	
26	00756308700001100	•Baffle	2	
27	1040000094	•Bolt	14	
28	1040300054	•Washer	14	
29	00756308600001110	•Slide block	2	


PULLEY ASSY.
D00755908600400000Y



**PULLEY ASSY.
D00755908600400000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00755908600400000	Pulley assy.		
1	00755908600401010	•Pulley	1	
2	00755908600401020	•Anti-friction bearing	2	
3	204110014	•Lithium-based Grease	1.0kg	E


TELESCOPIC BOOM SECTION 3 ASSY.
D00756308800000000Y



**TELESCOPIC BOOM SECTION 3 ASSY.
D00756308800000000Y**


POS.	CODE	DESCRIPTION	QTY.	REMARK
	007563088000000000	Telescopic boom section 3 assy.		
1	00756308800200001	•Telescopic boom section 3 welded	1	
2	00756308600001010	•Side slide block	2	
3	1040100079	•Screw	8	
4	00756308800001010	•Slide block	2	
5	1019900312	•Oil cup	2	
6	00756308600001030	•Sheath	2	
7	204110014	•Lithium-based Grease	1kg	E
8	00756308800001020	•Adjsuting plate	2	
9	00756308800001030	•Adjsuting plate	2	
10	00756308800001040	•Adjsuting plate	2	
11	00755908700400000	•Pulley assy.	2	
12	00755908700001060	•Spacer sleeve	2	
13	00755908700001070	•Pin	2	
14	1040300096	•Retainer ring	2	
15	00756308600001070	•Slide block	2	
16	00756308600001110	•Slide block	2	
17	00756308800001050	•Front lower slide block I	1	
18	00756308800001060	•Front lower slide block II	1	
19	00756308800001070	•Front lower slide block III	1	
20	204040017	•Molybdenum disulfide grease	1kg	E
21	00756308800001080	•Spacer sleeve	2	
22	00756308800001140	•Cover	2	
23	1040000189	•Bolt	8	
24	1040300067	•Washer	8	
25	00756308800001090	•Shaft	2	
26	00756308800001130	•Sheath	2	
27	00756308800001100	•Pulley	2	
28	1040200110	•Nut	6	
29	00755908700001150	•Bolt	6	
30	00756308800001170	•Slide block	2	
31	1040500298	•Pin	4	
32	00756308800001180	•Pin	4	
33	00756308800001190	•Plate	2	
34	00755908700001180	•Round slide block	2	

TELESCOPIC BOOM SECTION 3 ASSY.
D00756308800000000Y




**TELESCOPIC BOOM SECTION 3 ASSY.
D00756308800000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
35	1040100122	•Screw	2	
36	00755908700001190	•Guide block	2	
37	1040000575	•Bolt	12	
38	1040300054	•Washer	12	
39	00756308800001110	•Baffle	2	
40	00756308800001120	•Pad	2	
41	1050100063	•Automatic lubricating bearing	2	
42	1040100487	•Screw	4	
43	00756308800001150	•Front lower slide block IV	1	
44	00756308800001160	•Front lower slide block V	1	

**PULLEY ASSY.
D00755908700400000Y**


**PULLEY ASSY.
D00755908700400000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00755908700400000	Pulley assy.		
1	00755908700401010	•Pulley	1	
2	1040100036	•Screw	4	
3	00755908700401020	•Cover	1	
4	1050200010	•Deep grooved ball bearing	1	
5	204110014	•Lithium-based Grease	1kg	E

**TELESCOPIC BOOM SECTION 4 ASSY.
D0075630890000000ZY**



**TELESCOPIC BOOM SECTION 4 ASSY.
D0075630890000000ZY**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	007563089000000000	Telescopic boom section 4 assy.		
1	00756308900200000	•Telescopic boom section 4 welded	1	
2	00756308900400000	•Shaft	1	
3	0063400000056	•Baffle 120	4	
4	1040000016	•Bolt	8	
5	1040300065	•Washer	8	
6	00756308900001010	•Spacer sleeve	9	
7	00756308900600000	•Pulley assy.	9	
8	00756308900001020	•Spacer sleeve	1	
9	00756308900001030	•Spacer sleeve	1	
10	00756308900001040	•Pipe	1	
11	0063400000007	•Spring-loaded pin (D22,24,25,28)	6	
12	1040000103	•Bolt	2	
13	1040300066	•Washer	2	
14	1040300063	•Washer	2	
15	00756308900001050	•Cover plate	1	
16	00756308900001060	•Pipe	1	
17	00756308900001070	•Pipe	1	
18	00756308900001080	•Shaft	1	
19	1040100080	•Screw	2	
20	00756118800001170	•Pin 1	1	
21	00755908800001180	•Washer	1	
22	0063400000001	•Spring-loaded pin	1	
23	1090100296	•Wedge sleeve	1	
24	1090100439	•Wedge	1	
25	1990200935	•Wire rope clamp	1	
26	00756308900001090	•Slide block	2	
27	00756308900001100	•Pad	2	
28	00756308900001110	•Pad	1	
29	00756308900001120	•Pad	1	
30	1080000001	•Oil cup	2	
31	00756308900001130	•Rod	2	
32	204110014	•Lithium base grease	1	E
33	00756308600001070	•Slide block	2	
34	00756308900001140	•Wire securing stud	1	

**TELESCOPIC BOOM SECTION 4 ASSY.
D0075630890000000ZY**



**TELESCOPIC BOOM SECTION 4 ASSY.
D00756308900000000ZY**

POS.	CODE	DESCRIPTION	QTY.	REMARK
35	1040200110	•Nut	1	

**PULLEY ASSY.
D00756308900600000Y**


**PULLEY ASSY.
D00756308900600000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756308900600000	Pulley assy.		
1	00756308900601010	•Pulley	1	
2	1040300009	•Retainer ring	1	
3	00756308900601020	•Spacer sleeve	1	
4	1050200731	•Anti-friction bearing	2	
5	204110014	•Lithium-based Grease	1kg	E

**ROOSTER SHEAVE
D00756301200000000Y**


**ROOSTER SHEAVE
D00756301200000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756301200000000	Rooster sheave		
1	006340000032	•Spring-loaded pin	2	
2	00755701200001010	•Pin	1	
3	00756301200001010	•Baffle	1	
4	1040000069	•Bolt	4	
5	1040300041	•Washer	4	
6	1040300054	•Washer	4	
7	00756301200001020	•Shaft	1	
8	00756301200200000	•Rooster sheave bracket	1	
9	00756308900600000	•Pulley assy.	1	
10	00756301200001030	•Spacer sleeve	2	

**PULLEY ASSY.
D00756308900600000Y**

**PULLEY ASSY.
D00756308900600000Y**


POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756308900600000	Pulley assy.		
1	00756308900601010	•Pulley	1	
2	1040300009	•Retainer ring	1	
3	00756308900601020	•Spacer sleeve	1	
4	1050200731	•Anti-friction bearing	2	
5	204110014	•Lithium-based Grease	1kg	E

**ROOSTER SHEAVE INSTALLATION
D00756304700800000Y**

**ROOSTER SHEAVE INSTALLATION
D00756304700800000Y**


POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756304700800000	Rooster sheave installation		
1	00756304700801010	•Plate	1	
2	00755904701610000	•Pin	1	
3	00756304700810000	•Pin	2	
4	0063400000029	•Spring-loaded pin	3	
5	00756301200000000	Rooster sheave	1	

MAIN BOOM ASSY. D00756300100000000Y




**MAIN BOOM ASSY.
D00756300100000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756300100000000	Main boom assy.		
1	00756300100200000	•Pulley housing	2	
2	1040000098	•Bolt	6	
3	1040300063	•Washer	10	
4	1040300066	•Washer	6	
5	1040100028	•Screw	8	
6	00756300100400001	•Adjusting pad	2	
7	00756300100001200	•Pressure plate	4	
8	006340000013	•Baffle 30	10	
9	1040000109	•Bolt	20	
10	1040300062	•Washer	20	
11	00755900100001050	•Spacer sleeve	10	
12	1050200261	•Deep grooved ball bearing	10	
13	00756300100001010	•Drum	1	
14	00755900100001030	•Pin	10	
15	00756300100001020	•Drum	1	
16	00756300100001030	•Drum	1	
17	00756300100001040	•Drum	1	
18	00756300100001050	•Drum	1	
19	00756300100001060	•Plate	2	
20	1040100158	•Screw	10	
21	00755900100001090	•Aligning block	16	
22	1040100208	•Screw	16	
23	1040300211	•Washer	80	
24	1040200113	•Nut	16	
25	1040300067	•Washer	16	
26	1040300048	•Washer	36	
27	1040100900	•Screw	36	
28	00755900100001101	•Grooved plate	9	
29	1040200192	•Nut	4	
30	00755900100001170	•Guide pulley of cable	1	
31	1040000111	•Bolt	1	
32	1040300060	•Washer	50	
33	1040000855	•Bolt	14	
34	00756300100001070	•Plate	2	

**MAIN BOOM ASSY.
D00756300100000000Y**



**MAIN BOOM ASSY.
D00756300100000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
35	00756300100001080	•Plate	2	
36	00755900100001181	•Pad	2	
37	00756300100600000	•Rope guide assy.	1	
38	1040500057	•Pin	2	
39	1040300106	•Washer	4	
40	00755900100001190	•Pin	2	
41		Telescopic boom section 3 assy.	1	
42		Telescopic boom section 2 assy.	1	
43		Basic boom assy.	1	
44		Telescopic boom section 1 assy.	1	
45		Telescopic boom section 4 assy.	1	

**ROPE GUIDE ASSY.
D00756300100600000Y**

**ROPE GUIDE ASSY.
D00756300100600000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756300100600000	Rope guide assy.		
1	1040300062	•Washer	4	
2	006340000013	•Baffle 30	2	
3	1040000109	•Bolt	4	
4	00755900100001050	•Spacer sleeve	2	
5	1050200084	•Anti-friction bearing	2	
6	00755900100001030	•Pin	2	
7	00756300100601010	•Drum	1	
8	00756300100610000	•Rope guide	1	

**MAIN BOOM INSTALLATION
D00756304700200001Y**

MAIN BOOM INSTALLATION
D00756304700200001Y

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756304700200001	Main boom installation		
1	00756304700201030	•Shaft	1	
2	1019900312	•Oil cup	2	
3	204110014	•Lithium-based Grease	0.2kg	E
4	00756304700201040	•Plate	1	
5	1040000016	•Bolt	2	
6	1040300065	•Washer	2	
7		Basic boom assy.	1	
8		Slewing table and its attachments assy. welded	1	

JIB
D00756300200000000Y

