

388H BACKHOE LOADER

EXPLODED DRAWING

前 言

388H 轮式挖掘装载机零部件图册，是为了便于用户在使用、维修和保养等工作中的方便而编绘的，以供在使用过程中查阅及参考，也可帮助用户了解本机的结构和装配关系。发动机随机已有零部件图册，本书故未编出。

图册按各总成及结构布局绘制出了各零部件的图形及相互关系。凡不可拆卸的部件，一般只标出部件代号，不另列其组成零件。明细表采用中英文对照编译了名称、代号及数量。

随着技术更新和生产的不断发展，产品将不断改进，故本图册的内容会有部分不相一致，因此用户在订购零部件时，请指明车出厂日期和编号。

FOREWORD

This part list of Model 388H backhoe loader is intent as a consultation reference for the customer to use the machine, and to help them repair and maintain the loaders. It can also help the users to be familiar with the construction and assembly relation of the machine. The engine has its own part list with it,so this book does not contain the engine part list.

The part list contains the part-drawings of deferent assem-blies,showing the shape of the parts as well as the assembling relation,The components which can not be taken apart(as the weldment or riveted assemblies) are Indicated only by their component numbers without the consisting part numbers.

目录 CONTENTS

图一	整 机	(1)
FIG1	THE WHOLE MACHINE	(1)
图二	动臂组合	(3)
FIG2	LOADER BOOM MODULE	(3)
图三	快换六合一	(5)
FIG3	QUICK CHANGE SIX IN ONE	(5)
图四	快换装置	(7)
FIG4	CHANGE THE GEAR	(7)
图五	联板组合	(9)
FIG5	LINKAGE MODULE	(9)
图六	车架总成	(11)
FIG6	FRAME ASSEMBLY	(11)
图七	转向液压系统	(13)
FIG7	STEERING HYDRAULIC SYSTEM	(13)
图八	工作液压系统	(15)
FIG8	WORKING DEVICE HYDRAULIC SYSTEM	(15)
图九	四合一斗液压系统	(17)
FIG9	FOUR-IN-ONE BUCKET HYDRAULIC SYSTEM	(17)
图十	快换液压系统	(19)
FIG10	CHANGE THE HYDRAULIC SYSTEM QUICKLY	(19)
图十一	装载阀总成	(21)
FIG11	LOADER VALVE ASSEMBLY	(21)
图十二	转斗油缸	(23)
FIG12	TILTING CYLINDER ASSEMBLY	(23)
图十三	举升油缸	(25)
FIG13	LIFTING CYLINDER ASSEMBLY	(25)
图十四	手制动系统	(27)
FIG14	MANUEL BRAKE SYSTEM	(27)
图十五	行车制动系统	(29)
FIG15	DRIVING BRAKE SYSTEM	(29)
图十六	方向机组合	(33)
FIG16	STEERING WHEEL MODULE	(33)
图十七	传动系统	(35)
FIG17	TRANSMISSION SYSTEM	(35)
图十八	变速箱总成	(37)
FIG18	GEARBOX ASSEMBLY	(37)
图十九	前进低档离合器	(41)
FIG19	FORWARD LOW GEAR CLUTCH	(41)
图二十	倒退离合器总成	(43)
FIG20	REVERSE CLUTCH ASSEMBLY	(43)


图二十一 双变中间轴.....	(45)
FIG21 DOUBLE VARIABLE INTERMEDIATE AXIS.....	(45)
图二十二 双变输出轴.....	(47)
FIG22 DUAL VARIABLE OUTPUT SHAFT.....	(47)
图二十三 双变变矩器.....	(49)
FIG23 DOUBLE TORQUE CONVERTER.....	(49)
图二十四 大泵口油泵轴组件.....	(52)
FIG24 LARGE PUMP SHAFT ASSEMBLY.....	(52)
图二十五 油泵轴组件.....	(54)
FIG25 OIL PUMP SHAFT ASSEMBLY.....	(54)
图二十六 驱动桥总成.....	(56)
FIG26 AXLE ASSEMBLY.....	(56)
图二十七 驱动桥总成.....	(58)
FIG27 AXLE ASSEMBLY.....	(58)
图二十八 主减总成.....	(62)
FIG28 MASTER SUBCTION ASSEMBLY.....	(62)
图二十九 轮胎轮辋总成.....	(64)
FIG29 RIM AND TYRE ASSEMBLY.....	(64)
图三十 传动液压系统.....	(66)
FIG30 TRANSMISSION HYDRAULIC SYSTEM.....	(66)
图三十一 转向器.....	(68)
FIG31 ORBIT-ROLL VALV.....	(68)
图三十二 优先阀.....	(70)
FIG32 PRIORITY VALVE.....	(70)
图三十三 齿轮泵总成.....	(72)
FIG33 GEAR PUMP ASSEMBIY.....	(72)
图三十四 油门操纵系统.....	(74)
FIG34 THROTTLE CONTROL SYSTEM.....	(74)
图三十五 熄火机构.....	(76)
FIG35 FLAMEOUT MECHANISM.....	(76)
图三十六 座椅安装总成.....	(78)
FIG36 SEAT INSTALLATION ASSEMBLY.....	(78)
图三十七 驾驶室.....	(80)
FIG37 CAB CEILING.....	(80)
图三十八 驾驶室外装总成.....	(82)
FIG38 CAB OUTER INSTALL ASSEMBLY.....	(82)
图三十九 顶盖线路.....	(85)
FIG39 FRAME ACCESSORIES.....	(85)

图四十 底盘线路·····	(89)
FIG40 CHASSIS WIRING·····	(89)
图四十一 仪表安装·····	(91)
FIG41 INSTRUMENT INSTALLATION·····	(91)
图四十二 控制台线路·····	(95)
FIG42 CONSOLE LINE·····	(95)
图四十三 电瓶组系统·····	(99)
FIG43 BATTERY CASES SYSTEM·····	(99)
图四十四 底盘液压系统(一)·····	(103)
FIG44 CHASSIS HYDRAULIC SYSTEM (ONE)·····	(103)
图四十五 底盘液压系统(二)·····	(106)
FIG45 CHASSIS HYDRAULIC SYSTEM (TWO)·····	(106)
图四十六 挖掘液压系统(一)·····	(108)
FIG46 BZCKHOE HYDRAULIC SYSTEM (ONE)·····	(108)
图四十七 挖掘液压系统(二)·····	(110)
FIG47 BZCKHOE HYDRAULIC SYSTEM (TWO)·····	(110)
图四十八 挖掘阀支架·····	(112)
FIG48 BACKHOE VALVE FRAME·····	(112)
图四十九 油缸及阀·····	(114)
FIG49 CYLINDER AND VALVE·····	(114)
图五十 挖掘阀总成·····	(116)
FIG50 BACKHOE VALVE FRAME·····	(116)
图五十一 回转油缸·····	(119)
FIG51 SWING BYLINDER·····	(119)
图五十二 挖掘油缸·····	(121)
FIG52 BACKHOE CYLINDER·····	(121)
图五十三 斗杆油缸·····	(123)
FIG53 CROWD CYLINDER·····	(123)
图五十四大臂油缸·····	(125)
FIG54 BOOM CYLINDER·····	(125)
图五十五 支腿油缸·····	(127)
FIG55 SABILIZER CYLINDER·····	(127)
图五十六 夹紧油缸·····	(129)
FIG56 GRIPING CYLINDER·····	(129)
图五十七 伸缩油缸·····	(131)

FIG57 RETRACTABLE CYLINDER.....	(131)
图五十八 装载装置操纵机构.....	(133)
FIG58 OPERATING MECHANISM OF WORKING DECICE.....	(133)
图五十九 挖掘操纵机构.....	(135)
FIG59 EXCAVATION CONTROL MECHANISM.....	(135)
图六十 挖掘摆臂组合.....	(137)
FIG60 BACKHOE SWING ARM MODULE.....	(137)
图六十一 挖斗组合.....	(139)
FIG61 BACKHOE BUCKET MODULE.....	(139)
图六十二 挖掘大臂组合.....	(141)
FIG62 BACKHOE BOOM MODULE.....	(141)
图六十三 伸缩斗杆组合.....	(143)
FIG63 TELESCOPIC ROD.....	(143)
图六十四 伸缩臂座体组合.....	(145)
FIG64 TELESCOPIC BOOM.....	(145)
图六十五 摆架总成.....	(147)
FIG65 AUXILIARY FRAME ASSEMBLY.....	(147)
图六十六 滑动架总成.....	(149)
FIG66 SLIDE FRAME ASSEMBLY.....	(149)
图六十七 滑架推拉座.....	(151)
FIG67 SLIDING FRAME PUSH-PULL SEAT.....	(151)
图六十八 柴油机装置.....	(153)
FIG68 DIESEL ENGINE MOUNT.....	(153)
图六十九 柴油箱总成.....	(155)
FIG69 FUEL TANK ASSEMBLY.....	(155)
图七十 机油箱总成.....	(157)
FIG70 ENGINE OIL TANK ASSEMBLY.....	(157)
图七十一 发动机罩总成.....	(159)
FIG71 ENGINE HOOD ASSEMBLY.....	(159)
图七十二 变速操纵杆部.....	(161)
FIG72 CONTROL SYSTEM.....	(161)
图七十三 空调系统.....	(163)
FIG73 AIR CONDITION SYSTEM.....	(163)

整机


MACHINE BODY



整机 MACHINE BODY

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	Z065011021	Scoop bucket	铲斗	1	
2	Z065010150	Boom	动臂	1	
3	W110010620	Tires	轮胎	4	
4	Z065070110	Battery box	电瓶箱	1	
5	W064600000	Back loading part Axle	后桥	1	
	W064500000	Front loading part Axle	前桥	1	
6	Z065020011	Car Frame	车架	1	
7	Z061240012	Slewing frame	回转架	1	
8	Z061260001	Digging bucket	挖斗	1	
9	W053025055	Excavate the cylinder	挖掘缸	1	
10	Z050260346	Telescopic arm bucket rod	伸缩臂斗杆	1	
11	Z062260210A	Bucket rod slide frame	斗杆滑架	1	
12	Z062260012	Big Arms	大臂	1	
13	W053025800	Big Arm cylinder	大臂缸	1	
14	Z062200011	Cabin Ass'y	驾驶室部分	1	
15	W017100000	Engine	发动机	1	
16	Z061053103	Rotating hood	旋转罩	1	


动臂组合 LODER BOOM MOODULE



动臂组合 LODER BOOM MOODULE

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	Z065010150	Boom	动臂	1	
2	Z062010900	Bushing	衬套	2	
3	Z062010910	Lifting cylinder front pin	举升缸前销轴	2	
4	Z062011060	Battery box	摇臂衬套	2	
5	Z062010880	Rear bushing of frame tie rod	车架拉杆后衬套	2	
6	Z061012150	Rear pin shaft of boom	动臂后销轴	2	
7	Z062010171	Block Circle	挡圈	2	
8	B190120303	Nylon lock nut	尼龙锁紧螺母	2	
9	B040611265	Bolt M12X65	螺 栓 M12X65	2	
10	B042521225	Bolt M12X25	螺 栓 M12X25	2	
11	Z062010900	Bushing	衬套	4	


快换六合一 QUICK CHANGE SIX IN ONE



快换六合一 QUICK CHANGE SIX IN ONE

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	Z061011590	Spindle Assembly	转轴总成	2	
2	Z061011620	Sleeve	轴套	2	
3	Z061011630	Pin shaft on cylinder	油缸上销轴	2	
4	Z061011560	Lower pin shaft of oil cylinder	油缸下销轴	2	
5	Z065011126	After four-in-one	四合一斗后	1	
6	B040910825	Bolt M8X25	螺栓 M8X25	14	
7	Z065011021	Four-in-one before	四合一斗前	1	
8	Z110010010	Bucket Tooth Bolt	斗齿螺栓	16	
9	Z110010800	Left Tooth	左边齿	1	
10	Z110010020	Bucket Teeth	斗齿	5	
11	Z110010800	Right Tooth	右边齿	1	
12	B050331614	Nut	螺母	16	
13	Z061011370	Pin	支架销轴	2	
14	Z061011330	Left support	左支座	1	
15	Z061011490	Fork stand	货叉支架	2	
16	Z061011440	Forks	货叉	2	
17	Z061011380	Shaft support	转轴支座	1	
18	B042520880	Bolt	六角法兰面螺栓	2	
19	B050210806	Nylon hexagon lock nut	锁紧螺母	2	
20	Z061011430	Right support	右支座	1	
21	B042521635	Bolt	六角法兰面螺栓	8	
22	Z061011480	Pin	定位销	2	
23	Z061011470	Pin	转销	2	
24	B080211063	Pin	开口销 6X60	2	


快换装置 **CHANGE THE GEAR**



快换装置 CHANGE THE GEAR

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	Z220510251	Pin Assembly	销轴总成	2	
2	Z050700015	Change the gear	快换装置	1	
3	Z062011012	Bucket arm pin shaft	铲斗动臂销轴	4	
4	B042521225	Bolt M12X25	螺栓 M12×25	4	


联板组合 LINKAGE MODULE



联板组合 LINKAGE MODULE

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	Z062010900	ARM front bushing	动臂前衬套	2	
2	Z062010970	Pole pin assembly	撑杆销轴总成	2	
3	B042521225	Bolt M12×25	螺栓 M12×25	10	
4	Z065010040	External Strut	外撑杆板	2	
5	B070114502	Block Circle	挡圈	10	
6	Z062010870	Frame tie rod front bushing	车架拉杆前衬套	2	
7	Z062010940	Rocker arm pin shaft	摇臂销轴	6	
8	Z062020900	Lock Lever	锁止杆	1	
9	Z062010880	Rear bushing of frame tie rod	车架拉杆后衬套	2	
10	Z065010100	Left rear lever	左后拉杆	1	
11	Z065010060	External rocker arm	外摇臂	2	
12	Z065010080	Inner rocker arm	内摇臂	2	
13	Z065010120	Right back lever	右后拉杆	1	
14	Z065010040	External strut plate	外撑杆板	2	
15	Z065010010	Front lever	前拉杆	2	

车架体 CHASSIS




车架体 CHASSIS

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	Z065020011	Chassis	车架体	1	
2	B070114002	Retaining ring	挡圈(轴用)	8	
3	Z050030810	Pin shaft on outrigger cylinder	支腿缸上销轴	2	
4	Z050030671	Lower pin shaft of outrigger cylinder	支腿缸下销轴	2	
5	Z050030681	Move your legs	活动支腿	2	
6	Z050030610	Foot support	支脚	2	
7	B040820027	Bolt M24×240	螺栓 M24×240	8	
8	B050212722	Lock nut M24	锁紧螺母 M24	8	
9	Z065020050	Pin	销轴	1	
10	Z065020060	Fixed shaft plate	定轴板	1	
11	B040911035	Bolt M10×35	螺栓 M10×35	2	
12	Z350021112	Transition joint	过渡接头	2	
13	Z060020952	Lubricating oil pipe i	润滑油管 I	1	

转向液压系统

STEERING HYDRAULIC SYSTEM




转向液压系统 STEERING HYDREULIC SYSTEM

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	Z062060030	Steering gear feed line	转向器进油管	1	
2	Z065060010	Diverter port a tubing	转向器 A 口油管	1	
3	WZL100W.01	Steering cylinder	转向缸	2	
4	Z350170030	Joint	接头	1	
5	QLWZG074-003027	Joint	直通接头	1	
6	Z062060170	Priority valve tubing	优先阀进油管	1	
7	W110250960	Joint	过渡接头	1	
8	QLWZG074-001412	Joint	直通接头	2	
9	QLWZG078-001414	Right Angle combination joint	直角组合接头	1	
10	Z062060210	Steering return tubing	转向器回油管	1	
11	Z180200230	Joint	接头	4	
12	QLWZG078-002222	Right Angle combination joint	直角组合接头	7	
13	QLWZG077-002218	Right angle adjustable joint	直角可调接头	3	
14	Z065060230	T to the Maebashi Pipeline	T 口到前桥油管	1	
15	Z062060150	LS tubing	LS 油管	1	
16	QLWZG078-003030	Right Angle combination joint	直角组合接头	1	
17	W110000300	Priority Valve	优先阀	1	
18	Z060250261	Priority valve return line	优先阀回油管	1	
19	W070100700	Solenoid valve	电磁阀	1	
20	W070100710	Valve Plate	阀板	1	
21	Z065060301	Valve Plate	控制电磁阀阀板	1	
22	Z590190020	Low pressure oil resistant hose	低压耐油胶管	1	
23	Z590190590	Patch flange	拼合法兰	1	
24	Z065060250	valve a outlet pipe	电磁阀 A 口油管	1	
25	Z065060270	valve b outlet pipe	电磁阀 B 口油管	1	

工作液压系统

WORKING DEVICE HYDRAUIC SYSTEM




工作液压系统 WORKING DEVICE HYDRAUIC SYSTEM

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'T Y	
1	W053025650	Flip Bucket	装载转斗缸	2	
2	QLWZG077-002218	Right angle adjustable joint	直角可调接头	8	
3	Z062100600	Oil feed pipe	左翻斗缸小腔硬管	1	
4	Z062100550	Oil feed pipe	翻斗缸大腔硬管	2	
5	Z065100120	Tubing	转斗缸软管	4	
6	Z065100031	Oil feed pipe	左翻斗缸小腔硬管	1	
7	Z065100050	Oil feed pipe	左翻斗缸大腔硬管	1	
8	Z061100323	Stent	支架	2	
9	Z061100350	Pipe Card	管卡	2	
10	Z064100162	Pressure Plate	压板	2	
11	W053025600	Lifting cylinder	举升缸	2	
12	Z062100346	Oil feed pipe	举升缸小腔硬管	2	
13	Z062100305	Oil feed pipe	举升缸大腔硬管	2	
14	Z062100164	Oil feed pipe	左举升缸大腔硬管	1	
15	Z062100144	Oil feed pipe	左举升缸小腔硬管	1	
16	Z062100091	Pressure Plate	压板	2	
17	QLWZG079-202222	Three-way connector	三通接头	4	
18	Z062240010	Tubing	工作阀出油管 1	1	
19	Z062240050	Tubing	工作阀出油管 3	2	
20	Z064100180	Tubing	工作阀出油管 2	1	
21	Z020100200	Joint	接头	6	
22	Z064100144	Oil feed pipe	右举升缸大腔硬管	1	
23	Z064100124	Oil feed pipe	右举升缸小腔硬管	1	
24	Z065100070	Oil feed pipe	右翻斗缸小腔硬管	1	
25	Z065100090	Oil feed pipe	右翻斗缸大腔硬管	1	
26	Z062100570	Oil feed pipe	右翻斗缸小腔硬管	1	

四合一斗液压系统

FOUR-IN-ONE BUCKET HYDRAULIC SYSTEM




四合一斗液压系统

FOUR-IN-ONE BUCKET HYDRAULIC SYSTEM

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY
1	W053025350	FOUR-IN -ONE CYLINDER	四合一斗油缸	2
2	W110251910	JOINT	接头	4
3	Z065100341	CYLINDER HOSE I	油缸软管 I	2
4	Z065100361	CYLINDER HOSE2	油缸软管 2	2
5	Z050560131	Hard Tube I	硬管 I	1
6	Z050560150	PIPE CARD	管卡	2
7	B042521225	BOLT	螺栓	2
8	Z050560101	Hard Tube2	硬管 2	1
9	Z065100280	RIGHT ARM HARD TUBE	右动臂硬管	1
10	Z065100300	TUBE	三通进油管	2
11	B042521020	BOLT	螺栓	4
12	Z065100240	TUBE	动臂硬管进油管	2
13	Z065100200	THIED RIGHT HARD TUBE	第三联右侧硬管	1
14	Z020100200	JOINT	接头	2
15	Z062380010	TUBE	第三联 A 口出油管	1
16	Z062380030	TUBE	第三联 B 口出油管	1
17	Z065100220	THIED LEFT HARD TUBE	第三联左侧硬管	1
18	Z065100260	Left arm hard tube	左动臂硬管	1

快换液压系统

CHANGE THE HYDRAULIC SYSTEM QUICKLY




快换液压系统

CHANGE THE HYDRAULIC SYSTEM QUICKLY

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY
1	W055200000	Change the oil cylinder quickly	快换油缸（两头忙）	1
2	Z065100600	Change the right front tubing	快换右前油管	1
3	Z065100580	Quick change right arm hard tube	快换右动臂硬管	1
4	B040711020	Bolt M10×20	螺栓 M10×20	4
5	Z065100540	Solenoid valve B outlet pipe	电磁阀 B 口出油管	1
6	Z061100280	Tube	油管	1
7	Z065100500	Tube	油管	1
8	W070100250	Valve Plate	阀板	1
9	W072000000	Wet solenoid directional valve	湿式电磁换向阀	1
10	Z590190940	Joint	过渡接头	4
11	Z065100520	Solenoid valve a outlet pipe	电磁阀 A 口出油管	1
12	Z065100560	Quick change left arm hard tube	快换左动臂硬管	1
13	Z065100620	Change the left front tubing	快换左前油管	1
14	Z350730590	Jont	接头	2


装载阀 LOAD VALVE



装载阀 LOAD VALVE

序号	零件号	Part Name	零件名称	数量	备注
ITEM	PART NO.			Q'TY	Remark
1	ACV-L25F-21	Screw plug	螺塞	3	
2	ISO6149/26.6x2.9	C-ring 26.6X2.9	O 型圈/26.6x2.9	3	
3	CDB-F20D-1.01d1	Inlet valve body	进油阀体	1	
4	CDB-F20-2.07	Valve Body	阀体	1	
5	CDB-F20-3.04c	Valve Body	阀体	1	
6	CDB20-2.03	Spring seat	弹簧座	3	
7	CDB20-2.05	Setting screw	定位螺钉	3	
8	CDB-F20-2.04a	Spring	弹簧	3	
9	XDYF20-02-00	Secondary Relief Valve	二次溢流阀	1	
10	CDB20-2.20	Spring seat	弹簧座	3	
11	CDB-F20-2.06	Positioning end cap	定位端盖	3	
12	GB93/6	PAD/6	弹垫/6	6	
13	GB70/M6x14	Hexagon Screw/M6X14	内六角螺钉/M6x14	6	
14	CDB-F20-3.04	Valve Body	阀体	1	
15	CDB-F20-5.00	Return valve body	回油阀体	1	
16	CDB-F20-7.00.3	Double headed bolt	双头螺栓 /M14x1.5x269	1	
17	GB6171/M14x1.5	Nut M14X1.5	螺母/M14x1.5	2	
18	CDB-F20-6.00.3	Stud Bolt /M12X1.25X269	双头螺栓 /M12x1.25x269	2	
19	GB6176/M12x1.25	Nut M12X1.25	螺母/M12x1.25	4	
20	B160120236	O-ring 23.6X2.65	O 型圈/23.6x2.65	1	
21	CDB-F20-1.09	Screw plug	螺塞	1	
22	CDB-F20-2.01	Spring	弹簧	3	
23	CDB-F20-2.02	Check Valve	单向阀	3	
24	GB3452.1/87.5x3.55	O-ring 87.5X3.55	O 型圈/87.5x3.55	4	
25	XDYF20-02/03.20	Secondary Relief Valve	二次溢流阀	1	
26	GB67/M6x10	Half Round head screw	半圆头螺钉/M6x10	6	
27	CDB-F20-2.11	Backing Plate	垫板	6	
28	CDB-F20-2.10	Nylon retaining ring	尼龙挡圈/25x3.2	6	
29	2-210	O-ring	O 型圈 18.64x3.53	6	
30	CDB20-4.01-02	Type 0 stem	O 型阀杆	3	
31	XDYF25-01b-00	Main Relief Valve	主溢流阀	1	


转斗油缸 TILT CYLINDER



转斗油缸 TILT CYLINDER

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'T Y	备注 Remark
1	ZD100	Cylinder block	缸体	1	
2	ZL30QG.30A-1	Piston	活塞	1	
6	ZD002	Guide sleeve	导向套	1	
13	ZD200	Piston rod	活塞杆	1	
14	ZD012	Rod bushing	杆衬套	1	
15	GB1152	Oil Cup M10 * 1	油杯 M10*1	2	
16	ZD117	Pipe Clip	管夹	1	
17	GBT16674.1	Hexagon flange bolts M10 * 15	六角法兰面螺栓 M10*15	2	
18	ZD011	Cylinder head bushing	缸头衬套	1	
19	W053025650-1	Sealed package	密封包	1	

举升油缸
 LIFTING CYLINDER




举升油缸 LIFTING CYLINDER

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	ZD100	Cylinder block	缸体	1	
2		Piston	活塞	1	
6	ZD002	Guide sleeve	导向套	1	
13	WZD200	Piston rod	活塞杆	1	
14	ZD012	Rod bushing	杆衬套	1	
15	GB1152	Oil Cup M10 * 1	油杯 M10*1	2	
16	ZD117	Pipe Clip	管夹	1	
17	GBT16674.1	Hexagon flange bolts	法兰面螺栓 M10*15	2	
18	B120525035	Joint Bearing 50	关节轴承 50	1	
19	W053025600-1	Sealed package	密封包	1	

手制动系统

MANNEL BRAKE SYSTEM




手制动系统

MANNEL BRAKE SYSTEM

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	W013500762	Handbrake assembly	手刹总成	1	
2	W013500762-1	Flexible shaft	软轴	1	

行车制动系统

DRIVING BRAKE SYSTEM




行车制动系统

DRIVING BRAKE SYSTEM

序号	零件号	Part Name	零件名称	数量	备注
ITEM	PART NO.			Q'TY	Remark
1	B050360807	Nuts M8	螺母	9	
2	B040810840	Bolt M8X40	螺栓 M8X40	5	
3	Z060110870	Support	支架	1	
4	B060310802	Washer 8	垫圈 8	4	
5	B060311003	Washer 10	垫圈 10	2	
6	Z060110810	Pedals	踏板	1	
7	B060212003	Washer	垫	1	
8	Z060110860	Joint cover	连接套	4	
9		Clevis	横夹	2	
10	B050360807	Nuts	螺母 M8	2	
11	Z060110930	Rod	顶杆	2	
12	W070800020	Brake pump	刹车泵	2	
13	Z060110920	Spring	弹簧	3	
14	B040710816	Bolt	螺栓	1	
15		Joint	连接板	1	
16	B080210002	Pin	销	2	
17	Z060110780	Pin shaft	销轴	1	
18		Pin	销	1	
19	Z050140130	Bushing	轴套	2	
20	B080330835	Pin shaft	销轴	1	
21	B050311008	Nuts	螺母 M10	1	
22	B060311003	Washer	垫圈 10	1	
23	B040711025	Bolt	螺栓 M10X25	1	
24	B080311032	Pin	销轴 10X32	2	
25	B040710830	Bilt	螺栓 M8X30	4	
26	B042520820	Bolt	螺栓 M8X20	4	
27	Z060110810	Pedal	踏板	1	


行车制动系统(二) DRIVING BRAKE SYSTEM(TWO)



行车制动系统(二) DRIVING BRAKE SYSTEM(TWO)

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	W062100001	Air Booster pump	空气加力泵	1	
2	Z064220100	Right bracket	右支架	1	
3	Z110070355	Gas storage tank	贮气筒 (L=380)	1	
4	Z065220030	Booster pump out of the tubing	加力泵出油管	1	
5	Z065220160	Air Bag intake pipe	气包进气管	1	
6	Z064220030	Air Bag outlet tube	气包出气管	1	
7	Z150110150	Air compressor outlet connector	空压机出气口接头	2	
8	Z065220140	Front axle right brake inlet pipe	前桥右制动进油管	1	
9	Z065220120	Front axle left brake inlet tubing	前桥左制动进油管	1	
10	Z065220350	Front axle brake tee joint	前桥刹车三通接头	1	
11	Z590220070	Oil-water separator inlet and outlet joint	油水分离器进出接头	2	
12	W110002580	Multifunctional unloading valve	多功能卸荷阀	1	
13	Z050110030	Air compressor outlet pipe	空压机出气管	1	
14	W910000100	Air Brake Valve	气制动阀	1	
15	Z064220160	Screw Block	螺堵	1	
17	Z590220230	Tubing fittings	油管接头	1	
18	Z590220190	Three-way board	三通板	1	
19	Z065220050	Rear axle brake inlet pipe	后桥制动进油管	2	
20	W110250962	Transition Joint	过渡接头	4	
21	W44000055	Right angle transition joint	直角过渡接头	1	
22	W110250961	Transition Joint	过渡接头	4	
23	Z065220110	Rear axle three-way oil board frame	后桥三通油路板架	1	
24	Z065220010	Foot brake air outlet	脚刹出气管	2	
25	Z060110140	Transmission valve tubing	变速阀油管	1	
26	Z050110160	Brake valve outlet tee	制动阀出气三通接头	1	
27	Z065220070	Front axle tee into tubing	前桥三通进油管	1	


方向机组合 STEERING MECHANISM MODULE



方向机组合 STEERING MECHANISM MODULE

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	W090120000	The steering wheel	方向盘	1	
2	GB6173-2000	Nut	螺母	1	
3	Z110050100	Spring	弹簧	1	
4	W110001650	Bearing	轴承	1	
5	W110002570	Horn relay ring	喇叭继电环	1	
6	Z110050110	Nesting	嵌入套	1	
7	Z110050010	Steering Shaft	转向轴	1	
8	Z110050060	Steering String	转向管柱	1	
9	B150101000	Butter nozzle	黄油嘴	1	
10	Z110050120	Axle sleeve	轴套	1	

传动系统 TRNSMISSION SYSTEM




传动系统 TRNSMISSION SYSTEM

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remar k
1	W064500000	Front drive axle assembly	前驱动桥总成	1	
2	Z065150011	Front drive shaft	前传动轴	1	
3	W024200000	Gearbox	变矩器变速箱	1	
4	Z065150021	Rear drive shaft	后传动轴	1	
5	W110010620	Tire	轮胎(无内胎)	4	
6	W064600000	Rear drive axle assembly	后驱动桥总成	1	

变速箱总成


GEARBOX SSEMBLY



变速箱总成 GEARBOX SSEMBLY

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	03.04.230	Forward tubing	前进油管	1	
2	03.06.051	First gear tubing	一档油管	1	
3	03.04.250	Reverse fuel line	倒档油管	1	
4	ZL15.5-28	Hollow Bolt M27X2	空心螺栓 M27X2	1	
5	03.04.260	Second gear tubing	二档油管	1	
6	ZL30D.1-02	Lubricating pipe	润滑油管	1	
7	B040912030	Bolt M20X30	六角头螺栓	7	
8	B060101007	Washers 20	弹性垫圈 20	8	
9	ZL15.5.3-1D	End cap M14X1.5	端盖 M14X1.5	1	
10	ZL15.5.4-1D	End cap M27X2	端盖 M27X2	1	
11	ZL16FXG	Shift Valve	换挡阀	1	
12	B060812703	Combination pad 27	组合垫 27	3	
13	03.04.451	Hanger ring screws M12	吊环螺钉 M12	1	
14	W024200120	Box Body	箱体	1	
15	ZL15.5-30	Oil Baffle	挡油板	1	
16	ZL30W.6-03	Cable holding plate	拉线固定板	1	
17	W024200100	Gearbox left bracket	变速箱左支架	1	
18	W024200110	High and low speed bracket assembly	高低速支架总成	1	
19	YJ240F-24	Return Tubing Connector 25	回油管接头 25	1	
20	W024200010	Reverse Clutch Assembly	倒档离合器总成	1	
21	W024200020	Forward Clutch Housing Assembly	前进离合器壳体总成	1	
22	ZL15.5-35	Locating Pin	定位销	2	
23	W024200030	Torque converter assembly	变矩器总成	1	
24	W024200040	General drawing of caliper disc brake	钳盘制动器总图 (左)	1	
25	W024200050	Small brake disc	小刹车盘	1	
26	W024200060	Output shaft assembly	输出轴总成	1	
27	W024200070	Intermediate Shaft Assembly	中间轴总成	1	
28	B060812002	Combination pad 20	组合垫 20	1	
29	ZL15.5.7-1	Drain plug M20X1.5	放油螺塞 M20X1.5	1	
30	W024200080	Fork support assembly	拨叉支架总成	1	


变速箱总成 GEARBOX SSEMBLY



变速箱总成 GEARBOX SSEMBLY

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
31	W024200090	Gearbox right bracket	变速箱右支架	1	
32	ZL15.5.8	Oil Mark	油标	1	
33	W024200130	Window cover	窗口盖板	1	
34	ZL15.5-29	Hollow Bolt M14X1.5	空心螺栓 M14X1.5	1	
35	B040912030	Bolt M20X30	六角头螺栓	1	
36	ZL15.5-2	Right Angle joint	直角接头	8	
37	B061621225	Plain washers class A 12	平垫圈 A 级 12	4	
38	B060111203	Elastic Washer 12	弹性垫圈 12	4	
39	B040911225	Bolt M12X25	六角头螺栓	4	
40	B040710816	Bolt M8X16	六角头螺栓 M8×16	8	
41	B040711025	Bolt M10X25	六角头螺栓	20	
42	B040611030	Bolt M10X30	六角头螺栓	27	
43	B060801403	Combined Washer 14	组合垫圈 14	2	
44	03.04.342	Nut M8	六角螺母 M8	1	
45	B040910825	Bolt M8X25	六角头螺栓 M8×25	1	
46	B060110802	Elastic Washer 8	弹性垫圈 8	13	
47	B060810802	Combined Washer 8	组合垫 8	1	
48	JB/ZQ4446	Hexagon Socket R 3	内六角螺塞 R3	1	
49	B060111003	Elastic Washer 10	弹性垫圈 10	47	
50	B060110802	Elastic Washer 8	弹性垫圈 8	8	
51	03.04.342	RC1/8 plug	RC1/8 丝堵	4	
52	B160120106	O-ring 10.6X2.65	O 型密封圈	4	
53	B160120950	O-ring 95X2.65	O 型圈 95X2.65	2	
54	B040910835	Bolt M8X35	六角头螺栓 M8×35	4	
55	B060110802	Elastic Washer 8	弹性垫圈 8	4	

前进低档离合器 FORWARD LOW GEAR CLUTCH
(W024200020)




前进低档离合器 FORWARD LOW GEAR CLUTCH

(W024200020)

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	W030300068	Cylindrical roller bearing	圆 柱 滚 子 轴 承 NJ308M	2	
2	W024200140	SPACER ring	隔环	1	
3	03.04.343	Stop Ring 80	止动环 80	2	
4	B120120818N	Deep groove ball bearing	深沟球轴承 6208N	2	
5	W024200150	Set 12	隔套 12	1	
6	W024200160	Gear 35 teeth	齿轮 35 齿	1	
7	W030100620	Resilient retaining rings for holes, type A	孔用弹性挡圈 A 型 150	2	
8	ZL15.5.1-3	Piston press plate	活塞压板	2	
9	ZL15.5.1.3	Active	主动片	14	
10	ZL15.5.1-4	Passive	被动片	12	
11	W030100582	Elastic retaining ring for shaft type A 52	轴用弹性挡圈 A 型 52	2	
12	W024200170	Spring seat	弹簧座	2	
13	W024200180	Forward low gear clutch housing	前进低档离合器壳 体	1	
14	W024200190	Clutch shaft	离合器轴	1	
15	03.04.342	RC1/8 plug	RC1/8 丝堵	2	
16	ZL15.5-36	Seal ring 40	密封环 40	3	
17	W024200200	Compartment 45	隔套 45	1	
18	B120120818	Deep groove ball bearing	深沟球轴承 6208	2	
19	B070158003	Elastic retaining ring for holes 80	孔用弹性挡圈 80	2	
20	W024200210	SPACER ring	隔环 8	1	
21	W024200220	First Gear 29	一档齿轮 29	1	
22	W024200230	Spring	弹簧	2	
23	ZL15.5.1.1-1D	Piston	活塞	2	
24	ZL15.5.1.1-3	Piston outer seal ring	活塞外封环	2	
25	B160140530	O-ring 53X5.3	O 型圈 53X5.3	2	

倒退离合器总成 REVERSE CLUTCH ASSEMBLY (W024200010)



倒退离合器总成

REVERSE CLUTCH ASSEMBLY (W024200010)

序号 ITEM	零件号 PART NO.	Part Name	零件名称	数量 Q'TY	备注 Remark
1	W024200240	SPACER ring	隔环	1	
2	03.04.343	Stop Ring	止动环	2	
3	B120120818N	Deep groove ball bearing	深沟球轴承 6208N	2	
4	W024200250	Set 12	隔套 12	1	
5	W024200260	Gear 35 teeth	齿轮 35 齿	1	
6	W030100620	Resilient retaining rings for holes, type A	孔用弹性挡圈 A 型	2	
7	W030100582	Elastic retaining ring for shaft type A	轴用弹性挡圈 A 型	2	
8	W024200270	Spring seat	弹簧座	2	
9	W024200280	Spring	弹簧	2	
10	ZL15.5.1.1-1D	Piston	活塞	2	
11	ZL15.5.1.1-3D	Piston outer seal ring	活塞外封环	2	
12	W024200290	Reverse low clutch housing	倒退低档离合器壳体	1	
13	W024200300	Reverse clutch shaft	倒档离合器轴	1	
14	ZL15.5-36	Sealing ring	密封环	3	
15	03.04.342	Rc1-8 plug	Rc1-8 丝堵	2	
16	W024200310	Ring divider 18.5	隔环 18.5	1	
17	W024200320	Compartment 14	隔套 14	1	
18	B070158003	B-type elastic retaining ring for Hole	孔用弹性挡圈 B 型	2	
19	B1204522209	Cylindrical roller bearing	圆柱滚子轴承	2	
20	W024200330	Gear 41	齿轮 41	1	
21	W024200340	Gear 52	齿轮 52	1	
22	GB / T93-1987	Elastic Washer	弹性垫圈	8	
23	B040911235	Bolt M12X35	六角头螺栓	8	
24	ZL15.5.1-3	Piston press plate	活塞压板	2	
25	ZL15.5.1.3	Active	主动片	14	
26	ZL15.5.1-4	Passive	被动片	12	
27	B160140530	O-ring 53X5.3	O 型圈 53X5.3	2	
28	B120452308M	Cylindrical roller bearing	圆柱滚子轴承	2	