



**MAIN BOOM ASSY.
D00756300100000000Y**


**MAIN BOOM ASSY.
D00756300100000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
	00756300100000000	Main boom assy.		
1	00756300100200000	•Pulley housing	2	
2	1040000098	•Bolt	6	
3	1040300063	•Washer	10	
4	1040300066	•Washer	6	
5	1040100028	•Screw	8	
6	00756300100400001	•Adjusting pad	2	
7	00756300100001200	•Pressure plate	4	
8	006340000013	•Baffle 30	10	
9	1040000109	•Bolt	20	
10	1040300062	•Washer	20	
11	00755900100001050	•Spacer sleeve	10	
12	1050200261	•Deep grooved ball bearing	10	
13	00756300100001010	•Drum	1	
14	00755900100001030	•Pin	10	
15	00756300100001020	•Drum	1	
16	00756300100001030	•Drum	1	
17	00756300100001040	•Drum	1	
18	00756300100001050	•Drum	1	
19	00756300100001060	•Plate	2	
20	1040100158	•Screw	10	
21	00755900100001090	•Aligning block	16	
22	1040100208	•Screw	16	
23	1040300211	•Washer	80	
24	1040200113	•Nut	16	
25	1040300067	•Washer	16	
26	1040300048	•Washer	36	
27	1040100900	•Screw	36	
28	00755900100001101	•Grooved plate	9	
29	1040200192	•Nut	4	
30	00755900100001170	•Guide pulley of cable	1	
31	1040000111	•Bolt	1	
32	1040300060	•Washer	50	
33	1040000855	•Bolt	14	
34	00756300100001070	•Plate	2	

**MAIN BOOM ASSY.
D00756300100000000Y**


**MAIN BOOM ASSY.
D00756300100000000Y**

POS.	CODE	DESCRIPTION	QTY.	REMARK
35	00756300100001080	•Plate	2	
36	00755900100001181	•Pad	2	
37	00756300100600000	•Rope guide assy.	1	
38	1040500057	•Pin	2	
39	1040300106	•Washer	4	
40	00755900100001190	•Pin	2	
41		Telescopic boom section 3 assy.	1	
42		Telescopic boom section 2 assy.	1	
43		Basic boom assy.	1	
44		Telescopic boom section 1 assy.	1	
45		Telescopic boom section 4 assy.	1	