

turtlesim plus package

turtlesim_plus_node.py

/turtlesim_plus

Publisher

```
/remove_turtle: turtlesim/srv/Kill
/spawn_pizza: turtlesim_plus/interfaces/srv/GivePosition
/spawn_turtle: turtlesim/srv/Spawn
/turtle1_cat: std_srvs/srv/Empty
/turtle1_stop: std_srvs/srv/Empty
```

Subscriber

```
mouse_position: geometry_msgs/msg/Point
parameter_events: rc1_interfaces/msg/ParameterEvent
rconsole: rc1_interfaces/msg/Log
turtle1_pizza_count: std_msgs/msg/Int64
turtle1_pose: turtlesim/msg/Pose
turtle1_scan: turtlesim_plus/interfaces/msg/ScannerDataArray
```

Service Server

```
/remove_turtle: turtlesim/srv/Kill
/spawn_pizza: turtlesim_plus/interfaces/srv/GivePosition
/spawn_turtle: turtlesim/srv/Spawn
/turtle1_cat: std_srvs/srv/Empty
/turtle1_stop: std_srvs/srv/Empty
/turtlesim_plus_describe_parameters:
  rc1_interfaces/srv/DescribeParameters
/turtlesim_plus_get_parameter_types:
  rc1_interfaces/srv/GetParameterTypes
/turtlesim_plus_get_parameters: rc1_interfaces/srv/GetParameters
```

Service Client

```
/turtlesim_plus_list_parameters: rc1_interfaces/srv/ListParameters
/turtlesim_plus_set_parameters: rc1_interfaces/srv/SetParameters
/turtlesim_plus_set_parameters_atomically:
  rc1_interfaces/srv/SetParametersAtomically
```

Terminal

Publisher

Subscriber

Service Server

Service Client

lab2 package

eater.py

/eater_node

Publisher

```
!hunt: std_msgs/msg/Bool
/turtle1_cmd_vel: geometry_msgs/msg/Twist
```

Subscriber

```
goal_pose: geometry_msgs/msg/PoseStamped
mouse_position: geometry_msgs/msg/Point
turtle1_pose: turtlesim/msg/Pose
```

Service Server

Service Client

```
/remove_turtle: turtlesim/srv/Kill
/spawn_pizza: turtlesim_plus/interfaces/srv/GivePosition
/spawn_turtle: turtlesim/srv/Spawn
/turtle1_cat: std_srvs/srv/Empty
/turtle1_stop: std_srvs/srv/Empty
```

killer.py

/killer_node

Publisher

```
!killer_cmd_vel: geometry_msgs/msg/Twist
```

Subscriber

```
!hunt: std_msgs/msg/Bool
!killer_pose: turtlesim/msg/Pose
!turtle1_pose: turtlesim/msg/Pose
```

Service Server

Service Client

```
/remove_turtle: turtlesim/srv/Kill
/spawn_turtle: turtlesim/srv/Spawn
```

turtlesim_pose.py

/odom_pub

Publisher

Subscriber

Service Server

Service Client

rviz2

/rviz

Publisher

Subscriber

Service Server

Service Client