

Restore

Mold Remediation SOP

CONFIDENTIAL - FOR EMPLOYEE USE ONLY
Last Updated: April 2026

Assessment & Containment

Mold remediation must follow IICRC S520 standards at all times.

1. Obtain and review any industrial hygienist (IH) report before beginning work
2. Establish containment using 6-mil polyethylene sheeting
3. Create negative air pressure within the containment area
4. Set up decontamination chamber at containment entry/exit
5. Post warning signs on all containment barriers

Remediation Procedures

Within the containment zone:

- HEPA vacuum all affected surfaces before removal
- Remove and bag affected porous materials (drywall, insulation, carpet)
- Clean non-porous surfaces with appropriate antimicrobial solution
- HEPA vacuum all surfaces after cleaning
- Encapsulate remaining structural elements if specified in the protocol
- All removed materials must be double-bagged and sealed before transport through clean areas

Post-Remediation Verification

Before releasing containment:

- Conduct visual inspection - no visible mold growth
- HEPA vacuum all containment materials
- Request post-remediation verification (PRV) from independent IH
- Do not remove containment until PRV clearance is received
- Document all work with photos and detailed logs