

Restore

Water Damage Restoration SOP

CONFIDENTIAL - FOR EMPLOYEE USE ONLY

Last Updated: April 2026

Initial Assessment & Documentation

Upon arrival at a water damage site:

1. Document existing conditions with photos and video BEFORE any work begins
2. Identify the water source and category (1, 2, or 3)
3. Map affected areas using moisture meters and thermal imaging
4. Create a scope of work and review with the property owner
5. Set up containment if needed to prevent cross-contamination

Water Extraction

Begin extraction within 1 hour of arrival on-site:

- Use truck-mounted extractors for large volume standing water
- Use portable extractors for smaller areas and carpet extraction
- Extract water from all affected materials (carpet, pad, hard floors)
- Remove and dispose of saturated padding (non-salvageable)
- Document moisture readings before and after extraction

Drying & Monitoring

Set up drying equipment according to IICRC S500 standards:

- Calculate required air movers based on square footage (1 per 10-16 linear feet of wall)
- Position dehumidifiers to achieve target grain depression
- Monitor daily: take moisture readings, adjust equipment placement
- Document all readings on the daily monitoring log
- Drying is complete when materials reach acceptable moisture content per IICRC standards