P1S BUILD PLATES: WHICH ONE?

For your three older Bambu plates: Textured PEI, Engineering Plate, and Cool Plate.

PLATE	REACH FOR IT WHEN…	GOOD FIT	WATCH OUT
Textured PEI	**You want the default, low-fuss plate.** Great first choice for routine printing and a textured bottom surface.	**PLA • PETG • TPU** Also many ABS/ASA jobs when the filament/profile permits it.	Texture transfers to the part. Very small contact areas may prefer a smooth plate. Some engineering formulations are better on Engineering Plate.
Engineering Plate	**You are printing engineering/high-temp materials** or want a smooth-ish surface with the adhesion system Bambu specifies.	**ABS / ASA • PC • PA/Nylon** Especially specialty engineering blends when their profile calls for it.	Glue is often part of the recommended setup—sometimes for adhesion, sometimes as a release layer. Follow the exact filament profile.
Cool Plate	**You are printing PLA and want a low bed temperature.** Useful for keeping the enclosed P1S from accumulating as much chamber heat.	**PLA / PLA-family** Use the correct Cool Plate sheet/profile and adhesive guidance.	**Not your general engineering-material plate.** The original Cool Plate is a consumable sticker surface and typically uses glue.

FAST DECISION

PLA? → Textured PEI for easiest everyday use; Cool Plate when you specifically want the cool-bed PLA workflow.
PETG or TPU? → Start with Textured PEI.
ABS / ASA / PC / PA? → Start by checking the filament profile; Engineering Plate is the natural first stop for the demanding engineering materials.

Important: plate compatibility varies by exact filament formulation. Filled materials (CF/GF), specialty blends, and old vs. new Bambu plate generations can change the recommendation. Select the actual plate in Bambu Studio so the printer uses the matching bed-temperature profile.