

HP 150 Personal Computers

**HP 150
TECHNICAL
Reference Manual**

Product No. 45625A



**Personal Office Computer Division
974 East Arques Avenue, Sunnyvale, CA 94086**

NOTICE

Purpose: This manual provides detailed technical information on the internals of the HP 150 hardware, firmware, and software. It is designed to aid in the development of hardware and software products which will become part of, or work in conjunction with, the HP 150.

User Level: Use of this information assumes a background in digital logic and assembly-language programming.

Related Products: The *HP 150 Programmer's Tool Kit* (Product 45435A) contains the Assembler, Linker, and appropriate documentation. The *HP 150 MS-DOS User's Guide* (Product 45624A) provides details on MS-DOS.

Compatibility: A hardware/software product designed to be dependent on one specific version of the HP 150 hardware, firmware, or software may be incompatible with other versions of the HP 150 -- or such a product may be incompatible with future personal computer products from Hewlett-Packard, including models based on the HP 150 itself.

Support: Because of the specialized nature of this information, the many capabilities of the HP 150 when used at this level, and the importance of design strategy for successful implementation of hardware/firmware-based products, assistance in the use of this manual is provided through local consulting -- available by the hour (Product 45686A) or by the day (Product 45687A). Contact your local HP Sales and Service Office -- ask for Personal Computer Systems Engineering.

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another program language without the prior written consent of Hewlett-Packard Company.

LIST OF EFFECTIVE PAGES

The List of Effective Pages gives the date of the current edition, and lists the dates of all pages of that edition and all updates. Within the manual, any page changed since the last edition is indicated by printing the date the changes were made on the bottom of the page. Changes are marked with a vertical bar in the margin. If an update is incorporated when an edition is reprinted, these bars and dates remain. No information is incorporated into a reprinting unless it appears as a prior update.

First Edition.....May 1984

| Effective Pages | Date |
|-----------------|----------|
| ALL..... | May 1984 |

PRINTING HISTORY

New editions are complete revisions of the manual. Update packages, which are issued between editions, contain additional and replacement pages to be merged into the manual by the customer. The date on the title page and back cover of the manual changes only when a new edition is published. When an edition is reprinted, all the prior updates to the edition are incorporated. No information is incorporated into a reprinting unless it appears as a prior update. The edition does not change.

First Edition.....May 1984

PREFACE

CAUTION

This document provides detailed technical information revealing internal details of the HP 150 hardware, firmware, and software.

The information presented allows development of hardware and software products for the HP 150 which may be incompatible with future personal computer products from Hewlett-Packard, including models based upon the HP 150 itself.

This manual presents technical information concerning the HP 150 Personal Computer and covers its hardware, firmware, and software subsystems.

The intent of the manual is to aid in the development of hardware and software products which will become part of, or work in conjunction with, the HP 150.

The reader is directed towards the HP 150 Programmer's Reference materials for complementary programming information including language and development tools.

MANUAL OVERVIEW

This manual consists of the following sections and appendices:

Section 1 - Introduction provides an overview of the HP 150.

Section 2 - Hardware Overview provides product specifications information and briefly describes each subsystem of the HP 150.

Section 3 - Hardware Subsystems contain detailed information on the HP 150's hardware subsystems and helpful design hints.

Section 4 - Memory and I/O Mapping provides information on the memory and input/output bit mappings of the system's processor.

Section 5 - System Software provides information on the operating systems, device drivers, MS-DOS calls, AGIOS, BIOS, configuration, and disc format structure.

Section 6 - System Firmware provides mapping information on system RAM memory.

Section 7 - Programming the HP 150 contains programming information on escape sequences, MS-DOS, AGIOS, alphanumeric and graphics displays, datacomm, keyboard, HPIB, and accessory card interfacing.

Section 8 - AGIOS Function Call Reference provides a reference list of AGIOS function calls.

Appendix A - Logic Diagrams contain schematic diagrams of the HP 150.

Appendix B - Further Reference Documents provides a list of reference documents to supplement this manual.

TABLE OF CONTENTS

Section 1 - INTRODUCTION

| | |
|-----------------------------|-----|
| HP 150 System Overview..... | 1-1 |
| System Architecture..... | 1-1 |
| Display..... | 1-2 |
| Keyboard..... | 1-3 |
| Communications..... | 1-3 |

Section 2 - HARDWARE OVERVIEW

| | |
|--|-----|
| Introduction..... | 2-1 |
| Product Specifications..... | 2-1 |
| General Description..... | 2-1 |
| Physical Specifications..... | 2-2 |
| Environmental Specifications..... | 2-2 |
| Product Regulations..... | 2-3 |
| Power Requirements..... | 2-3 |
| Communications..... | 2-3 |
| Subsystem Power Requirements..... | 2-3 |
| HP 150 Printed Circuit Assemblies..... | 2-5 |
| Analog Boards..... | 2-6 |
| Digital Logic Boards..... | 2-6 |

Section 3 - HARDWARE SUBSYSTEMS

| | |
|--|------|
| Front Plane..... | 3-1 |
| Thermal (Integral) Printer Interface..... | 3-1 |
| Front Plane Connectors and Signals..... | 3-2 |
| Video Board Front Plane Connector..... | 3-4 |
| Accessory Front Plane Connectors..... | 3-5 |
| Sweep Board Connector..... | 3-6 |
| Touchscreen Connector..... | 3-6 |
| Integral Printer Connector..... | 3-7 |
| Power Supply Connector..... | 3-7 |
| Front Plane Signal Descriptions..... | 3-7 |
| Processor Subsystem..... | 3-10 |
| Overview..... | 3-10 |
| Memory and I/O Mappings..... | 3-11 |
| Processor Board Block Diagrams..... | 3-11 |
| Reset, CMOS Power, and Test Strap Logic..... | 3-13 |
| Microprocessor System Architecture..... | 3-13 |
| Bus Cycles..... | 3-14 |
| System Timing and Control Logic..... | 3-14 |
| Interrupt Controller..... | 3-18 |
| I/O Devices..... | 3-19 |
| Video Subsystem..... | 3-23 |
| Video Technology and Display Format..... | 3-23 |
| Displaying Alpha Characters..... | 3-27 |
| Video Board Overview..... | 3-32 |

TABLE OF CONTENTS (Continued)

| | |
|--|------|
| Keyboard and Touchscreen Subsystem..... | 3-37 |
| Keyboard..... | 3-37 |
| Touchscreen..... | 3-38 |
| Specifications..... | 3-40 |
| Timing..... | 3-40 |
| 8041 Keyboard/Touchscreen Scanner..... | 3-44 |
| Datacomm Subsystem..... | 3-50 |
| General Description..... | 3-50 |
| RS232C/422 Datacomm Module Connector..... | 3-50 |
| Baud Rate Generator..... | 3-51 |
| Multi-Protocol Controller..... | 3-52 |
| Communications Interface Circuitry..... | 3-53 |
| Mezzanine Memory Subsystem..... | 3-55 |
| Mezzanine Memory PCA..... | 3-55 |
| PCA Overview..... | 3-55 |
| Connector Signals..... | 3-57 |
| ROM..... | 3-59 |
| Slot Selection Generation..... | 3-60 |
| CMOS RAM..... | 3-61 |
| LEDs..... | 3-62 |
| Dynamic RAM..... | 3-62 |
| Accessories Subsystem..... | 3-64 |
| Accessory Hardware Design Guidelines..... | 3-64 |
| Mechanical Specifications..... | 3-64 |
| Power Requirements..... | 3-64 |
| Thermal Limits..... | 3-65 |
| Accessory Signal Loading Restrictions..... | 3-65 |
| Signal Timing Diagrams..... | 3-67 |
| Accessory Front Plane Connector..... | 3-70 |
| Accessory Connector Signal Descriptions..... | 3-71 |
| Accessory Card Hardware and Electrical..... | 3-73 |
| Electrical Design..... | 3-73 |
| Mechanical Design..... | 3-76 |
| Drawings..... | 3-80 |

Section 4 – MEMORY AND I/O MAPPING

| | |
|--|-----|
| Memory Mapped Devices..... | 4-1 |
| HP 150 Memory Map..... | 4-1 |
| CRT Controller Registers..... | 4-3 |
| Horizontal Timing Registers (R0, R1, R2 and R3)..... | 4-4 |
| Vertical Timing Registers (R4, R5, R7, R8 and R9)..... | 4-5 |
| Pin Configuration/Skew Bits Register (R6)..... | 4-5 |
| DMA Control Register (RA)..... | 4-5 |
| Control Register (RB)..... | 4-6 |
| Table Start Register (RC and RD)..... | 4-6 |
| Auxiliary Register 1 (RE and RF)..... | 4-6 |
| Sequential Break Register 1 (R10)..... | 4-6 |

TABLE OF CONTENTS (Continued)

| | |
|--|------------|
| Data Row Register (R1)..... | 4-6 |
| Data Row End Register (R12)..... | 4-6 |
| Auxiliary Address Register 2 (R13 and R14)..... | 4-7 |
| Start Command (R15)..... | 4-7 |
| Reset Command (R16)..... | 4-7 |
| Smooth Scroll Offset Register (R17)..... | 4-7 |
| Vertical Cursor Control Register (R18)..... | 4-7 |
| Horizontal Cursor Register (R19)..... | 4-7 |
| Cursor Registers R38 and R39 (READ)..... | 4-7 |
| Interrupt Enable Register (R1A)..... | 4-7 |
| Status Register (R3A)..... | 4-8 |
| Vertical Light Pen Register (R3B)..... | 4-8 |
| Horizontal Light Pen Register (R3C)..... | 4-8 |
| Video Attribute Latch..... | 4-8 |
| I/O Mapped Devices..... | 4-9 |
| HP 150 Input/Output Map..... | 4-9 |
| Real Time Clock (MM58167A)..... | 4-10 |
| Integral Printer Interface..... | 4-11 |
| Keyboard/Touchscreen Controller (8041A)..... | 4-11 |
| Datacomm Port 1 Control Lines/Manuf Test Repeat..... | 4-12 |
| Datacomm Port 2 Control Lines/Clock Source Select..... | 4-12 |
| Interrupt Controller (8259)..... | 4-13 |
| Baud Rate Generator (8116T)..... | 4-13 |
| HPIB Controller (9914)..... | 4-14 |
| MPSC - Datacomm Controller (7201/8274)..... | 4-14 |

Section 5 ~ SYSTEM SOFTWARE

| | |
|---|------------|
| Operating System Structure..... | 5-1 |
| The Command Processor..... | 5-2 |
| The Personal Applications Manager (P.A.M.)..... | 5-2 |
| Applications Programs..... | 5-2 |
| Basic Disc Operating System (BDOS)..... | 5-3 |
| Basic Input/Output System (BIOS)..... | 5-3 |
| Operating System Memory Usage..... | 5-4 |
| Operating System Memory Map..... | 5-4 |
| Interrupt Vectors..... | 5-5 |
| MS-DOS Interrupts..... | 5-7 |
| HP 150 Hardware Interrupts..... | 5-7 |
| Firmware Variables..... | 5-7 |
| BIOS and BDOS..... | 5-7 |
| Disc Buffer Cache..... | 5-7 |
| File Control Blocks (FCBs)..... | 5-8 |
| Fields of the FCB..... | 5-8 |
| Installable Device Drivers..... | 5-10 |
| PAMCODE.EXE or Resident Portion of COMMAND.COM..... | 5-10 |
| Application Program Area (Program Segment)..... | 5-11 |
| Program Segment Prefix (PSP) Control Block..... | 5-12 |

TABLE OF CONTENTS (Continued)

| | |
|---|-------------|
| How a Program Terminates..... | 5-13 |
| Conditions in Effect When a Program Receives Control..... | 5-13 |
| Transient Portion of COMMAND.COM..... | 5-15 |
| HP 150 Devices..... | 5-16 |
| Logical (Mappable) Devices..... | 5-16 |
| Physical Devices..... | 5-16 |
| Mapping Logical to Physical Devices..... | 5-16 |
| The Device Configuration Utility..... | 5-17 |
| Installable Devices..... | 5-18 |
| Character Devices and Block Devices..... | 5-20 |
| How Application Programs Can Get to Devices..... | 5-20 |
| Device Driver Structure..... | 5-21 |
| Pointer to Next Device Field..... | 5-22 |
| Attribute Field..... | 5-22 |
| Strategy and Interrupt Routines..... | 5-23 |
| Name Field..... | 5-23 |
| Device List..... | 5-24 |
| How to Create a Device Driver..... | 5-26 |
| How MS-DOS Calls a Device Driver..... | 5-27 |
| Request Header..... | 5-27 |
| Unit Code..... | 5-27 |
| Command Code Field..... | 5-28 |
| Status Word..... | 5-28 |
| Device Driver Functions and Parameters..... | 5-31 |
| Init..... | 5-31 |
| Media Check..... | 5-32 |
| Build BPB (BIOS Parameter Block)..... | 5-33 |
| Read or Write..... | 5-35 |
| Non-Destructive Read No Wait..... | 5-36 |
| Status..... | 5-37 |
| Flush..... | 5-38 |
| HP 150 Installable Device Driver Example..... | 5-39 |
| AGIOS: I/O Control of the Con Device..... | 5-49 |
| The Alpha/Graphic Input/Output System (AGIOS)..... | 5-49 |
| Accessing the AGIOS..... | 5-49 |
| BIOS and Its Devices..... | 5-51 |
| Introduction..... | 5-51 |
| The CONFIG.SYS File..... | 5-55 |
| Disc Format and Directory Structure..... | 5-57 |
| Physical Disc Format..... | 5-57 |
| Disc Media Storage Capacity..... | 5-57 |
| Disc Sector Allocation..... | 5-58 |
| Header Record..... | 5-59 |
| Boot Sector..... | 5-61 |
| File Allocation Table (FAT)..... | 5-62 |
| Disc Clusters..... | 5-62 |
| FAT Structure..... | 5-62 |
| How to Use the File Allocation Table..... | 5-62 |
| MS-DOS Disc Directory..... | 5-63 |

TABLE OF CONTENTS (Continued)

Section 6 - SYSTEM FIRMWARE

| | |
|--|-----|
| Firmware Memory Map..... | 6-1 |
| RAM..... | 6-1 |
| Firmware Entry Point Jump Vectors..... | 6-1 |

Section 7 - PROGRAMMING THE HP 150

| | |
|--|------|
| Generating Escape Sequences..... | 7-1 |
| Performing MS-DOS System Function Calls..... | 7-2 |
| Making AGIOS Function Calls..... | 7-5 |
| Alphanumeric Display Interfacing..... | 7-8 |
| Alphanumeric Video RAM Structure..... | 7-8 |
| Alpha Video Buffer Format..... | 7-8 |
| Video Row Pointer Table Format..... | 7-9 |
| Row Pointer Formulation..... | 7-9 |
| Line Buffer Format..... | 7-10 |
| Enhancement/Character Set Byte Structure..... | 7-10 |
| Character Code Structure..... | 7-10 |
| Finding Row Pointer Table Origin..... | 7-11 |
| Fetching Row Pointers from the Table..... | 7-12 |
| Placing a Character in Alpha Memory..... | 7-13 |
| Writing to Lines 25, 26, and 27..... | 7-15 |
| Graphics Display Interfacing..... | 7-18 |
| Keyboard Interfacing..... | 7-22 |
| Keycode Mode..... | 7-22 |
| Console RAW/COOKED Mode..... | 7-23 |
| Key Characteristics..... | 7-24 |
| Sample Keyboard Driver..... | 7-25 |
| Flushing the Keyboard Buffer..... | 7-26 |
| Keycode Tables..... | 7-29 |
| Programming Data Communications..... | 7-34 |
| Data Comm Using COM1 and COM2 Logical Devices..... | 7-34 |
| Assigning COM1 and COM2 to Physical Ports..... | 7-34 |
| Opening the COM Devices..... | 7-35 |
| Input from the COM Devices..... | 7-35 |
| Output to the COM Devices..... | 7-36 |
| Closing the COM Devices..... | 7-37 |
| COM Device I/O Example - A Terminal Emulator..... | 7-37 |
| Programmatic Configuration of Data Comm..... | 7-39 |
| Reading the Current Configuration..... | 7-39 |
| Changing the Data Comm Configuration..... | 7-43 |
| Restoring the Original Configuration..... | 7-46 |
| Data Comm Control Functions..... | 7-48 |
| IOCTL Reads for Input..... | 7-48 |
| Special COM Functions Through IOCTL Write Request..... | 7-48 |
| Fast Buffer Send for Output..... | 7-50 |
| HPIB Interfacing..... | 7-52 |
| Limited HPIB Driver Functionality..... | 7-52 |
| Opening the HPIBDEV Device..... | 7-52 |

TABLE OF CONTENTS (Continued)

| | |
|---|------|
| HPIB Control Calls..... | 7-53 |
| MS-DOS IOCTL Function Call..... | 7-53 |
| Control Block Format..... | 7-53 |
| Control Template Format..... | 7-54 |
| Sample Identify Templates..... | 7-56 |
| Sample Read/Write Buffer Templates..... | 7-57 |
| HPIB Interface Example (9111A Graphics Tablet)..... | 7-58 |
| Accessory Card Interfacing..... | 7-65 |
| Memory (Slot) Address Identification..... | 7-65 |
| Section 8 - AGIOS FUNCTION CALL REFERENCE | |
| Syntax Used in the AGIOS Function Calls..... | 8-1 |
| Batch Function Call..... | 8-2 |
| Video Intrinsics..... | 8-4 |
| Define Area..... | 8-5 |
| Write Area..... | 8-5 |
| Clear Area..... | 8-6 |
| Enhance Area..... | 8-6 |
| Read Area..... | 8-6 |
| Shift Area..... | 8-7 |
| Write Line..... | 8-8 |
| Application Softkeys..... | 8-9 |
| Update Softkey Label..... | 8-9 |
| Read Softkey Label..... | 8-9 |
| Display Softkey Labels..... | 8-10 |
| Control Functions..... | 8-11 |
| Execute Two Character Sequence (ESC Char)..... | 8-11 |
| Position Cursor (ESC & a)..... | 8-12 |
| Define Enhancements (ESC & d)..... | 8-13 |
| Cursor Sense Absolute (ESC a)..... | 8-13 |
| Cursor Sense Relative (ESC `)..... | 8-13 |
| Set Cursor Type..... | 8-14 |
| Read Cursor Type..... | 8-14 |
| Read Terminal Configuration..... | 8-14 |
| Touchscreen Functions..... | 8-15 |
| Field Operations..... | 8-15 |
| Row Column Operations..... | 8-16 |
| Define Touch Field (ESC - z g)..... | 8-17 |
| Define Softkey Field (ESC - z s)..... | 8-18 |
| Delete Touch Field (ESC - z d)..... | 8-18 |
| Touchscreen Reset (ESC - z j)..... | 8-18 |
| Set Touch Reporting Mode (ESC - z n)..... | 8-19 |
| Keyboard Intercept..... | 8-20 |
| Define Key Characteristics..... | 8-21 |
| Get Key Characteristics..... | 8-21 |
| Put Key..... | 8-22 |
| Keycode On/Off..... | 8-22 |
| Keycode Status..... | 8-23 |

TABLE OF CONTENTS (Continued)

| | |
|---|------|
| Read Keypad Status..... | 8-23 |
| Display Control (ESC * d)..... | 8-24 |
| Clear Graphics Memory (ESC * d a)..... | 8-24 |
| Set Graphics Memory (ESC * d b)..... | 8-24 |
| Turn On Graphics Display (ESC * d c)..... | 8-24 |
| Turn Off Graphics Display (ESC * d d)..... | 8-25 |
| Turn On Alphanumeric Display (ESC * d e)..... | 8-25 |
| Turn Off Alphanumeric Display (ESC * d f)..... | 8-25 |
| Turn On Graphics Cursor (ESC * d k)..... | 8-25 |
| Turn Off Graphics Cursor (ESC * d l)..... | 8-26 |
| Turn On Rubber Band Line (ESC * d m)..... | 8-26 |
| Turn Off Rubber Band Line (ESC * d n)..... | 8-26 |
| Move Graphics Cursor Absolute (ESC * d <x,y> o)..... | 8-26 |
| Move Graphics Cursor Incremental (ESC * d <x,y> p)..... | 8-27 |
| Turn On Alphanumeric Cursor (ESC * d q)..... | 8-27 |
| Turn Off Alphanumeric Cursor (ESC * d r)..... | 8-27 |
| Turn On Graphics Text Mode (ESC * d s)..... | 8-28 |
| Turn Off Graphics Text Mode (ESC * d t)..... | 8-28 |
| Vector Drawing Mode (ESC * m)..... | 8-29 |
| Select Drawing Mode (ESC * m <mode> a)..... | 8-29 |
| Select Line Type (ESC * m <type> b)..... | 8-29 |
| Define Line Pattern and Scale (ESC * m<pattern><scale>c)..... | 8-30 |
| Define Area Fill Pattern (ESC * m <pattern> d)..... | 8-30 |
| Fill Rectangular Area, Absolute (ESC * m <x1,y1,x2,y2> e)..... | 8-31 |
| Fill Rectangular Area, Absolute Relocatable (ESC * m <x1,y1,x2,y2> f)..... | 8-31 |
| Select Polygonal Fill Pattern (ESC * m <pattern> g)..... | 8-31 |
| Select Boundary Pen (ESC * m <pen> h)..... | 8-32 |
| No Polygon Boundary (ESC * m h)..... | 8-32 |
| Set Relocatable Origin (ESC * m <x,y> j)..... | 8-33 |
| Set Relocatable Origin to Pen Position (ESC * m k)..... | 8-33 |
| Set Relocatable Origin to Cursor Position (ESC * m l)..... | 8-33 |
| Graphics Text (ESC *)..... | 8-34 |
| Set Graphics Text Size Text Size (ESC * m <size> m)..... | 8-34 |
| Set Graphics Text Orientation ((ESC * m <orientation> n)..... | 8-34 |
| Turn On Text Slant (ESC * m o)..... | 8-35 |
| Turn Off Text Slant ((ESC * m p)..... | 8-35 |
| Set Graphics Text Origin (ESC * m <0-9> q)..... | 8-36 |
| Graphics Text Label (ESC * l <text>)..... | 8-36 |
| Define User Character Set..... | 8-37 |
| Select Default Character Set..... | 8-37 |
| Output Single Text Character..... | 8-37 |
| Set Graphics Default (ESC * m r)..... | 8-38 |
| Set Picture Definition Defaults (ESC * m 1 r)..... | 8-39 |
| Graphics Hard Reset (ESC * w r)..... | 8-39 |
| Graphics Plotting (ESC * p)..... | 8-40 |
| Lift Pen (ESC * mp a)..... | 8-40 |
| Vector Move (ESC * p a <x,y>)..... | 8-40 |
| Lower Pen (ESC * p b)..... | 8-41 |

TABLE OF CONTENTS (Continued)

| | |
|--|------|
| Vector Draw (ESC * p b <x,y>) | 8-41 |
| Plot to Cursor Position (ESC * p c) | 8-42 |
| Point Plot (ESC * p d) | 8-42 |
| Set Relocatable Origin to Pen Position (ESC * p e) | 8-42 |
| Start Polygonal Area Fill (ESC * p s) | 8-43 |
| Terminate Polygonal Area Fill (ESC * p t) | 8-43 |
| Polygon Move | 8-43 |
| Polygon Draw | 8-44 |
| Lift Boundary Pen (ESC * p u) | 8-44 |
| Lower Boundary Pen (ESC * p v) | 8-45 |
| Graphics Status (ESC * s) | 8-46 |
| Read Device ID (ESC * s 1) | 8-46 |
| Read Pen Position (ESC * s 2) | 8-46 |
| Read Cursor Position (ESC * s 3) | 8-47 |
| Read Cursor Position, Wait for Key (ESC * s 4) | 8-47 |
| Read Display Size (ESC * s 5) | 8-48 |
| Read Graphics Settings (ESC * s 6) | 8-48 |
| Read Graphics Text Status (ESC * s 7) | 8-49 |
| Read Zoom Status (ESC * s 8) | 8-49 |
| Read Relocatable Origin (ESC * s 9) | 8-50 |
| Read Reset Status (ESC * s 10) | 8-50 |
| Read Area Shading (ESC * s 11) | 8-51 |
| Read Dynamics (ESC * s 12) | 8-51 |
| Read Extended Screen Dimensions | 8-52 |

Appendix A - LOGIC DIAGRAMS

| | |
|---|------|
| Touchscreen PCA | A-1 |
| Keyboard PCA | A-3 |
| Processor PCA | A-5 |
| Processor Front Plane Interface | A-7 |
| Processor I/O Bus | A-9 |
| Processor Datacomm Port | A-11 |
| Video Alpha RAM Subsystem | A-13 |
| Video Alpha Display Subsystem | A-15 |
| Video Graphics Display Subsystem | A-17 |
| Thermal Printer Interface (Part of Front Plane PCA) | A-19 |
| Mezzanine Memory PCA | A-21 |
| Mezzanine Datacomm PCA | A-23 |
| Sweep PCA | A-25 |
| RAM (Memory Extender) PCA | A-27 |
| Language PCA | A-29 |

Appendix B - FURTHER REFERENCE DOCUMENTS