



OP-1

GLOBAL KEYS for selected track

Tap Tempo

Metronome

Volume

Pan

Send 1 Send 2

Bank select

Play

when playing, jumps playback to start position

Punch IN/OUT

Loop

Overdub

Stop

Mute

Solo

Arm

Reset

M/S/A

Record

when stopped, rec+play
when started, stops recording but continues playing ('OP1'!)

Set/unset locator at position

Open/Close Browser

Toggle Arrangement/Session

Undo

Open/Close Detail view

Redo

PERFORM MODE

- Use to shift octave
- Use keyboard to play as usual

CLIP MODE

- Move red box up/down
- Move red box left/right
- Use keys to trigger clips (shift to stop)
- Last key triggers scene (shift to stop all)

TRANSPORT MODE

- Use to move marker or (+shift) locator
- prev track/channel next track/channel

Scrub playback position

Set Quantization

Move playmarker /+press Selection of a song
 Zoom arrangement view /+press Zoom current track

MIXER MODE

- Use to select tracks
- Use numbers to switch directly to track