## 03.106 HSS Emergency O2 Deactivation

(03. HSS Procedure)

#### **OBJECTIVE:**

To deactivate the Emergency O2 Generation System.

# **EQUIPMENT:**

None

## NOTE

In the event of an Oxygen Generation System failure, liquid O2 tanks are onboard and can be used on an emergency basis.

## L1D 1. DEACTIVATE EMERGENCY 02 GENERATION SYSTEM



Figure 1: Emergency O2 Generation System

- 1.1 Flip power switch of Emergency O2 Generation System to "OFF" (see Figure 1).
  - 1.1.1 Confirm Emergency O2 Generation System is off by verifying red light is no longer illuminated.
  - 1.1.2 Confirm Emergency O2 Generation System is off by verifying no audible fan sound.

15-Jul-2021 Page **1** of **1**