



Installation Instructions

Step-by-step guide to install your new smart door lock

1 What's Included

Make sure all of the parts are nearby.

- Motor unit
- Mounting plate
- Exterior unit
- Deadbolt
- Strike box
- Strike plate
- Batteries (4)
- Service pin
- Optional mounting screw
- Mounting plate screws (3)
- Interior unit screws (3)
- Mechanical keys (2)
- Strike and strike box screws (4)
- Installation template

Image: <https://casview.apple.com/view/C0EE17DF-2664-4952-8C0D-BC0C535A89F7?dl=1>

2 Tools Needed

Gather the following tools and keep them with the parts.

- Phillips screwdriver
- Level (Optional)

Image: <https://casview.apple.com/view/143DF5A7-8BF1-4AD6-B847-C69B93663E98?dl=1>

3 How Are You Installing Your Door Lock?

Are you installing your door lock in place of an existing lock?

Use Existing Location → Go to step 4

Choose New Location → Go to step 13

Image: <https://casview.apple.com/view/91C0A2BB-2D79-4654-AC25-44D2FCA55DB3?dl=1>

4 Check Existing Hole Size

1. Detach your existing doorlock from the door.
2. Refer to the included hole size and check whether the existing hole matches the recommended size (NN) for your doorlock.

Continue → Go to step 5

Hole is not the required size → Go to step 13

Image: <https://casview.apple.com/view/4164364C-3D34-42AE-B509-53B857D8D386?dl=1>

5 Install Deadbolt

If the backset—the distance from the edge of the door to the center of the bore hole—is 2.375 in (60.3 mm), use the deadbolt without extending it.

If the backset is 2.75 in (69.9 mm), rotate the deadbolt to extend it before installation.

1. Insert the deadbolt into the hole in the edge of the door.
2. Make sure the TOP marking on the deadbolt faces up.
3. Secure the deadbolt with the provided screws.

Video: <https://casview.apple.com/view/0F55D6DF-540E-436C-AD39-5281540AE66D?dl=1>

6 Install Exterior Unit

1. From the outside of the door, insert the shaft into the opening in the deadbolt.
2. Align the exterior unit with the edge of the door.
3. Make sure the gasket isn't pinched.

Video: <https://casview.apple.com/view/6DFFA8D0-FE9C-4E4D-9631-8803D6751793?dl=1>

7 Install Swivel Pin

The swivel pin limits the keypad to one direction and prevents it from hitting a nearby surface.

1. With the exterior unit aligned, rotate the keypad to check whether it touches the wall or another nearby surface.
2. Insert the swivel pin into the hole on the side where you want to limit the keypad's rotation.
3. Secure the ring to the hook.

Video: <https://casview.apple.com/view/225195F3-62F9-4F45-A574-28D6441473A9?dl=1>

8 Attach Mounting Plate

1. Pull the slide connector out completely.
2. Pass the slide connector through the opening in the mounting plate.
3. Align the two pins on the mounting plate with the holes in the deadbolt.
4. Attach the mounting plate to the deadbolt.
5. Place a level along the top edge of the mounting plate.
6. Adjust the mounting plate until it's horizontal.
7. Fasten the mounting plate with the screws.
8. Secure the mounting plate to the exterior unit with the three mounting plate screws.

Video: <https://casview.apple.com/view/C08B2EAD-0062-4875-93B8-DD57F65D65CC?dl=1>

9 Is the Mounting Plate Still Loose?

Gently move the mounting plate to check whether it's loose.

Yes → Go to step 10

No → Go to step 11

Video: <https://casview.apple.com/view/3AAE53B1-A315-4BB0-931B-E878C9C3764F?dl=1>

10 Secure Mounting Plate

1. Insert the optional mounting screw into the top hole of the mounting plate.
2. Tighten the screw until the mounting plate no longer wobbles.

Video: <https://casview.apple.com/view/762038A1-40CD-4FE5-95EE-2214DD391350?dl=1>

11 Install Interior Unit

1. Press the button at the bottom of the interior unit.
2. Remove the battery cover.
3. Align the slide connector with the connection port on the interior unit.
4. Attach the slide connector securely.
5. Insert the three interior unit screws through the holes in the battery compartment.
6. Tighten the screws.

Video: <https://casview.apple.com/view/FEECFCD4-A7ED-49F5-97BD-772BF4A4D5F2?dl=1>

12 Insert Batteries

1. Insert the four batteries according to the polarity markings in the battery compartment.
2. Wait for the status light on the exterior unit to turn on and for a sound.
3. Press and hold the button at the bottom of the interior unit.
4. Attach the battery cover.

Video: <https://casview.apple.com/view/3D49A0D7-9EC0-40E4-A167-383D9BE79FA3?dl=1>

13 Properly Sized Hole Required

Your door needs a properly sized hole to install your door lock.

If your door doesn't have the required holes, consult a qualified professional installer before continuing.

Image: <https://casview.apple.com/view/52479486-588E-40A6-9BA1-33E01447CCB6?dl=1>