



Installation Instructions

Step-by-step guide to install your new smart thermostat

1 What's Included

Make sure all of the parts are nearby.

- LG Smart Thermostat
- Base plate
- Trim plate
- Wire labels (2)
- Screws (2)
- Anchors (2)

Image: <https://casview.apple.com/view/5381B911-2730-4B17-9653-89DD8F672A6C?dl=1>

2 Tools Needed

Gather the following tools and keep them with the parts.

- Drill
- Drill bit
- Pencil
- Phillips screwdriver
- Pliers
- Hammer

Depending on your wiring, you may need an LG C Wire Adapter.

Image: <https://casview.apple.com/view/99F6CD3E-EFAD-41B7-8F30-A87A3085CBB7?dl=1>

3 Turn Off Power

1. Turn off the power to your HVAC system at the circuit breaker.
2. Turn off your thermostat. If it's battery-operated, the display may not turn off.
3. Remove the cover of your existing thermostat.

Video: <https://casview.apple.com/view/B11AA181-C610-4523-A503-DD18117D8BC6?dl=1>

4 Check Wiring

A C Wire supplies a consistent flow of low-voltage power to thermostats. Look for a wire connected to the C terminal on your existing thermostat.

If there isn't a C Wire, you can use an LG C Wire Adapter with a G Wire.

C and G Wire → Go to step 24

G Wire Only → Go to step 17

Neither C or G Wire → Go to step 35

Image: <https://casview.apple.com/view/C09C494E-1CE1-41BA-9705-8A4AC3404EB2?dl=1>

5 Take Photo of Existing Wiring

Take a photo of the existing wiring so you can reference it later.

This photo will be saved in Photos.

Video: <https://casview.apple.com/view/88F0DCBC-A914-4A35-9D1F-E5464E693181?dl=1>

6 Remove Existing Thermostat

1. Label the wires based on which terminal they're connected to. Attach labels according to the wire designations:

- R → Rc
- W → W1
- Y → Y1
- AUX → W2
- O or B → O/B

2. Disconnect the wires from the thermostat. Make sure the wires do not fall behind the wall.

3. Remove the jumper wire.

4. Remove the base of the thermostat.

Video: <https://casview.apple.com/view/40DB33C5-9589-4A31-9E4A-50D36766A11E?dl=1>

7 Position Base Plate

1. Hold the base plate on the wall where you want your thermostat to be.
2. Use a level to make sure the base plate is straight.
3. Mark two drilling points with a pencil.
4. Drill a hole at each of the marked points. Use anchors to support the screws if needed.

Video: <https://casview.apple.com/view/B3BD7C46-AB02-4C36-82D9-BD097AD84389?dl=1>

8 Cover Marks and Holes with Trim Plate

A trim plate attaches to the base plate to help cover pencil marks, holes, and any visible wall openings. You may need one if your new thermostat is smaller or a different shape than the one you removed.

Use Trim Plate → Go to step 9

Skip → Go to step 13

Image: <https://casview.apple.com/view/D02F4B44-5853-46FA-8C37-20E2E9780F81?dl=1>

9 Install Base and Trim Plate

1. Press the base plate to the back of the trim plate until you hear a click.
2. Thread wires through the center of the base plate.
3. Place a level along the top edge to make sure the plates are straight.
4. Secure the base plate to the wall with the screws. To prevent damage to the base plate, use a Phillips screwdriver or reduce the torque on an electric screwdriver.

Video: <https://casview.apple.com/view/BA8E51E1-0E28-4D04-B985-2B8672D10400?dl=1>

10 Connect Wires

1. If any wires are bent, straighten them with pliers.
2. Connect each labeled wire to the corresponding terminal.
3. Tug each wire gently to make sure it's secure.
4. Wire colors may vary depending on your HVAC installation.

Video: <https://casview.apple.com/view/F459B353-6521-4A71-9BB2-50FA177C9776?dl=1>

11 Attach Thermostat

1. Tuck the wires back into the wall.
2. Align the pins on the back of your thermostat with the slots on the base plate.
3. Press your thermostat onto the base plate until you hear a click.
Do not force the thermostat, as this can damage it.

Video: <https://casview.apple.com/view/70867CFD-5A10-4D76-BB02-175F481CE7BF?dl=1>

12 Turn On Power

1. Turn on the power to your HVAC system at the circuit breaker.
2. Once the power is restored, the thermostat will be ready to set up.

Video: <https://casview.apple.com/view/45DE2260-E4C8-4682-850A-A01251E9C290?dl=1>

13 Install Base Plate

1. Thread the wires through the center of the base plate.
2. Secure the base plate to the wall with the screws. To prevent damage to the base plate, use a Phillips screwdriver or reduce the torque on an electric screwdriver.

Video: <https://casview.apple.com/view/A14C8B7E-F0CF-4604-A5BA-957AD19C21E4?dl=1>

14 Connect Wires

1. If any wires are bent, straighten them with pliers.
2. Connect each labeled wire to the corresponding terminal.
3. Tug each wire gently to make sure it's secure.
4. Wire colors may vary depending on your HVAC installation.

Video: <https://casview.apple.com/view/F459B353-6521-4A71-9BB2-50FA177C9776?dl=1>

15 Attach Thermostat

1. Tuck the wires back into the wall.
2. Align the pins on the back of your thermostat with the slots on the base plate.
3. Press your thermostat onto the base plate until you hear a click.
Do not force the thermostat, as this can damage it.

Video: <https://casview.apple.com/view/09F29E2B-17D1-4C0A-93E8-5E6D381DB5AD?dl=1>

16 Turn On Power

1. Turn on the power to your HVAC system at the circuit breaker.
2. Once the power is restored, the thermostat will be ready to set up.

Video: [video/default](#)

17 LG Thermostat C Wire Adapter Required

An LG Thermostat C wire Adapter is required to finish installing your thermostat.
If needed, you can pause setup and continue once you have this adapter.

Image: <https://casview.apple.com/view/82FB2BD7-9BB1-4AC8-838B-784010BDB082?dl=1>

18 Turn Off the HVAC Power

Turn off the power to your HVAC system.
Most HVAC systems have the power supply nearby.

Video: <https://casview.apple.com/view/8E554468-2F2C-4F36-B171-012145B49872?dl=1>

19 Take Photo of HVAC Wiring

1. Open the HVAC control board.
2. Take a photo of the existing wiring so you can reference it later.

This photo will be saved in Photos.

Video: <https://casview.apple.com/view/D18B5DD9-5F76-41CF-B386-B243579CD654?dl=1>

20 Label and Disconnect Wires

1. Label the wires based on which terminal they're connected to on the HVAC control board.
2. Disconnect the wires.

Video: <https://casview.apple.com/view/27ECA4C8-5CF5-426F-81D2-8CB52403DC64?dl=1>

21 Install the C Wire Adapter

1. Open the cover of the C wire Adapter.
2. Connect the wires on the HVAC control board to the corresponding terminals on the C wire Adapter.
3. Tug each wire gently to make sure it's secure.

Video: <https://casview.apple.com/view/4FAD87EA-4ACB-4BFB-A940-DE867563D39A?dl=1>

22 Connect C wire Adapter Harness

1. If any wires are bent, straighten them with pliers.
2. Connect the adapter harness to the corresponding terminals on the HVAC control board.
3. Close the adapter cover.

Video: <https://casview.apple.com/view/773814DA-5869-46A5-8465-86AD50EB6199?dl=1>

23 Turn On the HVAC Power

1. Turn on the power back on at the power supply near the HVAC system.
2. Continue installation on your thermostat.

Video: <https://casview.apple.com/view/45DE2260-E4C8-4682-850A-A01251E9C290?dl=1>

24 Take Photo of Existing Wiring

Take a photo of the existing wiring so you can reference it later.

This photo will be saved in Photos.

Video: <https://casview.apple.com/view/88F0DCBC-A914-4A35-9D1F-E5464E693181?dl=1>

25 Remove Existing Thermostat

1. Label the wires based on which terminal they're connected to. Attach labels according to the wire designations:

- R → Rc
- W → W1
- Y → Y1
- AUX → W2
- O or B → O/B

2. Disconnect the wires from the thermostat. Make sure the wires do not fall behind the wall.

3. Remove the jumper wire.

4. Remove the base of the thermostat.

Video: <https://casview.apple.com/view/40DB33C5-9589-4A31-9E4A-50D36766A11E?dl=1>

26 Position Base Plate

1. Hold the base plate on the wall where you want your thermostat to be.

2. Use a level to make sure the base plate is straight.

3. Mark two drilling points with a pencil.

4. Drill a hole at each of the marked points. Use anchors to support the screws if needed.

Video: <https://casview.apple.com/view/B3BD7C46-AB02-4C36-82D9-BD097AD84389?dl=1>

27 Cover Marks and Holes with Trim Plate

A trim plate attaches to the base plate to help cover pencil marks, holes, and any visible wall openings. You may need one if your new thermostat is smaller or a different shape than the one you removed.

Use Trim Plate → Go to step 28

Skip → Go to step 31

Image: <https://casview.apple.com/view/D02F4B44-5853-46FA-8C37-20E2E9780F81?dl=1>

28 Install Base and Trim Plate

1. Press the base plate to the back of the trim plate until you hear a click.
2. Thread wires through the center of the base plate.
3. Place a level along the top edge to make sure the plates are straight.
4. Secure the base plate to the wall with the screws. To prevent damage to the base plate, use a Phillips screwdriver or reduce the torque on an electric screwdriver.

Video: <https://casview.apple.com/view/BA8E51E1-0E28-4D04-B985-2B8672D10400?dl=1>

29 Connect Wires

1. If any wires are bent, straighten them with pliers.
2. Connect the G wire to the C terminal and the Y wire to the PEK terminal.
3. Connect each labeled wire to the corresponding terminal.
4. Tug each wire gently to make sure it's secure.
5. Wire colors may vary depending on your HVAC installation.

Video: <https://casview.apple.com/view/7D9FCE12-607A-45B3-8086-4FACEE72A013?dl=1>

30 Attach Thermostat

1. Tuck the wires back into the wall.
2. Align the pins on the back of your thermostat with the slots on the base plate.
3. Press your thermostat onto the base plate until you hear a click.
Do not force the thermostat, as this can damage it.

Video: <https://casview.apple.com/view/70867CFD-5A10-4D76-BB02-175F481CE7BF?dl=1>

31 Install Base Plate

1. Thread the wires through the center of the base plate.
2. Secure the base plate to the wall with the screws. To prevent damage to the base plate, use a Phillips screwdriver or reduce the torque on an electric screwdriver.

Video: <https://casview.apple.com/view/A14C8B7E-F0CF-4604-A5BA-957AD19C21E4?dl=1>

32 Connect Wires

1. If any wires are bent, straighten them with pliers.
2. Connect the G wire to the C terminal and the Y wire to the PEK terminal.
3. Connect each labeled wire to the corresponding terminal.
4. Tug each wire gently to make sure it's secure.
5. Wire colors may vary depending on your HVAC installation.

Video: <https://casview.apple.com/view/0B922298-25C6-41D2-8F3F-67122C75CD0C?dl=1>

33 Attach Thermostat

1. Tuck the wires back into the wall.
2. Align the pins on the back of your thermostat with the slots on the base plate.
3. Press your thermostat onto the base plate until you hear a click.

Do not force the thermostat, as this can damage it.

Video: <https://casview.apple.com/view/09F29E2B-17D1-4C0A-93E8-5E6D381DB5AD?dl=1>

34 Turn On Power

1. Turn on the power to your HVAC system at the circuit breaker.
2. Once the power is restored, the thermostat will be ready to set up.

Video: <https://casview.apple.com/view/16FA26B8-C4EB-469E-9333-6DB06935E491?dl=1>

35 C or G Wire Required

Your thermostat requires a C or G wire for power.

You can pause setup until an electrician wires your home and then pick up where you left off.

Image: <https://casview.apple.com/view/40397103-F233-4539-9201-8B52AC33B766?dl=1>