

Schneider Electric



No Asset

# Installation Instructions

Step-by-step guide to install your accessory

## 1 What You Need

Ensure your old thermostat and HVAC system are working correctly. You will need a Phillips screwdriver, drill and level.

Optional tools include pliers, pencil and wire strippers.

Estimated Time Needed: 30 Minutes.

Image: What\_you\_need

## 2 Power Off System

For your safety, power off your thermostat and your heating and cooling system.

Switch off the circuit breaker in the electrical panel. Make sure there is no power flowing to the old thermostat.

If at any point you are unsure, stop right away and contact a professional electrician to finish the installation.

Image: Power\_off

## 3 Hazard of Electric Shock

Make sure the power is completely off before continuing.

Failure to do so can result in death or serious injury.

Acknowledge & Confirm → Go to step 4

Cancel → Go to step 4

Image: Power\_off

## 4 Remove Old Thermostat

Carefully pull off or unscrew the front plate of the thermostat from the wall mount.

Image: Power\_off

## 5 Take a Photo

Take a clear photo of existing wiring configuration and terminals. You'll need to refer to it later to match the wiring system of your new thermostat.

Image: remove\_photo

## 6 Check Compatibility

High voltage wires may look like thick red, black, or other color wires. Some older systems, like baseboard heating, use them. These systems won't work with smart thermostats.

Can you confirm there are no high-voltage wires?

Yes → Go to step 7

No → Go to step 9

Image: high\_voltage\_video

Video: high\_voltage\_video

## 7 Check Compatibility

Packaged Terminal Air Conditioning (PTAC) are typically all-in-one units installed in walls or under windows. They can also be known as Through-The-Wall AC unit.

Can you confirm that you have no PTAC?

Yes → Go to step 8

No → Go to step 9

Image: ptac\_system

## 8 Check Compatibility

The C wire, or common wire, provides a constant 24-volt AC power supply to your thermostat. It may be colored blue.

If you don't see it, the unused C wire might be wrapped with the other wiring in your wall.

Do you have a C wire?

Yes → Go to step 10

No → Go to step 9

Image: c\_wire

## 9 Thermostat Incompatible

Unfortunately if you have high voltage wires or a PTAC system or a lack of a C wire, you should not continue with the thermostat installation.

Contact your nearest electrician to help you install your thermostat.

Go to <insert URL link>

## 10 Label Wires

If your wires are already labelled, please proceed.

Otherwise you may choose to use the label stickers or refer to the photo you have taken to identify the wires later on.

Image: label\_wires

## 11 Remove Old Wall Mount

Disconnect the wires carefully then remove any jumper wires (short wires connecting two terminals, typically R to RC or R to RH), followed by the old wall mount.

Image: remove\_wall\_mount

## 12 Review Wire Conditions

Before you continue, be sure your wires are not damaged.

This shows an example of wires that are notched.

You do not have damaged wires, correct?

Yes → Go to step 13

No → Go to step 14

Image: trim\_plate

## 13 Thermostat Trim Plate

Are you installing without the optional Thermostat Trim Plate?

Yes → Go to step 14

No, I have the Trim Plate → Go to step 14

Image: trim\_plate

## 14 Attach Wall Mount

Pull all wires through the wall and secure them so they don't slip back in.

Drill holes, then use a screwdriver to securely attach the wall mount with the new screws.

Image: attach\_wall

## 15 Reconnect Wires

Connect each wire to its correct terminal.

Compare your new wiring with the photo of the old wall mount and wiring.

Do they match accordingly?

Yes → Go to step 16

No → Go to step 14

Image: reconnect

## 16 Jumper Wires

Do you have wires connected to the following terminals in any of these combinations:

I Don't Have Them → Go to step 17

R & RC → Go to step 18

R/RC & U-R → Go to step 19

R & RC & U-R → Go to step 20

Image: jumper

## 17 How To Match Wires

Use your old thermostat terminal labels to match each wire to the new terminals:

4 / W / W1 / H1 / E / E1 → W/AUX terminal

5 / R / RH / R4 / VR → R terminal

6 / F / G / G1 / GL → G terminal

C / C1 / X / V → C terminal

A / DH / H / HD / HMD / E2 / M → U terminal

AUX-R / RU / RA → U-R terminal

B / H2 / O / W2 / \* → W2/OB terminal

GH / G2 / H2 / Y2 → Y2/G2 terminal

Y / Y1 → Y terminal

RC → RC terminal

Note:

AUX (Stage 1 AUX Heat) / H1 (Stage 1 Heating) → W/AUX terminal

AUX (Humidifier or Dehumidifier or A-valve or Stage 2 AUX Heat) / H1 (Humidifier 1) → U terminal

## 18 R & RC Connector

If you have R & RC wires, your U terminal accessory is powered separately from your heating and cooling.

Locate the jumper block on the back of the thermostat and shift it from R + RC position (right) to OFF position (left).

Reinsert the jumper block.

Image: jumper

Video: jumper\_video

## 19 R RC & U-R Connector

If you have R RC & U-R wires, your U terminal accessory is powered separately from your heating and cooling.

Locate the jumper block on the back of the thermostat and shift it from U-R position (right) to OFF position (left).

Reinsert the jumper block.

Image: jumper

Video: jumper\_video

## 20 R & Rc, R & U-R Wires

If you have R & Rc and R & U-R wires, you have fully independent transformers.

Locate the jumper block on the back of the thermostat and shift it from both U-R & R + RC position (right) to OFF position (left).

Reinsert the jumper block.

Image: jumper

Video: jumper\_video

## 21 Attach Thermostat

Align the thermostat with the wall plate.

Press firmly until it clicks into place.

Image: attach\_new

## 22 Restore Power & Pair

Turn your HVAC system power back on. It should display “Finish setup in your mobile app”.

Image: power\_pair