RISC-V External Debug Support Version 0.14.0-DRAFT 09788a8ce324e13e8cd243c013f122ebaea11928

Editors:

Ernie Edgar <ernie.edgar@sifive.com>, SiFive, Inc.
Tim Newsome <tim@sifive.com>, SiFive, Inc.

Wed Jul 29 10:58:07 2020 -0700

Contributors to all versions of the spec in alphabetical order (please contact editors to suggest corrections): Bruce Ableidinger, Krste Asanović, Peter Ashenden, Allen Baum, Mark Beal, Alex Bradbury, Chuanhua Chang, Zhong-Ho Chen, Monte Dalrymple, Paul Donahue, Vyacheslav Dyachenko, Peter Egold, Marc Gauthier, Markus Goehrle, Robert Golla, John Hauser, Richard Herveille, Yungching Hsiao, Po-wei Huang, Scott Johnson, L. J. Madar, Grigorios Magklis, Kai Meinhard, Jean-Luc Nagel, Aram Nahidipour, Rishiyur Nikhil, Gajinder Panesar, Deepak Panwar, Antony Pavlov, Klaus Kruse Pedersen, Ken Pettit, Joe Rahmeh, Gavin Stark, Wesley Terpstra, Megan Wachs, Jan-Willem van de Waerdt, Stefan Wallentowitz, Ray Van De Walker, Andrew Waterman, Andy Wright, and Bryan Wyatt.

Preface

Warning! This draft specification will change before being accepted as standard, so implementations made to this draft specification will likely not conform to the future standard.

Contents

P	refac	ee ee	i
1	Intr	roduction	1
	1.1	Terminology	1
		1.1.1 Context	2
		1.1.2 Versions	2
	1.2	About This Document	2
		1.2.1 Structure	2
		1.2.2 Register Definition Format	2
		1.2.2.1 Long Name (shortname, at 0x123)	3
	1.3	Background	3
	1.4	Supported Features	4
2	Sys	stem Overview	5
3	Deb	bug Module (DM)	7
	3.1	Debug Module Interface (DMI)	8
	3.2	Reset Control	8
	3.3	Selecting Harts	9
		3.3.1 Selecting a Single Hart	9
		3.3.2 Selecting Multiple Harts	9
	3.4	Hart DM States	10

$RISC$ - V $Ext\epsilon$	ernal Debug	Support	Version	0.14.0-D	RAFT
----------------------------	-------------	---------	---------	----------	------

iii

3.5	Run Control	10
3.6	Halt Groups, Resume Groups, and External Triggers	11
3.7	Abstract Commands	12
	3.7.1 Abstract Command Listing	13
	3.7.1.1 Access Register	13
	3.7.1.2 Quick Access	15
	3.7.1.3 Access Memory	16
3.8	Program Buffer	17
3.9	Overview of Hart Debug States	18
3.10	System Bus Access	18
3.11	Minimally Intrusive Debugging	20
3.12	Security	20
3.13	Version Detection	21
3.14	Debug Module Registers	21
	3.14.1 Debug Module Status (dmstatus, at 0x11)	22
	3.14.2 Debug Module Control (dmcontrol, at 0x10)	24
	3.14.3 Hart Info (hartinfo, at 0x12)	27
	3.14.4 Hart Array Window Select (hawindowsel, at 0x14)	28
	3.14.5 Hart Array Window (hawindow, at 0x15)	29
	3.14.6 Abstract Control and Status (abstractcs, at 0x16)	29
	3.14.7 Abstract Command (command, at 0x17)	30
	3.14.8 Abstract Command Autoexec (abstractauto, at 0x18)	31
	3.14.9 Configuration String Pointer 0 (confstrptr0, at 0x19)	31
	3.14.10 Configuration String Pointer 1 (confstrptr1, at 0x1a)	32
	3.14.11 Configuration String Pointer 2 (confstrptr2, at 0x1b)	32
	3.14.12 Configuration String Pointer 3 (confstrptr3, at 0x1c)	32
	3.14.13 Next Debug Module (nextdm, at 0x1d)	33
	3.14.14 Abstract Data 0 (data0, at 0x04)	33

		3.14.15 Program Buffer 0 (progbuf0, at 0x20)	33
		3.14.16 Authentication Data (authdata, at 0x30)	34
		3.14.17 Debug Module Control and Status 2 (dmcs2, at 0x32)	34
		3.14.18 Halt Summary 0 (haltsum0, at 0x40)	35
		3.14.19 Halt Summary 1 (haltsum1, at 0x13)	36
		3.14.20 Halt Summary 2 (haltsum2, at 0x34)	36
		3.14.21 Halt Summary 3 (haltsum3, at 0x35)	36
		3.14.22 System Bus Access Control and Status (sbcs, at 0x38)	37
		3.14.23 System Bus Address 31:0 (sbaddress0, at 0x39)	38
		3.14.24 System Bus Address 63:32 (sbaddress1, at 0x3a)	39
		3.14.25 System Bus Address 95:64 (sbaddress2, at 0x3b)	39
		3.14.26 System Bus Address 127:96 (sbaddress3, at 0x37)	40
		3.14.27 System Bus Data 31:0 (sbdata0, at 0x3c)	40
		3.14.28 System Bus Data 63:32 (sbdata1, at 0x3d)	41
		3.14.29 System Bus Data 95:64 (sbdata2, at 0x3e)	42
		3.14.30 System Bus Data 127:96 (sbdata3, at 0x3f)	42
		3.14.31 Custom Features (custom, at 0x1f)	42
		3.14.32 Custom Features 0 (custom0, at 0x70)	42
		3.14.33 Custom Features 15 (custom15, at 0x7f)	43
4	RIS	C-V Debug	44
	4.1	Debug Mode	44
	4.2	Load-Reserved/Store-Conditional Instructions	45
	4.3	Wait for Interrupt Instruction	45
	4.4	Single Step	45
		4.4.1 Step Bit In Dcsr	45
		4.4.2 Icount Trigger	46
	4.5	Reset	46

RI	SC-V	External Debug Support Version 0.14.0-DRAFT	,
	4.6	Resume	46
	4.7	dret Instruction	47
	4.8	XLEN	47
	4.9	Core Debug Registers	47
		4.9.1 Debug Control and Status (dcsr, at 0x7b0)	47
		4.9.2 Debug PC (dpc, at 0x7b1)	5(
		4.9.3 Debug Scratch Register 0 (dscratch0, at 0x7b2)	5(
		4.9.4 Debug Scratch Register 1 (dscratch1, at 0x7b3)	50
	4.10	Virtual Debug Registers	5(
		4.10.1 Privilege Level (priv, at virtual)	51
5	Trig	ger Module	52
	5.1	Enumeration	52
	5.2	Actions	53
	5.3	Priority	53
	5.4	Native M-Mode Triggers	54
	5.5	Trigger Registers	55
6	Deb	oug Transport Module (DTM)	56
	6.1	JTAG Debug Transport Module	56
		6.1.1 JTAG Background	56
		6.1.2 JTAG DTM Registers	57
		6.1.3 IDCODE (at 0x01)	57
		6.1.4 DTM Control and Status (dtmcs, at 0x10)	58
		6.1.5 Debug Module Interface Access (dmi, at 0x11)	59
		6.1.6 BYPASS (at 0x1f)	60
		6.1.7 Recommended JTAG Connector	61

	A.1	Abstract Command Based	63
	A.2	Execution Based	63
	A.3	Debug Module Interface Signals	64
В	Deb	ugger Implementation	66
	B.1	Debug Module Interface Access	66
	B.2	Checking for Halted Harts	67
	B.3	Halting	67
	B.4	Running	67
	B.5	Single Step	67
	B.6	Accessing Registers	67
		B.6.1 Using Abstract Command	67
		B.6.2 Using Program Buffer	68
	B.7	Reading Memory	68
		B.7.1 Using System Bus Access	68
		B.7.2 Using Program Buffer	69
		B.7.3 Using Abstract Memory Access	70
	B.8	Writing Memory	71
		B.8.1 Using System Bus Access	71
		B.8.2 Using Program Buffer	71
		B.8.3 Using Abstract Memory Access	72
	B.9	Triggers	73
	B.10	Handling Exceptions	74
	B.11	Quick Access	74
In	dex		75
\mathbf{C}	Cha	nge Log	75

List of Figures

2.1	RISC-V Debug System Overview	 		•	•			•		•	•	 	•	•	6
3.1	Run/Halt Debug State Machine.							_							19

List of Tables

1.2	Register Access Abbreviations	3
3.1	Use of Data Registers	12
3.2	Meaning of cmdtype	13
3.3	Abstract Register Numbers	14
3.7	System Bus Data Bits	20
3.8	Debug Module Debug Bus Registers	22
4.1	Core Debug Registers	47
4.3	Virtual address in DPC upon Debug Mode Entry	50
4.5	Privilege Level Encoding	51
4.4	Virtual Core Debug Registers	51
5.1	encoding	53
5.2	Synchronous exception priority in decreasing priority order	54
6.1	JTAG DTM TAP Registers	57
6.5	MIPI-10 Connector Diagram	61
6.6	MIPI-20 Connector Diagram	61
6.7	JTAG Connector Pinout	62
A.1	Signals for the suggested DMI between one DTM and one DM	65

Chapter 1

Introduction

When a design progresses from simulation to hardware implementation, a user's control and understanding of the system's current state drops dramatically. To help bring up and debug low level software and hardware, it is critical to have good debugging support built into the hardware. When a robust OS is running on a core, software can handle many debugging tasks. However, in many scenarios, hardware support is essential.

This document outlines a standard architecture for external debug support on RISC-V platforms. This architecture allows a variety of implementations and tradeoffs, which is complementary to the wide range of RISC-V implementations. At the same time, this specification defines common interfaces to allow debugging tools and components to target a variety of platforms based on the RISC-V ISA.

System designers may choose to add additional hardware debug support, but this specification defines a standard interface for common functionality.

1.1 Terminology

A platform is a single integrated circuit consisting of one or more components. Some components may be RISC-V cores, while others may have a different function. Typically they will all be connected to a single system bus. A single RISC-V core contains one or more hardware threads, called harts.

DXLEN of a hart is its widest supported XLEN, ignoring the current value of MXL in misa.

A physical address is directly usable on the system bus.

A virtual address is an address as a hart sees it. If there is address translation this may be different from the physical address. If there is no translation then it will be the same.

1.1.1 Context

This document is written to work with:

- 1. The RISC-V Instruction Set Manual, Volume I: User-Level ISA, Document Version 2.2 (the ISA Spec)
- 2. The RISC-V Instruction Set Manual, Volume II: Privileged Architecture, Version 1.10 (the Privileged Spec)

1.1.2 Versions

Version 0.13 of this document was ratified by the RISC-V Foundation's board. Versions 0.13.x are bug fix releases to that ratified specification.

Version 0.14 will be forwards and backwards compatible with Version 0.13.

1.2 About This Document

1.2.1 Structure

This document contains two parts. The main part of the document is the specification, which is given in the numbered sections. The second part of the document is a set of appendices. The information in the appendices is intended to clarify and provide examples, but is not part of the actual specification.


1.2.2 Register Definition Format

All register definitions in this document follow the format shown below. A simple graphic shows which fields are in the register. The upper and lower bit indices are shown to the top left and top right of each field. The total number of bits in the field are shown below it.

After the graphic follows a table which for each field lists its name, description, allowed accesses, and reset value. The allowed accesses are listed in Table 1.2. The reset value is either a constant or "Preset." The latter means it is an implementation-specific legal value.

Names of registers and their fields are hyperlinks to their definition, and are also listed in the index on page 75.

1.2.2.1 Long Name (shortname, at 0x123)



Field	Description	Access	Reset
field	Description of what this field is used for.	R/W	15

Table 1.2: Register Access Abbreviations

R	Read-only.
R/W	Read/Write.
R/W1C	Read/Write Ones to Clear. Writing 0 to every bit has
	no effect. Writing 1 to every bit clears the field. The
	result of other writes is undefined.
WARZ	Write any, read zero. A debugger may write any
	value. When read this field returns 0.
W1	Write-only. Only writing 1 has an effect. When read
	the returned value should be 0.
WARL	Write any, read legal. A debugger may write any
	value. If a value is unsupported, the implementation
	converts the value to one that is supported.

1.3 Background

There are several use cases for dedicated debugging hardware, both internal to a CPU core and with an external connection. This specification addresses the use cases listed below. Implementations can choose not to implement every feature, which means some use cases might not be supported.

- Debugging low-level software in the absence of an OS or other software.
- Debugging issues in the OS itself.
- Bootstrapping a system to test, configure, and program components before there is any executable code path in the system.
- Accessing hardware on a system without a working CPU.

In addition, even without a hardware debugging interface, architectural support in a RISC-V CPU can aid software debugging and performance analysis by allowing hardware triggers and breakpoints.

1.4 Supported Features

The debug interface described in this specification supports the following features:

- 1. All hart registers (including CSRs) can be read/written.
- 2. Memory can be accessed either from the hart's point of view, through the system bus directly, or both.
- 3. RV32, RV64, and future RV128 are all supported.
- 4. Any hart in the platform can be independently debugged.
- 5. A debugger can discover almost verything it needs to know itself, without user configuration.
- 6. Each hart can be debugged from the very first instruction executed.
- 7. A RISC-V hart can be halted when a software breakpoint instruction is executed.
- 8. Hardware single-step can execute one instruction at a time.
- 9. Debug functionality is independent of the debug transport used.
- 10. The debugger does not need to know anything about the microarchitecture of the harts it is debugging.
- 11. Arbitrary subsets of harts can be halted and resumed simultaneously. (Optional)
- 12. Arbitrary instructions can be executed on a halted hart. That means no new debug functionality is needed when a core has additional or custom instructions or state, as long as there exist programs that can move that state into GPRs. (Optional)
- 13. Registers can be accessed without halting. (Optional)
- 14. A running hart can be directed to execute a short sequence of instructions, with little overhead. (Optional)
- 15. A system bus master allows memory access without involving any hart. (Optional)
- 16. A RISC-V hart can be halted when a trigger matches the PC, read/write address/data, or an instruction opcode. (Optional)
- 17. Harts can be grouped, and harts in the same group will all halt when any of them halts. These groups can also react to or notify external triggers. (Optional)

This document does not suggest a strategy or implementation for hardware test, debugging or error detection techniqes. Scan, BIST, etc. are out of scope of this specification, but this specification does not intend to limit their use in RISC-V systems.

It is possible to debug code that uses software threads, but there is no special debug support for it.

¹Notable exceptions include information about the memory map and peripherals.

Chapter 2

System Overview

Figure 2.1 shows the main components of External Debug Support. Blocks shown in dotted lines are optional.

The user interacts with the Debug Host (e.g. laptop), which is running a debugger (e.g. gdb). The debugger communicates with a Debug Translator (e.g. OpenOCD, which may include a hardware driver) to communicate with Debug Transport Hardware (e.g. Olimex USB-JTAG adapter). The Debug Transport Hardware connects the Debug Host to the Platform's Debug Transport Module (DTM). The DTM provides access to one or more Debug Modules (DMs) using the Debug Module Interface (DMI).

Each hart in the platform is controlled by exactly one DM. Harts may be heterogeneous. There is no further limit on the hart-DM mapping, but usually all harts in a single core are controlled by the same DM. In most platforms there will only be one DM that controls all the harts in the platform.

DMs provide run control of their harts in the platform. Abstract commands provide access to GPRs. Additional registers are accessible through abstract commands or by writing programs to the optional Program Buffer.

The Program Buffer allows the debugger to execute arbitrary instructions on a hart. This mechanism can also be used to access memory. An optional system bus access block allows memory accesses without using a RISC-V hart to perform the access.

Each RISC-V hart may implement a Trigger Module. When trigger conditions are met, harts will halt and inform the debug module that they have halted.



Figure 2.1: RISC-V Debug System Overview

Chapter 3

Debug Module (DM)

The Debug Module implements a translation interface between abstract debug operations and their specific implementation. It might support the following operations:

- 1. Give the debugger necessary information about the implementation. (Required)
- 2. Allow any individual hart to be halted and resumed. (Required)
- 3. Provide status on which harts are halted. (Required)
- 4. Provide abstract read and write access to a halted hart's GPRs. (Required)
- 5. Provide access to a reset signal that allows debugging from the very first instruction after reset. (Required)
- 6. Provide a mechanism to allow debugging harts immediately out of reset (regardless of the reset cause). (Optional)
- 7. Provide abstract access to non-GPR hart registers. (Optional)
- 8. Provide a Program Buffer to force the hart to execute arbitrary instructions. (Optional)
- 9. Allow multiple harts to be halted, resumed, and/or reset at the same time. (Optional)
- 10. Allow memory access from a hart's point of view. (Optional)
- 11. Allow direct System Bus Access. (Optional)
- 12. Group harts. When any hart in the group halts, they all halt. (Optional)
- 13. Respond to external triggers by halting each hart in a configured group. (Optional)
- 14. Signal an external trigger when a hart in a group halts. (Optional)

In order to be compliant with this specification an implementation must:

- 1. Implement all the required features listed above.
- 2. Implement at least one of Program Buffer, System Bus Access, or Abstract Access Memory command mechanisms.
- 3. Do at least one of:
 - (a) Implement the Program Buffer.
 - (b) Implement abstract access to all registers that are visible to software running on the hart including all the registers that are present on the hart and listed in Table 3.3.
 - (c) Implement abstract access to at least all GPRs, dcsr, and dpc, and advertise the implementation as conforming to the "Minimal RISC-V Debug Specification 0.14.0-DRAFT",

instead of the "RISC-V Debug Specification 0.14.0-DRAFT".

A single DM can debug up to 2^{20} harts.

3.1 Debug Module Interface (DMI)

Debug Modules are slaves to a bus called the Debug Module Interface (DMI). The master of the bus is the Debug Transport Module(s). The Debug Module Interface can be a trivial bus with one master and one slave (see A.3), or use a more full-featured bus like TileLink or the AMBA Advanced Peripheral Bus. The details are left to the system designer.

The DMI uses between 7 and 32 address bits. It supports read and write operations. The bottom of the address space is used for the first (and usually only) DM. Extra space can be used for custom debug devices, other cores, additional DMs, etc. If there are additional DMs on this DMI, the base address of the next DM in the DMI address space is given in nextdm.

The Debug Module is controlled via register accesses to its DMI address space.

3.2 Reset Control

There are two methods that allow a debugger to reset harts. ndmreset resets all the harts in the system, as well as all other parts of the system except for the Debug Modules, Debug Transport Modules, and Debug Module Interface. Exactly what is affected by this reset is implementation dependent, but it must be possible to debug programs from the first instruction executed. hartreset resets all the currently selected harts. In this case an implementation may reset more harts than just the ones that are selected. The debugger can discover which other harts are reset (if any) by selecting them and checking anyhavereset and allhavereset.

To perform either of these resets, the debugger first asserts the bit, and then clears it. The actual reset may start as soon as the bit is asserted, but may start an arbitrarily long time after the bit is deasserted. The reset itself may also take an arbitrarily long time. While the reset is on-going, harts are either in the running state, indicating it's possible to perform some abstract commands during this time, or in the unavailable state, indicating it's not possible to perform any abstract commands during this time. Once a hart's reset is complete, havereset becomes set. When a hart comes out of reset and haltred or resethaltred are set, the hart will immediately enter Debug Mode (halted state). Otherwise, if the hart was initially running it will execute normally (running state) and if the hart was initially halted it should now be running but may be halted.

There is no general, reliable way for the debugger to know when reset has actually begun.

The Debug Module's own state and registers should only be reset at power-up and while dmactive in dmcontrol is 0. If there is another mechanism to reset the DM, this mechanism must also reset all the harts accessible to the DM.

Due to clock and power domain crossing issues, it may not be possible to perform arbitrary DMI

accesses across system reset. While ndmreset or any external reset is asserted, the only supported DM operations are reading and writing dmcontrol. The behavior of other accesses is undefined.

When harts have been reset, they must set a sticky havereset state bit. The conceptual havereset state bits can be read for selected harts in anyhavereset and allhavereset in dmstatus. These bits must be set regardless of the cause of the reset. The havereset bits for the selected harts can be cleared by writing 1 to ackhavereset in dmcontrol. The havereset bits may or may not be cleared when dmactive is low.

3.3 Selecting Harts

Up to 2^{20} harts can be connected to a single DM. The debugger selects a hart, and then subsequent halt, resume, reset, and debugging commands are specific to that hart.

To enumerate all the harts, a debugger must first determine HARTSELLEN by writing all ones to hartsel (assuming the maximum size) and reading back the value to see which bits were actually set. Then it selects each hart starting from 0 until either anynonexistent in dmstatus is 1, or the highest index (depending on HARTSELLEN) is reached.

The debugger can discover the mapping between hart indices and mhartid by using the interface to read mhartid, or by reading the system's configuration string.

3.3.1 Selecting a Single Hart

All debug modules must support selecting a single hart. The debugger can select a hart by writing its index to hartsel. Hart indexes start at 0 and are contiguous until the final index.

3.3.2 Selecting Multiple Harts

Debug Modules may implement a Hart Array Mask register to allow selecting multiple harts at once. The nth bit in the Hart Array Mask register applies to the hart with index n. If the bit is 1 then the hart is selected. Usually a DM will have a Hart Array Mask register exactly wide enough to select all the harts it supports, but it's allowed to tie any of these bits to 0.

The debugger can set bits in the hart array mask register using hawindowsel and hawindow, then apply actions to all selected harts by setting hasel. If this feature is supported, multiple harts can be halted, resumed, and reset simultaneously. The state of the hart array mask register is not affected by setting or clearing hasel.

Only the actions initiated by dmcontrol can apply to multiple harts at once, Abstract Commands apply only to the hart selected by hartsel.

3.4 Hart DM States

Every hart that can be selected is in exactly one of the following four DM states: non-existent, unavailable, running, or halted. Which state the selected harts are in is reflected by allnonexistent, anynonexistent, allunavail, anyunavail, allrunning, anyrunning, allhalted, and anyhalted.

Harts are nonexistent if they will never be part of this system, no matter how long a user waits. E.g. in a simple single-hart system only one hart exists, and all others are nonexistent. Debuggers may assume that a system has no harts with indexes higher than the first nonexistent one.

Harts are unavailable if they might exist/become available at a later time, or if there are other harts with higher indexes than this one. Harts may be unavailable for a variety of reasons including being reset, temporarily powered down, and not being plugged into the system. Systems with very large number of harts may permanently disable some during manufacturing, leaving holes in the otherwise continuous hart index space. In order to let the debugger discover all harts, they must show up as unavailable even if there is no chance of them ever becoming available.

Harts are running when they are executing normally, as if no debugger was attached. This includes being in a low power mode or waiting for an interrupt, as long as a halt request will result in the hart being halted.

Harts are halted when they are in Debug Mode, only performing tasks on behalf of the debugger.

Which states a hart that is reset goes through is implementation dependent. Harts may be unavailable while reset is asserted, and some time after reset is deasserted. They might transition to running for some time after reset is deasserted. Finally they end up either running or halted, depending on haltreq and resethaltreq.

3.5 Run Control

For every hart, the Debug Module tracks 4 conceptual bits of state: halt request, resume ack, halt-on-reset request, and hart reset. (The hart reset and halt-on-reset request bits are optional.) These 4 bits reset to 0, except for resume ack, which may reset to either 0 or 1. The DM receives halted, running, and havereset signals from each hart. The debugger can observe the state of resume ack in allresumeack and anyresumeack, and the state of halted, running, and havereset signals in allhalted, anyhalted, allrunning, anyrunning, allhavereset, and anyhavereset. The state of the other bits cannot be observed directly.

When a debugger writes 1 to haltreq, each selected hart's halt request bit is set. When a running hart, or a hart just coming out of reset, sees its halt request bit high, it responds by halting, deasserting its running signal, and asserting its halted signal. Halted harts ignore their halt request bit.

When a debugger writes 1 to resumereq, each selected hart's resume ack bit is cleared and each selected, halted hart is sent a resume request. Harts respond by resuming, clearing their halted signal, and asserting their running signal. At the end of this process the resume ack bit is set. These status signals of all selected harts are reflected in allresumeack, anyresumeack, allrunning, and

anyrunning. Resume requests are ignored by running harts.

When halt or resume is requested, a hart must respond in less than one second, unless it is unavailable. (How this is implemented is not further specified. A few clock cycles will be a more typical latency).

The DM can implement optional halt-on-reset bits for each hart, which it indicates by setting hasresethaltreq to 1. This means the DM implements the setresethaltreq and clrresethaltreq bits. Writing 1 to setresethaltreq sets the halt-on-reset request bit for each selected hart. When a hart's halt-on-reset request bit is set, the hart will immediately enter debug mode on the next deassertion of its reset. This is true regardless of the reset's cause. The hart's halt-on-reset request bit remains set until cleared by the debugger writing 1 to clrresethaltreq while the hart is selected, or by DM reset.

3.6 Halt Groups, Resume Groups, and External Triggers

An optional feature allows a debugger to place harts into two kinds of groups: halt groups and resume groups. It is also possible to add external triggers to a halt and resume groups.

When any hart in a halt group halts, or an external trigger that's a member of the halt group fires:

- 1. All the harts in that group will quickly halt, even if they are currently in the process of resuming.
- 2. Any external triggers in that group are notified.

Adding a hart to a halt group does not automatically halt that hart, even if other harts in the group are already halted.

When any hart in a resume group resumes, or an external trigger that's a member of the resume group fires:

- 1. All the other harts in that group will quickly resume as soon as any currently executing abstract commands have completed, except for the harts that are in the process of halting.
- 2. Any external triggers in that group are notified.

Adding a hart to a resume group does not automatically resume that hart, even if other harts in the group are currently running.

External triggers are abstract concepts that can signal the DM and/or receive signals from the DM. This configuration is done through dmcs2, where external triggers are referred to by a number. Commonly, external triggers are capable of sending a signal from the system into the DM, as well as receiving a signal from the DM to take their own action on. It is also allowable for an external trigger to be input-only or output-only. By convention external triggers 0–7 are bidirectional, triggers 8–11 are input-only, and triggers 12–15 are output-only but this is not required.

In both halt and resume groups, group 0 is special. Harts in group 0 halt/resume as if groups aren't implemented at all.

When the DM is reset, all harts must be placed in the lowest-numbered halt and resume groups that they can be in. (This will usually be group 0.)

Some designs may choose to hardcode hart groups to a group other than group 0, meaning it is never possible to halt or resume just a single hart. This is explicitly allowed. In that case it must be possible to discover the groups by using dmcs2 even if it's not possible to change the configuration.

3.7 Abstract Commands

The DM supports a set of abstract commands, most of which are optional. Depending on the implementation, the debugger may be able to perform some abstract commands even when the selected hart is not halted. Debuggers can only determine which abstract commands are supported by a given hart in a given state (running, halted, or held in reset) by attempting them and then looking at cmderr in abstractcs to see if they were successful. Commands may be supported with some options set, but not with other options set. If a command has unsupported options set or if bits that are defined as 0 aren't 0, then the DM must set cmderr to 2 (not supported).

Example: Every system must support the Access Register command, but may not support accessing CSRs. If the debugger requests to read a CSR in that case, the command will return "not supported."

Debuggers execute abstract commands by writing them to command. They can determine whether an abstract command is complete by reading busy in abstracts. If the debugger starts a new command while busy is set, cmderr becomes 1 (busy), the currently executing command still gets to run to completion, but any error generated by the currently executing command is lost. After completion, cmderr indicates whether the command was successful or not. Commands may fail because a hart is not halted, not running, unavailable, or because they encounter an error during execution.

If the command takes arguments, the debugger must write them to the data registers before writing to command. If a command returns results, the Debug Module must ensure they are placed in the data registers before busy is cleared. Which data registers are used for the arguments is described in Table 3.1. In all cases the least-significant word is placed in the lowest-numbered data register. The argument width depends on the command being executed, and is DXLEN where not explicitly specified.

Argument Width	arg0/return value	arg1	arg2
32	data0	data1	data2
64	data0, data1	data2, data3	data4, data5
128	data0-data3	data4-data7	data8-data11

Table 3.1: Use of Data Registers

possible, and then later check whether they completed without error. In the common case the debugger will be much slower than the target and commands succeed, which allows for maximum throughput. If there is a failure, the interface ensures that no commands execute after the failing one. To discover which command failed, the debugger has to look at the state of the DM (e.g. contents of data0) or hart (e.g. contents of a register modified by a Program Buffer program) to determine which one failed.

Before starting an abstract command, a debugger must ensure that haltreq, resumereq, and ackhavereset are all 0.

While an abstract command is executing (busy in abstractcs is high), a debugger must not change hartsel, and must not write 1 to haltreq, resumereq, ackhavereset, setresethaltreq, or clrresethaltreq.

If an abstract command does not complete in the expected time and appears to be hung, the debugger can try to reset the hart (using hartreset or ndmreset). If that doesn't clear busy, then it can try resetting the Debug Module (using dmactive).

If an abstract command is started while the selected hart is unavailable or if a hart becomes unavailable while executing an abstract command, then the Debug Module may terminate the abstract command, setting busy low, and cmderr to 4 (halt/resume). Alternatively, the command could just appear to be hung (busy never goes low).

3.7.1 Abstract Command Listing

This section describes each of the different abstract commands and how their fields should be interpreted when they are written to command.

Each abstract command is a 32-bit value. The top 8 bits contain cmdtype which determines the kind of command. Table 3.2 lists all commands.

cmdtype	Command	Page			
0	Access Register Command	13			
1	Quick Access	15			
2	Access Memory Command	16			

Table 3.2: Meaning of cmdtype

3.7.1.1 Access Register

This command gives the debugger access to CPU registers and allows it to execute the Program Buffer. It performs the following sequence of operations:

- 1. If write is clear and transfer is set, then copy data from the register specified by regno into the argo region of data, and perform any side effects that occur when this register is read from M-mode.
- 2. If write is set and transfer is set, then copy data from the arg0 region of data into the register specified by regno, and perform any side effects that occur when this register is written from M-mode.

- 3. If aarpostincrement is set, increment regno.
- 4. Execute the Program Buffer, if postexec is set.

If any of these operations fail, cmderr is set and none of the remaining steps are executed. An implementation may detect an upcoming failure early, and fail the overall command before it reaches the step that would cause failure. If the failure is that the requested register does not exist in the hart, cmderr must be set to 3 (exception).

Debug Modules must implement this command and must support read and write access to all GPRs when the selected hart is halted. Debug Modules may optionally support accessing other registers, or accessing registers when the hart is running. It is recommended that if one register in a group is accessible, then all registers in that group are accessible, but each individual register (aside from GPRs) may be supported differently across read, write, and halt status.

Registers might not be accessible if they wouldn't be accessible by M mode code currently running. (E.g. fflags may not be accessible when mstatus.FS is 0.) If this is the case, the debugger is responsible for changing state to make the registers accessible. The Core Debug Registers (Section 4.9) should be accessible if abstract CSR access is implemented.

Table 3.3: Abstract Register Numbers

Numbers	Group Description
0x0000 - 0x0fff	CSRs. The "PC" can be accessed here through dpc.
0x1000 - 0x101f	GPRs
0x1020 - 0x103f	Floating point registers
0xc000 - 0xffff	Reserved for non-standard extensions and internal use.

The encoding of aarsize was chosen to match sbaccess in sbcs.

This command modifies arg0 only when a register is read. The other data registers are not changed.

31	24	23	22	20	19	18	17	16	15	0
cmd	type	0	aar	size	aarpostincrement	postexec	transfer	write	regno	
	2	1		3	1	1	1	1	16	

Field	Description					
cmdtype	This is 0 to indicate Access Register Command.					
aarsize	2: Access the lowest 32 bits of the register.					
	3: Access the lowest 64 bits of the register.					
	4: Access the lowest 128 bits of the register.					
	If aarsize specifies a size larger than the register's					
	actual size, then the access must fail. If a reg-					
	ister is accessible, then reads of aarsize less than					
	or equal to the register's actual size must be sup-					
	ported.					
	This field controls the Argument Width as refer-					
	enced in Table 3.1.					

Continued on next page

Field	Description			
aarpostincrement	0: No effect. This variant must be supported.			
	1: After a successful register access, regno is in-			
	cremented (wrapping around to 0). Supporting			
	this variant is optional. It is undefined whether			
	the increment happens when transfer is 0.			
postexec	0: No effect. This variant must be supported, and			
	is the only supported one if progbufsize is 0.			
	1: Execute the program in the Program Buffer			
	exactly once after performing the transfer, if any.			
	Supporting this variant is optional.			
transfer	0: Don't do the operation specified by write.			
	1: Do the operation specified by write.			
	This bit can be used to just execute the Pro-			
	gram Buffer without having to worry about plac-			
	ing valid values into aarsize or regno.			
write	When transfer is set: 0: Copy data from the spec-			
	ified register into arg0 portion of data.			
	1: Copy data from arg0 portion of data into the			
	specified register.			
regno	Number of the register to access, as described in			
	Table 3.3. dpc may be used as an alias for PC if			
	this command is supported on a non-halted hart.			

3.7.1.2 Quick Access

Perform the following sequence of operations:

- 1. If the hart is halted, the command sets cmderr to "halt/resume" and does not continue.
- 2. Halt the hart. If the hart halts for some other reason (e.g. breakpoint), the command sets cmderr to "halt/resume" and does not continue.
- 3. Execute the Program Buffer. If an exception occurs, cmderr is set to "exception" and the program buffer execution ends, but the quick access command continues.
- 4. Resume the hart.

Implementing this command is optional.

This command does not touch the data registers.

31	24	23		0
cmd	type		0	
	3		24	

Field	Description
cmdtype	This is 1 to indicate Quick Access command.

3.7.1.3 Access Memory

This command lets the debugger perform memory accesses, with the exact same memory view and permissions as the selected hart has. This includes access to hart-local memory-mapped registers, etc. The command performs the following sequence of operations:

- 1. Copy data from the memory location specified in arg1 into the arg0 portion of data, if write is clear.
- 2. Copy data from the arg0 portion of data into the memory location specified in arg1, if write is set
- 3. If aampostincrement is set, increment arg1.

If any of these operations fail, cmderr is set and none of the remaining steps are executed. An access may only fail if the hart, running M-mode code, might encounter that same failure when it attempts the same access. An implementation may detect an upcoming failure early, and fail the overall command before it reaches the step that would cause failure.

Debug Modules may optionally implement this command and may support read and write access to memory locations when the selected hart is running or halted. If this command supports memory accesses while the hart is running, it must also support memory accesses while the hart is halted.

The encoding of aamsize was chosen to match sbaccess in sbcs.

This command modifies arg0 only when memory is read. It modifies arg1 only if aampostincrement is set. The other data registers are not changed.

31		24	23		22	20			19		
cr	ndty	pe	aamvirt	ual	aan	nsize	а	amp	ostinc	reme	nt
	8		1			3			1		
	18	17	16	15		14	4	13		0	
		0	write	tar	get-s	pecific	2		0		
		2	1		2				14		

Field	Description
cmdtype	This is 2 to indicate Access Memory Command.

Continued on next page

Field	Description
aamvirtual	An implementation does not have to implement
	both virtual and physical accesses, but it must
	fail accesses that it doesn't support.
	0: Addresses are physical (to the hart they are
	performed on).
	1: Addresses are virtual, and translated the way
	they would be from M-mode, with MPRV set.
aamsize	0: Access the lowest 8 bits of the memory loca-
	tion.
	1: Access the lowest 16 bits of the memory loca-
	tion.
	2: Access the lowest 32 bits of the memory loca-
	tion.
	3: Access the lowest 64 bits of the memory loca-
	tion.
	4: Access the lowest 128 bits of the memory loca-
	tion.
aampostincrement	After a memory access has completed, if this bit
	is 1, increment arg1 (which contains the address
	used) by the number of bytes encoded in aamsize.
	Supporting this variant is optional, but highly rec-
	ommended for performance reasons.
write	0: Copy data from the memory location specified
	in arg1 into the low bits of arg0. Any remaining
	bits of arg0 now have an undefined value.
	1: Copy data from the low bits of arg0 into the
	memory location specified in arg1.
target-specific	These bits are reserved for target-specific uses.

3.8 Program Buffer

To support executing arbitrary instructions on a halted hart, a Debug Module can include a Program Buffer that a debugger can write small programs to. Systems that support all necessary functionality using abstract commands only may choose to omit the Program Buffer.

A debugger can write a small program to the Program Buffer, and then execute it exactly once with the Access Register Abstract Command, setting the postexec bit in command. The debugger can write whatever program it likes (including jumps out of the Program Buffer), but the program must end with ebreak or c.ebreak. An implementation may support an implied ebreak that is executed when a hart runs off the end of the Program Buffer. This is indicated by impebreak. With this feature, a Program Buffer of just 2 32-bit words can offer efficient debugging.

If progbufsize is 1, impebreak must be 1. It is possible that the Program Buffer can hold only one 32-

or 16-bit instruction, so the debugger must only write a single instruction in this case, regardless of its size. This instruction can be a 32-bit instruction, or a compressed instruction in the lower 16 bits accompanied by a compressed nop in the upper 16 bits.

The slightly inconsistent behavior with a Program Buffer of size 1 is to accommodate hardware designs that prefer to stuff instructions directly into the pipeline when halted, instead of having the Program Buffer exist in the address space somewhere.

While these programs are executed, the hart does not leave Debug Mode (see Section 4.1). If an exception is encountered during execution of the Program Buffer, no more instructions are executed, the hart remains in Debug Mode, and cmderr is set to 3 (exception error). If the debugger executes a program that doesn't terminate with an ebreak instruction, the hart will remain in Debug Mode and the debugger will lose control of the hart.

Executing the Program Buffer may clobber dpc. If that is the case, it must be possible to read/write dpc using an abstract command with postexec not set. The debugger must attempt to save dpc between halting and executing a Program Buffer, and then restore dpc before leaving Debug Mode.

Allowing Program Buffer execution to clobber dpc allows for direct implementations that don't have a separate PC register, and do need to use the PC when executing the Program Buffer.

The Program Buffer may be implemented as RAM which is accessible to the hart. A debugger can determine if this is the case by executing small programs that attempt to write and read back relative to pc while executing from the Program Buffer. If so, the debugger has more flexibility in what it can do with the program buffer.

3.9 Overview of Hart Debug States

Figure 3.1 shows a conceptual view of the states passed through by a hart during run/halt debugging as influenced by the different fields of dmcontrol, abstractcs, abstractauto, and command.

3.10 System Bus Access

A debugger can access memory from a hart's point of view using a Program Buffer or the Abstract Access Memory command. (Both these features are optional.) A Debug Module may also include a System Bus Access block to provide memory access without involving a hart, regardless of whether Program Buffer is implemented. The System Bus Access block uses physical addresses.

The System Bus Access block may support 8-, 16-, 32-, 64-, and 128-bit accesses. Table 3.7 shows which bits in sbdata are used for each access size.

Depending on the microarchitecture, data accessed through System Bus Access may not always be coherent with that observed by each hart. It is up to the debugger to enforce coherency if the implementation does not. This specification does not define a standard way to do this. Possibilities may include writing to special memory-mapped locations, or executing special instructions via the Program Buffer.



Figure 3.1: Run/Halt Debug State Machine for single-hart systems. As only a small amount of state is visibile to the debugger, the states and transitions are conceptual.

Access Size	Data Bits			
8	sbdata0 bits 7:0			
16	sbdata0 bits 15:0			
32	sbdata0			
64	sbdata1, sbdata0			
128	sbdata3, sbdata2, sbdata1, sbdata0			

Table 3.7: System Bus Data Bits

Implementing a System Bus Access block has several benefits even when a Debug Module also implements a Program Buffer. First, it is possible to access memory in a running system with minimal impact. Second, it may improve performance when accessing memory. Third, it may provide access to devices that a hart does not have access to.

3.11 Minimally Intrusive Debugging

Depending on the task it is performing, some harts can only be halted very briefly. There are several mechanisms that allow accessing resources in such a running system with a minimal impact on the running hart.

First, an implementation may allow some abstract commands to execute without halting the hart.

Second, the Quick Access abstract command can be used to halt a hart, quickly execute the contents of the Program Buffer, and let the hart run again. Combined with instructions that allow Program Buffer code to access the data registers, as described in ??, this can be used to quickly perform a memory or register access. For some systems this will be too intrusive, but many systems that can't be halted can bear an occasional hiccup of a hundred or less cycles.

Third, if the System Bus Access block is implemented, it can be used while a hart is running to access system memory.

3.12 Security

To protect intellectual property it may be desirable to lock access to the Debug Module. To allow access during a manufacturing process and not afterwards, a reasonable solution could be to add a fuse bit to the Debug Module that can be used to be permanently disable it. Since this is technology specific, it is not further addressed in this spec.

Another option is to allow the DM to be unlocked only by users who have an access key. Between authenticated, authbusy, and authdata arbitrarily complex authentication mechanism can be supported. When authenticated is clear, the DM must not interact with the rest of the platform, nor expose details about the harts connected to the DM. All DM registers should read 0, while writes should be ignored, with the following mandatory exceptions:

1. authenticated in dmstatus is readable.

- 2. authbusy in dmstatus is readable.
- 3. version in dmstatus is readable.
- 4. dmactive in dmcontrol is readable and writable.
- 5. authdata is readable and writable.

3.13 Version Detection

To detect the version of the Debug Module with a minimum of side effects, use the following procedure:

- 1. Read dmcontrol.
- 2. Write dmcontrol, preserving hartreset, hasel, hartsello, and hartselhi from the value that was read, setting dmactive, and clearing all the other bits.
- 3. Read dmcontrol until dmactive is high.
- 4. Read dmstatus, which contains version.

This has the following unavoidable side effects:

- 1. haltreq is cleared, potentially preventing a halt request made by a previous debugger from taking effect.
- 2. resumered is cleared, potentially preventing a resume request made by a previous debugger from taking effect.
- 3. ndmreset is deasserted, releasing the system from reset if a previous debugger had set it.
- 4. dmactive is asserted, releasing the DM from reset. This in itself is not observable by any harts.

This procedure is guaranteed to work in future versions of this spec. The meaning of the dmcontrol bits where hartreset, hasel, hartsello, and hartselhi currently reside might change, but preserving them will have no side effects. Clearing the bits of dmcontrol not explicitly mentioned here will have no side effects beyond the ones mentioned above.

3.14 Debug Module Registers

The registers described in this section are accessed over the DMI bus. Each DM has a base address (which is 0 for the first DM). The register addresses below are offsets from this base address.

When read, unimplemented Debug Module DMI Registers return 0. Writing them has no effect.

For each register it is possible to determine that it is implemented by reading it and getting a non-zero value (e.g. sbcs), or by checking bits in another register (e.g. progbufsize).

Table 3.8: Debug Module Debug Bus Registers

Address	Name	Page
0x04	Abstract Data 0 (data0)	33
0x0f	Abstract Data 11 (data11)	
0x10	Debug Module Control (dmcontrol)	24
0x11	Debug Module Status (dmstatus)	$\frac{1}{22}$
0x12	Hart Info (hartinfo)	27
0x13	Halt Summary 1 (haltsum1)	36
0x14	Hart Array Window Select (hawindowsel)	28
0x15	Hart Array Window (hawindow)	29
0x16	Abstract Control and Status (abstractcs)	29
0x17	Abstract Command (command)	30
0x18	Abstract Command Autoexec (abstractauto)	31
0x19	Configuration String Pointer 0 (confstrptr0)	31
0x1a	Configuration String Pointer 1 (confstrptr1)	32
0x1b	Configuration String Pointer 2 (confstrptr2)	32
0x1c	Configuration String Pointer 3 (confstrptr3)	32
0x1d	Next Debug Module (nextdm)	33
0x1f	Custom Features (custom)	42
0x20	Program Buffer 0 (progbuf0)	33
0x2f	Program Buffer 15 (progbuf15)	
0x30	Authentication Data (authdata)	34
0x32	Debug Module Control and Status 2 (dmcs2)	34
0x34	Halt Summary 2 (haltsum2)	36
0x35	Halt Summary 3 (haltsum3)	36
0x37	System Bus Address 127:96 (sbaddress3)	40
0x38	System Bus Access Control and Status (sbcs)	37
0x39	System Bus Address 31:0 (sbaddress0)	38
0x3a	System Bus Address 63:32 (sbaddress1)	39
0x3b	System Bus Address 95:64 (sbaddress2)	39
0x3c	System Bus Data 31:0 (sbdata0)	40
0x3d	System Bus Data 63:32 (sbdata1)	41
0x3e	System Bus Data 95:64 (sbdata2)	42
0x3f	System Bus Data 127:96 (sbdata3)	42
0x40	Halt Summary 0 (haltsum0)	35
0x70	Custom Features 0 (custom0)	42
0x7f	Custom Features 15 (custom15)	43

3.14.1 Debug Module Status (dmstatus, at 0x11)

This register reports status for the overall Debug Module as well as the currently selected harts, as defined in hasel. Its address will not change in the future, because it contains version.

This entire register is read-only.

		31	23	22	21	20	1	19	18			
		0		impebreak		0	allhavereset		anyhave	reset		
	9		1		2	1		1				
	17			16		15			14	13		
al	Iresı	ımeack	an	yresumeack	all	allnonexis		anyno	nexistent	allu	llunavail	
	1			1		1		1			1	
	12		11		10		9	8				
	anyunavail		allrunning	ga	anyrunning		allhalte	d anyha	lted			
	1		1		1		1	1				
	7		6		5		4		3	0		
	authenticated		authbusy	has	hasresethaltreq		confstrptrvalid		vers	sion		
_	1		-				1		4			

Field	Description	Access	Reset
impebreak	If 1, then there is an implicit ebreak instruction	R	Preset
	at the non-existent word immediately after the		
	Program Buffer. This saves the debugger from		
	having to write the ebreak itself, and allows the		
	Program Buffer to be one word smaller.		
	This must be 1 when progbufsize is 1.		
allhavereset	This field is 1 when all currently selected harts	R	-
	have been reset and reset has not been acknowl-		
	edged for any of them.		
anyhavereset	This field is 1 when at least one currently selected	R	-
	hart has been reset and reset has not been ac-		
	knowledged for that hart.		
allresumeack	This field is 1 when all currently selected harts	R	-
	have acknowledged their last resume request.		
anyresumeack	This field is 1 when any currently selected hart	R	-
	has acknowledged its last resume request.		
allnonexistent	This field is 1 when all currently selected harts do	R	-
	not exist in this platform.		
anynonexistent	This field is 1 when any currently selected hart	R	-
	does not exist in this platform.		
allunavail	This field is 1 when all currently selected harts	R	-
	are unavailable.		
anyunavail	This field is 1 when any currently selected hart is	R	-
	unavailable.		
allrunning	This field is 1 when all currently selected harts	R	-
	are running.		
anyrunning	This field is 1 when any currently selected hart is	R	-
	running.		
allhalted	This field is 1 when all currently selected harts	R	-
	are halted.		
anyhalted	This field is 1 when any currently selected hart is	R	-
	halted.		
	Contin	ned on n	ort mage

Continued on next page

Field	Description	Access	Reset
authenticated	0: Authentication is required before using the	R	Preset
	DM.		
	1: The authentication check has passed.		
	On components that don't implement authentica-		
	tion, this bit must be preset as 1.		
authbusy	0: The authentication module is ready to process	R	0
	the next read/write to authdata.		
	1: The authentication module is busy. Accessing		
	authdata results in unspecified behavior.		
	authbusy only becomes set in immediate response		
	to an access to authdata.		
hasresethaltreq	1 if this Debug Module supports halt-on-reset	R	Preset
	functionality controllable by the setresethaltreq		
	and clrresethaltreq bits. 0 otherwise.		
confstrptrvalid	0: confstrptr0-confstrptr3 hold information	R	Preset
	which is not relevant to the configuration string.		
	1: confstrptr0-confstrptr3 hold the address		
	of the configuration string.		
version	0: There is no Debug Module present.	R	3
	1: There is a Debug Module and it conforms to		
	version 0.11 of this specification.		
	2: There is a Debug Module and it conforms to		
	version 0.13 of this specification.		
	3: There is a Debug Module and it conforms to		
	version 0.14 of this specification.		
	15: There is a Debug Module but it does not con-		
	form to any available version of this spec.		

3.14.2 Debug Module Control (dmcontrol, at 0x10)

This register controls the overall Debug Module as well as the currently selected harts, as defined in hasel.

Throughout this document we refer to hartsel, which is hartselhi combined with hartsello. While the spec allows for 20 hartsel bits, an implementation may choose to implement fewer than that. The actual width of hartsel is called HARTSELLEN. It must be at least 0 and at most 20. A debugger should discover HARTSELLEN by writing all ones to hartsel (assuming the maximum size) and reading back the value to see which bits were actually set. Debuggers must not change hartsel while an abstract command is executing.

There are separate setresethaltreq and clrresethaltreq bits so that it is possible to write dmcontrol without changing the halt-on-reset request bit for each selected hart, when not all selected harts have the same configuration.

On any given write, a debugger may only write 1 to at most one of the following bits: resumereq, hartreset, ackhavereset, setresethaltreq, and clrresethaltreq. The others must be written 0.

resethaltreq is an optional internal bit of per-hart state that cannot be read, but can be written with setresethaltreq and clrresethaltreq.

For forward compatibility, version will always be readable when bit 1 (ndmreset) is 0 and bit 0 (dmactive) is 1.

			31		30		29		28	27			
			haltreq	resu	ıme	req	hartreset	ackh	avereset	relaxed	lpriv		
			1		1		1		1	1			
26	25	16	15	6	5	4	3		2	2	1		0
hasel	harts	ello	hart	selhi	(0	setresetha	ltreq	clrreset	haltreq	ndmr	eset	dmactive
1	10)	1	0		2	1		1		1		1

Field	Description	Access	Reset					
haltreq	Writing 0 clears the halt request bit for all cur-	WARZ	-					
	rently selected harts. This may cancel outstand-							
	ing halt requests for those harts.							
	Writing 1 sets the halt request bit for all currently							
	selected harts. Running harts will halt whenever							
	their halt request bit is set.							
	Writes apply to the new value of hartsel and hasel.							
resumereq	Writing 1 causes the currently selected harts to	W1	-					
	resume once, if they are halted when the write							
	occurs. It also clears the resume ack bit for those							
	harts.							
	resumereq is ignored if haltreq is set.							
	Writes apply to the new value of hartsel and hasel.							
hartreset	This optional field writes the reset bit for all the	WARL	0					
	currently selected harts. To perform a reset the							
	debugger writes 1, and then writes 0 to deassert							
	the reset signal.							
	While this bit is 1, the debugger must not change							
	which harts are selected.							
	If this feature is not implemented, the bit always							
	stays 0, so after writing 1 the debugger can read							
	the register back to see if the feature is supported.							
	Writes apply to the new value of hartsel and hasel.							
ackhavereset	0: No effect.	W1	-					
	1: Clears havereset for any selected harts.							
	Writes apply to the new value of hartsel and hasel.							
Continued on me								

Continued on next page

Field	Description	Access	Reset
relaxedpriv	This optional bit controls whether program buffer	WARL	Preset
	and abstract memory accesses are performed with		
	the exact and full set of permission checks that		
	apply based on the current architectural state		
	of the hart performing the access, or with a re-		
	laxed set of permission checks (e.g. PMP restric-		
	tions are ignored). The details of the latter are		
	implementation-specific. When set to 0, full per-		
	missions apply; when set to 1, relaxed permissions		
	apply.		
hasel	Selects the definition of currently selected harts.	R/W	0
	0: There is a single currently selected hart, that		
	is selected by hartsel.		
	1: There may be multiple currently selected harts		
	- the hart selected by hartsel, plus those selected		
	by the hart array mask register.		
	An implementation which does not implement the		
	hart array mask register must tie this field to 0.		
	A debugger which wishes to use the hart array		
	mask register feature should set this bit and read		
hartsello	back to see if the functionality is supported.	R/W	0
nartseno	The low 10 bits of hartsel: the DM-specific index of the hart to select. This hart is always part of	n/w	
	the currently selected harts.		
hartselhi	The high 10 bits of hartsel: the DM-specific index	R/W	0
Hartselli	of the hart to select. This hart is always part of	10/ 11	
	the currently selected harts.		
setresethaltreq	This optional field writes the halt-on-reset re-	W1	-
	quest bit for all currently selected harts, unless		
	clrresethaltreq is simultaneously set to 1. When		
	set to 1, each selected hart will halt upon the next		
	deassertion of its reset. The halt-on-reset request		
	bit is not automatically cleared. The debugger		
	must write to clrresethaltreq to clear it.		
	Writes apply to the new value of hartsel and hasel.		
	If hasresethaltreq is 0, this field is not imple-		
	mented.	****	
clrresethaltreq	This optional field clears the halt-on-reset request	W1	-
	bit for all currently selected harts.		
	Writes apply to the new value of hartsel and hasel.		

Continued on next page

Field	Description	Access	Reset
ndmreset	This bit controls the reset signal from the DM to	R/W	0
	the rest of the system. The signal should reset		
	every part of the system, including every hart,		
	except for the DM and any logic required to access		
	the DM. To perform a system reset the debugger		
	writes 1, and then writes 0 to deassert the reset.		
dmactive	This bit serves as a reset signal for the Debug	R/W	0
	Module itself.		
	0: The module's state, including authentication		
	mechanism, takes its reset values (the dmactive		
	bit is the only bit which can be written to some-		
	thing other than its reset value). Any accesses to		
	the module may fail. Specifically, version may not		
	return correct data.		
	1: The module functions normally. After writ-		
	ing 1, the debugger should poll dmcontrol until		
	dmactive is high. Hardware may take an arbitrar-		
	ily long time to initialize and will indicate com-		
	pletion by setting dmactive to 1.		
	No other mechanism should exist that may result		
	in resetting the Debug Module after power up.		
	A debugger may pulse this bit low to get the De-		
	bug Module into a known state.		
	Implementations may pay attention to this bit to		
	further aid debugging, for example by preventing		
	the Debug Module from being power gated while		
	debugging is active.		

3.14.3 Hart Info (hartinfo, at 0x12)

This register gives information about the hart currently selected by hartsel.

This register is optional. If it is not present it should read all-zero.

If this register is included, the debugger can do more with the Program Buffer by writing programs which explicitly access the data and/or dscratch registers.

This entire register is read-only.

31	24	23	20	19	17	16	15	12	11	0
0		nscr	atch	()	dataaccess	data	size	dataa	addr
	3		1	:	3	1		l.	1:	2

Field	Description	Access	Reset
nscratch	Number of dscratch registers available for the	R	Preset
	debugger to use during program buffer execution,		
	starting from dscratch0. The debugger can make		
	no assumptions about the contents of these regis-		
	ters between commands.		
dataaccess	0: The data registers are shadowed in the hart	R	Preset
	by CSRs. Each CSR is DXLEN bits in size, and		
	corresponds to a single argument, per Table 3.1.		
	1: The data registers are shadowed in the hart's		
	memory map. Each register takes up 4 bytes in		
	the memory map.		
datasize	If dataaccess is 0: Number of CSRs dedicated to	R	Preset
	shadowing the data registers.		
	If dataaccess is 1: Number of 32-bit words in the		
	memory map dedicated to shadowing the data		
	registers.		
	Since there are at most 12 data registers, the		
	value in this register must be 12 or smaller.		
dataaddr	If dataaccess is 0: The number of the first CSR	R	Preset
	dedicated to shadowing the data registers.		
	If dataaccess is 1: Address of RAM where the		
	data registers are shadowed. This address is sign		
	extended giving a range of -2048 to 2047, easily		
	addressed with a load or store using x0 as the		
	address register.		

$3.14.4 \quad Hart\ Array\ Window\ Select\ (\texttt{hawindowsel},\ at\ 0x14)$

This register selects which of the 32-bit portion of the hart array mask register (see Section 3.3.2) is accessible in hawindow.

31		15	14	0
	0		hawind	owsel
	17		15	

Field	Description	Access	Reset
hawindowsel	The high bits of this field may be tied to 0, de-	R/W	0
	pending on how large the array mask register is.		
	E.g. on a system with 48 harts only bit 0 of this		
	field may actually be writable.		

3.14.5 Hart Array Window (hawindow, at 0x15)

This register provides R/W access to a 32-bit portion of the hart array mask register (see Section 3.3.2). The position of the window is determined by hawindowsel. I.e. bit 0 refers to hart hawindowsel *32, while bit 31 refers to hart hawindowsel *32 + 31.

Since some bits in the hart array mask register may be constant 0, some bits in this register may be constant 0, depending on the current value of hawindowsel.



3.14.6 Abstract Control and Status (abstractcs, at 0x16)

Writing this register while an abstract command is executing causes cmderr to become 1 (busy) once the command completes (busy becomes 0).

 $\begin{array}{l} \textbf{datacount} \ \textit{must} \ \textit{be} \ \textit{at least} \ \textit{1} \ \textit{to} \ \textit{support} \ \textit{RV32} \ \textit{harts}, \ \textit{2} \ \textit{to} \ \textit{support} \ \textit{RV64} \ \textit{harts}, \ \textit{or} \ \textit{4} \ \textit{to} \ \textit{support} \ \textit{RV128} \ \textit{harts}. \end{array}$

31	29	28	24	23		13	12	11	10	8	7	4	3	0
()	progbi	ufsize		0		busy	0	cmd	err	()	data	count
:	3	5			11		1	1	3			1		4

Field	Description	Access	Reset
progbufsize	Size of the Program Buffer, in 32-bit words. Valid	R	Preset
	sizes are 0 - 16.		
busy	1: An abstract command is currently being exe-	R	0
	cuted.		
	This bit is set as soon as command is written, and		
	is not cleared until that command has completed.		

Continued on next page

Field	Description	Access	Reset			
cmderr	Gets set if an abstract command fails. The bits in	R/W1C	0			
	this field remain set until they are cleared by writ-					
	ing 1 to them. No abstract command is started					
	until the value is reset to 0.					
	This field only contains a valid value if busy is 0.					
	0 (none): No error.					
	1 (busy): An abstract command was executing					
	while command, abstractcs, or abstractauto					
	was written, or when one of the data or progbuf					
	registers was read or written. This status is only					
	written if cmderr contains 0.					
	2 (not supported): The command in command is					
	not supported. It may be supported with different					
	options set, but it will not be supported at a later					
	time when the hart or system state are different.					
	3 (exception): An exception occurred while ex-					
	ecuting the command (e.g. while executing the					
	Program Buffer).					
	4 (halt/resume): The abstract command couldn't					
	execute because the hart wasn't in the required					
	state (running/halted), or unavailable.					
	5 (bus): The abstract command failed due to a					
	bus error (e.g. alignment, access size, or timeout).					
	6: Reserved for future use.					
	7 (other): The command failed for another rea-					
	son.					
datacount	Number of data registers that are implemented	R	Preset			
	as part of the abstract command interface. Valid					
	sizes are $1-12$.					

3.14.7 Abstract Command (command, at 0x17)

Writes to this register cause the corresponding abstract command to be executed.

Writing this register while an abstract command is executing causes cmderr to become 1 (busy) once the command completes (busy becomes 0).

If cmderr is non-zero, writes to this register are ignored.

cmderr inhibits starting a new command to accommodate debuggers that, for performance reasons, send several commands to be executed in a row without checking cmderr in between. They can safely do so and check cmderr at the end without worrying that one command failed but then a later command (which might have depended on the previous one succeeding) passed.

31	24	23		0
cmd	type		control	
-	8		24	

Field	Description	Access	Reset
cmdtype	The type determines the overall functionality of	WARZ	0
	this abstract command.		
control	This field is interpreted in a command-specific	WARZ	0
	manner, described for each abstract command.		

3.14.8 Abstract Command Autoexec (abstractauto, at 0x18)

This register is optional. Including it allows more efficient burst accesses. A debugger can detect whether it is support by setting bits and reading them back.

Writing this register while an abstract command is executing causes cmderr to become 1 (busy) once the command completes (busy becomes 0).

31	16	15	12	11	0
autoexecprogb	uf	0		autoexeco	lata
16		4		12	

Field	Description	Access	Reset
autoexecprogbuf	When a bit in this field is 1, read or write ac-	R/W	0
	cesses to the corresponding progbuf word cause		
	the command in command to be executed again.		
autoexecdata	When a bit in this field is 1, read or write ac-	R/W	0
	cesses to the corresponding data word cause the		
	command in command to be executed again.		

3.14.9 Configuration String Pointer 0 (confstrptr0, at 0x19)

When confstrptrvalid is set, reading this register returns bits 31:0 of the configuration string pointer. Reading the other confstrptr registers returns the upper bits of the address.

When system bus mastering is implemented, this must be an address that can be used with the System Bus Access module. Otherwise, this must be an address that can be used to access the configuration string from the hart with ID 0.

If confstrptrvalid is 0, then the confstrptr registers hold identifier information which is not further specified in this document.

The configuration string itself is described in the Privileged Spec.

This entire register is read-only.



3.14.10 Configuration String Pointer 1 (confstrptr1, at 0x1a)

When confstrptrvalid is set, reading this register returns bits 63:32 of the configuration string pointer. See confstrptr0 for more details.

This entire register is read-only.



3.14.11 Configuration String Pointer 2 (confstrptr2, at 0x1b)

When confstrptrvalid is set, reading this register returns bits 95:64 of the configuration string pointer. See confstrptr0 for more details.

This entire register is read-only.



3.14.12 Configuration String Pointer 3 (confstrptr3, at 0x1c)

When confstrptrvalid is set, reading this register returns bits 127:96 of the configuration string pointer. See confstrptr0 for more details.

This entire register is read-only.

31		0
	addr	
	32	

3.14.13 Next Debug Module (nextdm, at 0x1d)

If there is more than one DM accessible on this DMI, this register contains the base address of the next one in the chain, or 0 if this is the last one in the chain.

This entire register is read-only.



3.14.14 Abstract Data 0 (data0, at 0x04)

data0 through data11 are basic read/write registers that may be read or changed by abstract commands. datacount indicates how many of them are implemented, starting at data0, counting up. Table 3.1 shows how abstract commands use these registers.

Accessing these registers while an abstract command is executing causes cmderr to be set to 1 (busy) if it is 0.

Attempts to write them while busy is set does not change their value.

The values in these registers may not be preserved after an abstract command is executed. The only guarantees on their contents are the ones offered by the command in question. If the command fails, no assumptions can be made about the contents of these registers.



3.14.15 Program Buffer 0 (progbuf0, at 0x20)

progbuf0 through progbuf15 provide read/write access to the optional program buffer. progbufsize indicates how many of them are implemented starting at progbuf0, counting up.

Accessing these registers while an abstract command is executing causes cmderr to be set to 1 (busy) if it is 0.


Attempts to write them while busy is set does not change their value.

31		0
	data	
	32	

3.14.16 Authentication Data (authdata, at 0x30)

This register serves as a 32-bit serial port to/from the authentication module.

When authbusy is clear, the debugger can communicate with the authentication module by reading or writing this register. There is no separate mechanism to signal overflow/underflow.



3.14.17 Debug Module Control and Status 2 (dmcs2, at 0x32)

This register contains DM control and status bits that didn't easily fit in dmcontrol and dmstatus. All are optional.

If halt groups are not implemented, then group will always be 0 when grouptype is 0.

If resume groups are not implemented, then grouptype will remain 0 even after 1 is written there.

The external triggers available to add to halt groups may or may not be distinct from the external triggers available to add to resume groups.

31		12	11	10	7	6	2	1	0
	0		grouptype	exttrigg	ger	gro	up	hgwrite	hgselect
	20		1	4		5		1	1

Field	Description	Access	Reset
grouptype	0: The remaining fields in this register configure	WARL	0
	halt groups.		
	1: The remaining fields in this register configure		
	resume groups.		
exttrigger	This field contains the currently selected external	WARL	0
	trigger.		
	If a non-existent trigger value is written here, the		
	hardware will change it to a valid one or 0 if no		
	external triggers exist.		

 $Continued\ on\ next\ page$

Field	Description	Access	Reset
group	When hgselect is 0, contains the group of the hart	WARL	preset
	specified by hartsel.		
	When hgselect is 1, contains the group of the ex-		
	ternal trigger selected by exttrigger.		
	Writes only have an effect if hgwrite is also written		
	1.		
	Group numbers are contiguous starting at 0,		
	with the highest number being implementation-		
	dependent, and possibly different between differ-		
	ent group types. Debuggers should read back this		
	field after writing to confirm they are using a hart		
	group that is supported.		
	If groups aren't implemented, then this entire field		
	is 0.		
hgwrite	When hgselect is 0, writing 1 changes the group	W1	-
	of all selected harts to the value written to group.		
	When 1 is written and hgselect is 0, for every se-		
	lected hart the DM will change its group to the		
	value written to group, if the hardware supports		
	that group for that hart.		
	When 1 is written and hgselect is 1, the DM will		
	change the group of the external trigger selected		
	by exttrigger to the value written to group, if the		
	hardware supports that group for that trigger.		
	Writing 0 has no effect.	****	
hgselect	0: Operate on harts.	WARL	0
	1: Operate on external triggers.		
	If there are no external triggers, this field must be		
	tied to 0.		

3.14.18 Halt Summary 0 (haltsum0, at 0x40)

Each bit in this read-only register indicates whether one specific hart is halted or not. Unavailable/nonexistent harts are not considered to be halted.

This register might not be present if fewer than 2 harts are connected to this DM.

The LSB reflects the halt status of hart {hartsel[19:5],5'h0}, and the MSB reflects halt status of hart {hartsel[19:5],5'h1f}.

This entire register is read-only.



3.14.19 Halt Summary 1 (haltsum1, at 0x13)

Each bit in this read-only register indicates whether any of a group of harts is halted or not. Unavailable/nonexistent harts are not considered to be halted.

This register might not be present if fewer than 33 harts are connected to this DM.

The LSB reflects the halt status of harts {hartsel[19:10],10'h0} through {hartsel[19:10],10'h1f}. The MSB reflects the halt status of harts {hartsel[19:10],10'h3e0} through {hartsel[19:10],10'h3ff}.

This entire register is read-only.



3.14.20 Halt Summary 2 (haltsum2, at 0x34)

Each bit in this read-only register indicates whether any of a group of harts is halted or not. Unavailable/nonexistent harts are not considered to be halted.

This register might not be present if fewer than 1025 harts are connected to this DM.

The LSB reflects the halt status of harts {hartsel[19:15],15'h0} through {hartsel[19:15],15'h3ff}. The MSB reflects the halt status of harts {hartsel[19:15],15'h7c00} through {hartsel[19:15],15'h7fff}.

This entire register is read-only.



3.14.21 Halt Summary 3 (haltsum3, at 0x35)

Each bit in this read-only register indicates whether any of a group of harts is halted or not. Unavailable/nonexistent harts are not considered to be halted.

This register might not be present if fewer than 32769 harts are connected to this DM.

The LSB reflects the halt status of harts 20'h0 through 20'h7fff. The MSB reflects the halt status of harts 20'hf8000 through 20'hfffff.

This entire register is read-only.



3.14.22 System Bus Access Control and Status (sbcs, at 0x38)

		31	29	28	23		22		21			20	
		sbversion		()	sbb	usyerror	sb	busy	sb	read	lonadd	r
		3		(3		1		1			1	
	19	17		-	16		15	<u>, </u>		14	12	11	5
	sbaccess sb		sba	sbautoincrement		sbreadondata		ta	sberror		sbasize		
		3			1		1			3	3		7
	4		4 3		2			1		0			
	sbaccess128		L28	sbac	ccess	54	sbaccess3	32	sbac	cess	16	sbacc	ess8
1				1		1			1		1		

Field	Description	Access	Reset
sbversion	0: The System Bus interface conforms to mainline	R	1
	drafts of this spec older than 1 January, 2018.		
	1: The System Bus interface conforms to this ver-		
	sion of the spec.		
	Other values are reserved for future versions.		
sbbusyerror	Set when the debugger attempts to read data	R/W1C	0
	while a read is in progress, or when the debug-		
	ger initiates a new access while one is already in		
	progress (while sbbusy is set). It remains set until		
	it's explicitly cleared by the debugger.		
	While this field is set, no more system bus accesses		
	can be initiated by the Debug Module.		
sbbusy	When 1, indicates the system bus master is busy.	R	0
	(Whether the system bus itself is busy is related,		
	but not the same thing.) This bit goes high im-		
	mediately when a read or write is requested for		
	any reason, and does not go low until the access		
	is fully completed.		
	Writes to sbcs while sbbusy is high result in un-		
	defined behavior. A debugger must not write to		
	sbcs until it reads sbbusy as 0.		
sbreadonaddr	When 1, every write to sbaddress0 automatically	R/W	0
	triggers a system bus read at the new address.		

Continued on next page

Field	Description	Access	Reset
sbaccess	Select the access size to use for system bus ac-	R/W	2
	cesses.		
	0: 8-bit		
	1: 16-bit		
	2: 32-bit		
	3: 64-bit		
	4: 128-bit		
	If sbaccess has an unsupported value when the		
	DM starts a bus access, the access is not per-		
	formed and sberror is set to 4.		
sbautoincrement	When 1, sbaddress is incremented by the access	R/W	0
	size (in bytes) selected in sbaccess after every sys-		
	tem bus access.		
sbreadondata	When 1, every read from sbdata0 automatically	R/W	0
	triggers a system bus read at the (possibly auto-		
	incremented) address.		
sberror	When the Debug Module's system bus master en-	R/W1C	0
	counters an error, this field gets set. The bits in		
	this field remain set until they are cleared by writ-		
	ing 1 to them. While this field is non-zero, no		
	more system bus accesses can be initiated by the		
	Debug Module.		
	An implementation may report "Other" (7) for		
	any error condition.		
	0: There was no bus error.		
	1: There was a timeout.		
	2: A bad address was accessed.		
	3: There was an alignment error.		
	4: An access of unsupported size was requested.		
	7: Other.		
sbasize	Width of system bus addresses in bits. (0 indi-	R	Preset
	cates there is no bus access support.)		
sbaccess128	1 when 128-bit system bus accesses are supported.	R	Preset
sbaccess64	1 when 64-bit system bus accesses are supported.	R	Preset
sbaccess32	1 when 32-bit system bus accesses are supported.	R	Preset
sbaccess16	1 when 16-bit system bus accesses are supported.	R	Preset
sbaccess8	1 when 8-bit system bus accesses are supported.	R	Preset

3.14.23 System Bus Address 31:0 (sbaddress0, at 0x39)

If sbasize is 0, then this register is not present.

When the system bus master is busy, writes to this register will set sbbusyerror and don't do anything

else.

If sberror is 0, sbbusyerror is 0, and sbreadonaddr is set then writes to this register start the following:

- 1. Set sbbusy.
- 2. Perform a bus read from the new value of sbaddress.
- 3. If the read succeeded and shautoincrement is set, increment shaddress.
- 4. Clear sbbusy.



Field	Description	Access	Reset
address	Accesses bits 31:0 of the physical address in	R/W	0
	sbaddress.		

3.14.24 System Bus Address 63:32 (sbaddress1, at 0x3a)

If sbasize is less than 33, then this register is not present.

When the system bus master is busy, writes to this register will set sbbusyerror and don't do anything else.



Field	Description	Access	Reset
address	Accesses bits 63:32 of the physical address in	R/W	0
	sbaddress (if the system address bus is that wide).		
	wide).		

3.14.25 System Bus Address 95:64 (sbaddress2, at 0x3b)

If sbasize is less than 65, then this register is not present.

When the system bus master is busy, writes to this register will set sbbusyerror and don't do anything else.



Field	Description	Access	Reset
address	Accesses bits 95:64 of the physical address in	R/W	0
	sbaddress (if the system address bus is that wide).		

3.14.26 System Bus Address 127:96 (sbaddress3, at 0x37)

If sbasize is less than 97, then this register is not present.

When the system bus master is busy, writes to this register will set sbbusyerror and don't do anything else.



Field	Description	Access	Reset
address	Accesses bits 127:96 of the physical address in	R/W	0
	sbaddress (if the system address bus is that		
	wide).		

3.14.27 System Bus Data 31:0 (sbdata0, at 0x3c)

If all of the sbaccess bits in sbcs are 0, then this register is not present.

Any successful system bus read updates sbdata. If the width of the read access is less than the width of sbdata, the contents of the remaining high bits may take on any value.

If either sberror or sbbusyerror isn't 0 then accesses do nothing.

If the bus master is busy then accesses set sbbusyerror, and don't do anything else.

Writes to this register start the following:

1. Set sbbusy.

- 2. Perform a bus write of the new value of sbdata to sbaddress.
- 3. If the write succeeded and shautoincrement is set, increment shaddress.
- 4. Clear sbbusy.

Reads from this register start the following:

- 1. "Return" the data.
- 2. Set sbbusy.
- 3. If sbreadondata is set:
 - (a) Perform a system bus read from the address contained in sbaddress, placing the result in sbdata.
 - (b) If sbautoincrement is set and the read was successful, increment sbaddress.
- 4. Clear sbbusy.

Only sbdata0 has this behavior. The other sbdata registers have no side effects. On systems that have buses wider than 32 bits, a debugger should access sbdata0 after accessing the other sbdata registers.



Field	Access	Reset	
data	Accesses bits 31:0 of sbdata.	R/W	0

3.14.28 System Bus Data 63:32 (sbdata1, at 0x3d)

If sbaccess64 and sbaccess128 are 0, then this register is not present.

If the bus master is busy then accesses set sbbusyerror, and don't do anything else.


31		0
	data	
	32	

Field	Description	Access	Reset
data	Accesses bits 63:32 of sbdata (if the system bus	R/W	0
	is that wide).		

3.14.29 System Bus Data 95:64 (sbdata2, at 0x3e)

This register only exists if sbaccess128 is 1.

If the bus master is busy then accesses set sbbusyerror, and don't do anything else.




Field	Description	Access	Reset
data	Accesses bits 95:64 of sbdata (if the system bus	R/W	0
	is that wide).		

3.14.30 System Bus Data 127:96 (sbdata3, at 0x3f)

This register only exists if sbaccess128 is 1.

If the bus master is busy then accesses set sbbusyerror, and don't do anything else.



Field	Description	Access	Reset
data	Accesses bits 127:96 of sbdata (if the system bus	R/W	0
	is that wide).		

3.14.31 Custom Features (custom, at 0x1f)

This optional register may be used for non-standard features. Future version of the debug spec will not use this address.

3.14.32 Custom Features 0 (custom0, at 0x70)

This optional register may be used for non-standard features. Future version of the debug spec will not use this address.

3.14.33 Custom Features 15 (custom15, at 0x7f)

This optional register may be used for non-standard features. Future version of the debug spec will not use this address.

Chapter 4

RISC-V Debug

Modifications to the RISC-V core to support debug are kept to a minimum. There is a special execution mode (Debug Mode) and a few extra CSRs. The DM takes care of the rest.

In order to be compliant with this specification an implementation must implement everything described in this section that is not explicitly listed as optional.

4.1 Debug Mode

Debug Mode is a special processor mode used only when a hart is halted for external debugging. Because the hart is halted, there is no forward progress in the normal instruction stream. How Debug Mode is implemented is not specified here.

When executing code due to an abstract command, the hart stays in Debug Mode and the following apply:

- 1. All operations are executed at machine mode privilege level, except that MPRV in mstatus may be ignored according to mprven. Full permission checks, or a relaxed set of permission checks, will apply according to relaxedpriv.
- 2. All interrupts (including NMI) are masked.
- 3. Exceptions don't update any registers. That includes cause, epc, tval, dpc, and mstatus. They do end execution of the Program Buffer.
- 4. No action is taken if a trigger matches.
- 5. If stopcount is 0 then counters continue. If it is 1 then counters are stopped.
- 6. If stoptime is 0 then timers continue. If it is 1 then timers are stopped.
- 7. The wfi instruction acts as a nop.
- 8. Almost all instructions that change the privilege level have undefined behavior. This includes ecall, mret, sret, and uret. (To change the privilege level, the debugger can write prv in dcsr). The only exception is ebreak, which ends execution of the Program Buffer when executed.
- 9. Completing Program Buffer execution is considered output for the purpose of fence instructions.

- 10. All control transfer instructions may act as illegal instructions if their destination is in the Program Buffer. If one such instruction acts as an illegal instruction, all such instructions must act as illegal instructions.
- 11. All control transfer instructions may act as illegal instructions if their destination is outside the Program Buffer. If one such instruction acts as an illegal instruction, all such instructions must act as illegal instructions.
- 12. Instructions that depend on the value of the PC (e.g. auipc) may act as illegal instructions.
- 13. Effective XLEN is DXLEN.
- 14. Forward progress is guaranteed.

In general, the debugger is expected to be able to simulate all the effects of MPRV. The exception is the case of Sv32 systems, which need MPRV functionality in order to access 34-bit physical addresses. Other systems are likely to tie mprven to 0.

4.2 Load-Reserved/Store-Conditional Instructions

The reservation registered by an lr instruction on a memory address may be lost when entering Debug Mode or while in Debug Mode. This means that there may be no forward progress if Debug Mode is entered between lr and sc pairs.

This is a behavior that debug users must be aware of. If they have a breakpoint set between a lr and sc pair, or are stepping through such code, the sc may never succeed. Fortunately in general use there will be very few instructions in such a sequence, and anybody debugging it will quickly notice that the reservation is not occurring. The solution in that case is to set a breakpoint on the first instruction after the sc and run to it. A higher level debugger may choose to automate this.

4.3 Wait for Interrupt Instruction

If halt is requested while wfi is executing, then the hart must leave the stalled state, completing this instruction's execution, and then enter Debug Mode.

4.4 Single Step

4.4.1 Step Bit In Dcsr

This method is only available to external debuggers, and is the preferred way to single step.

An external debugger can cause a halted hart to execute a single instruction or trap and then re-enter Debug Mode by setting step before setting resumereq.

If control is transferred to a trap handler while executing the instruction, then Debug Mode is re-entered immediately after the PC is changed to the trap handler, and the appropriate tval and

cause registers are updated. In this case none of the trap handler is executed, and if the cause was a pending interrupt no instructions might be executed at all.

If executing or fetching the instruction causes a trigger to fire, Debug Mode is re-entered immediately after that trigger has fired. In that case cause is set to 2 (trigger) instead of 4 (single step). Whether the instruction is executed or not depends on the specific configuration of the trigger.

If the instruction that is executed causes the PC to change to an address where an instruction fetch causes an exception, that exception does not occur until the next time the hart is resumed. Similarly, a trigger at the new address does not fire until the hart actually attempts to execute that instruction.

If the instruction being stepped over is wfi and would normally stall the hart, then instead the instruction is treated as nop.

4.4.2 Icount Trigger

Native debuggers won't have access to dcsr, but can use the trigger by setting to 1.

This approach does have some limitations:

- 1. Interrupts will fire as usual. Debuggers that want to disable interrupts while stepping must disable them by changing mstatus, and specially handle instructions that read mstatus.
- 2. wfi instructions are not treated specially and might take a very long time to complete.

4.5 Reset

If the halt signal (driven by the hart's halt request bit in the Debug Module) or resethaltreq are asserted when a hart comes out of reset, the hart must enter Debug Mode before executing any instructions, but after performing any initialization that would usually happen before the first instruction is executed.

4.6 Resume

When a hart resumes:

- 1. pc changes to the value stored in dpc.
- 2. The current privilege mode is changed to that specified by prv.
- 3. If the new privilege mode is less privileged than M mode, MPRV in mstatus is cleared.
- 4. The hart is no longer in debug mode.

4.7 dret Instruction

To return from Debug Mode, a new instruction is defined: dret. It has an encoding of 0x7b200073. On harts which support this instruction, executing dret in Debug Mode cause the hart to resume as described above.

Executing dret outside of Debug Mode causes an illegal instruction exception.

It is not necessary for the debugger to know whether an implementation supports dret, as the Debug Module will ensure that it is executed if necessary. It is defined in this specification only to reserve the opcode and allow for reusable Debug Module implementations.

4.8 XLEN

While in Debug Mode, XLEN is DXLEN. It is up to the debugger to determine the XLEN during normal program execution (by looking at misa) and to clearly communicate this to the user.

4.9 Core Debug Registers

The supported Core Debug Registers must be implemented for each hart that can be debugged. They are CSRs, accessible using the RISC-V csr opcodes and optionally also using abstract debug commands.

These registers are only accessible from Debug Mode.

Table 4.1: Core Debug Registers

Address	Name	Page
0x7b0	Debug Control and Status (dcsr)	47
0x7b1	Debug PC (dpc)	50
0x7b2	Debug Scratch Register 0 (dscratch0)	50
0x7b3	Debug Scratch Register 1 (dscratch1)	50

4.9.1 Debug Control and Status (dcsr, at 0x7b0)

cause priorities are assigned such that the least predictable events have the highest priority.

31	28	27	16		15		14	13	3		12		11	10)
xdebı	ıgver	0		eb	reak	кm	0	ebre	aks	eb	reaku	ste	epie	stopc	ount
4	Į.	12			1		1	1			1		1	1	
		9		8	6	5		4	3		2	1	0		
		stoptin	ne	caı	ise	0	mp	rven	nm	ip	step	р	rv		
		1		3	;	1		1	1		1	:	2		

Field	Description	Access	Reset
xdebugver	0: There is no external debug support.	R	Preset
	4: External debug support exists as it is described		
	in this document.		
	15: There is external debug support, but it does		
	not conform to any available version of this spec.		
ebreakm	0: ebreak instructions in M-mode behave as de-	R/W	0
	scribed in the Privileged Spec.		
	1: ebreak instructions in M-mode enter Debug		
	Mode.		
ebreaks	0: ebreak instructions in S-mode behave as de-	WARL	0
	scribed in the Privileged Spec.		
	1: ebreak instructions in S-mode enter Debug		
	Mode.		
	This bit is hardwired to 0 if the hart does not		
	support S mode.	TIVA D.T.	0
ebreaku	0: ebreak instructions in U-mode behave as de-	WARL	0
	scribed in the Privileged Spec.		
	1: ebreak instructions in U-mode enter Debug		
	Mode.		
	This bit is hardwired to 0 if the hart does not		
stepie	support U mode. 0: Interrupts (including NMI) are disabled during	WARL	0
steple	single stepping.	WAILL	0
	1: Interrupts (including NMI) are enabled during		
	single stepping.		
	Implementations may hard wire this bit to 0. In		
	that case interrupt behavior can be emulated by		
	the debugger.		
	The debugger must not change the value of this		
	bit while the hart is running.		
stopcount	0: Increment counters as usual.	WARL	Preset
	1: Don't increment any hart-local counters while		
	in Debug Mode or on ebreak instructions that		
	cause entry into Debug Mode. These counters		
	include the instret CSR. On single-hart cores		
	cycle should be stopped, but on multi-hart cores		
	it must keep incrementing.		
	An implementation may hardwire this bit to 0 or		
	1.		
stoptime	0: Increment timers as usual.	WARL	Preset
	1: Don't increment any hart-local timers while in		
	Debug Mode.		
	An implementation may hardwire this bit to 0 or		
	1.		

Continued on next page

Field	Description	Access	Reset
cause	Explains why Debug Mode was entered.	R	0
	When there are multiple reasons to enter Debug		
	Mode in a single cycle, hardware should set cause		
	to the cause with the highest priority.		
	1: An ebreak instruction was executed. (priority		
	3)		
	2: The Trigger Module caused a breakpoint exception. (priority 4)		
	3: The debugger requested entry to Debug Mode		
	using haltreq. (priority 1)		
	4: The hart single stepped because step was set.		
	(priority 0, lowest)		
	5: The hart halted directly out of reset due to		
	resethaltreq. It is also acceptable to report 3 when		
	this happens. (priority 2)		
	6: The hart halted because it's part of a halt		
	group. (priority 5, highest) Harts may report 3		
	for this cause instead.		
	Other values are reserved for future use.		
mprven	0: MPRV in mstatus is ignored in Debug Mode.	WARL	Preset
	1: MPRV in mstatus takes effect in Debug Mode.		
	Implementing this bit is optional. It may be tied		
	to either 0 or 1.		
nmip	When set, there is a Non-Maskable-Interrupt	R	0
	(NMI) pending for the hart.		
	Since an NMI can indicate a hardware error condi-		
	tion, reliable debugging may no longer be possible		
	once this bit becomes set. This is implementation-		
	dependent.		
step	When set and not in Debug Mode, the hart will	R/W	0
	only execute a single instruction and then enter		
	Debug Mode. See Section 4.4.1 for details.		
	The debugger must not change the value of this		
	bit while the hart is running.	TITA D.T.	0
prv	Contains the privilege level the hart was operating	WARL	3
	in when Debug Mode was entered. The encoding		
	is described in Table 4.5. A debugger can change		
	this value to change the hart's privilege level when		
	exiting Debug Mode.		
	Not all privilege levels are supported on all harts.		
	If the encoding written is not supported or the		
	debugger is not allowed to change to it, the hart		
	may change to any supported privilege level.		

4.9.2 Debug PC (dpc, at 0x7b1)

Upon entry to debug mode, dpc is updated with the virtual address of the next instruction to be executed. The behavior is described in more detail in Table 4.3.

Table 1.9. Virtual address in BT e apon Besug wode Entry				
Cause	Virtual Address in DPC			
ebreak	Address of the ebreak instruction			
single step	Address of the instruction that would be executed			
	next if no debugging was going on. Ie. $pc + 4$ for			
	32-bit instructions that don't change program flow,			
	the destination PC on taken jumps/branches, etc.			
trigger module	If is 0, the address of the instruction which caused the			
	trigger to fire. If is 1, the address of the next			
	instruction to be executed at the time that debug			
	mode was entered.			
halt request	Address of the next instruction to be executed at the			
	time that debug mode was entered			

Table 4.3: Virtual address in DPC upon Debug Mode Entry

When resuming, the hart's PC is updated to the virtual address stored in dpc. A debugger may write dpc to change where the hart resumes.

DXLEN-1	0
dpc	
DXLEN	

4.9.3 Debug Scratch Register 0 (dscratch0, at 0x7b2)

Optional scratch register that can be used by implementations that need it. A debugger must not write to this register unless hartinfo explicitly mentions it (the Debug Module may use this register internally).

4.9.4 Debug Scratch Register 1 (dscratch1, at 0x7b3)

Optional scratch register that can be used by implementations that need it. A debugger must not write to this register unless hartinfo explicitly mentions it (the Debug Module may use this register internally).

4.10 Virtual Debug Registers

A virtual register is one that doesn't exist directly in the hardware, but that the debugger exposes as if it does. Debug software should implement them, but hardware can skip this section. Virtual

Table 4.5: Privilege Level Encoding

Encoding	Privilege Level
0	User/Application
1	Supervisor
3	Machine

registers exist to give users access to functionality that's not part of standard debuggers without requiring them to carefully modify debug registers while the debugger is also accessing those same registers.

Table 4.4: Virtual Core Debug Registers

		0
Address	Name	Page
virtual	Privilege Level (priv)	51

4.10.1 Privilege Level (priv, at virtual)

Users can read this register to inspect the privilege level that the hart was running in when the hart halted. Users can write this register to change the privilege level that the hart will run in when it resumes.

This register contains prv from dcsr, but in a place that the user is expected to access. The user should not access dcsr directly, because doing so might interfere with the debugger.

Field	Description	Access	Reset
prv	Contains the privilege level the hart was operat-	R/W	0
	ing in when Debug Mode was entered. The en-		
	coding is described in Table 4.5, and matches the		
	privilege level encoding from the Privileged Spec.		
	A user can write this value to change the hart's		
	privilege level when exiting Debug Mode.		

Chapter 5

Trigger Module

Triggers can cause a breakpoint exception, entry into Debug Mode, or a trace action without having to execute a special instruction. This makes them invaluable when debugging code from ROM. They can trigger on execution of instructions at a given memory address, or on the address/data in loads/stores. These are all features that can be useful without having the Debug Module present, so the Trigger Module is broken out as a piece that can be implemented separately.

A hart can be compliant with this specification without implementing any trigger functionality at all, but if it is implemented then it must conform to this section. If triggers aren't implemented, the CSRs may not exist at all and accessing them results in an illegal instruction exception.

Triggers do not fire while in Debug Mode.

5.1 Enumeration

Each trigger may support a variety of features. A debugger can build a list of all triggers and their features as follows:

- 1. Write 0 to . If this results in an illegal instruction exception, then there are no triggers implemented.
- 2. Read back and check that it contains the written value. If not, exit the loop.
- 3. Read
- 4. If that caused an exception, the debugger must read to discover the type. (If is 0, this trigger doesn't exist. Exit the loop.)
- 5. If is 1, this trigger doesn't exist. Exit the loop.
- 6. Otherwise, the selected trigger supports the types discovered in .
- 7. Repeat, incrementing the value in .

The above algorithm reads back so that implementations which have 2^n triggers only need to implement n bits of .

The algorithm checks and in case the implementation has m bits of but fewer than 2^m triggers.

5.2 Actions

Triggers can be configured to take one of several actions when they fire. Table 5.1 lists all options.

Table 5.1: encoding

	Table 9.1. cheoding				
Value	Description				
0	Raise a breakpoint exception into M-Mode. (Used				
	when software wants to use the trigger module				
	without an external debugger attached.) mepc must				
	contain the virtual address of the next instruction				
	that must be executed to preserve the program flow.				
1	Enter Debug Mode. dpc must contain the virtual				
	address of the next instruction that must be executed				
	to preserve the program flow.				
	This action is only legal when the trigger's is 1. Since				
	the tdata registers are WARL, hardware should clear				
	the action field whenever the action field is 1, is				
	cleared, and the new value of the action field would				
	also be 1.				
2 - 5	Reserved for use by the trace specification.				
other	Reserved for future use.				

5.3 Priority

Table 5.3 lists the synchronous exceptions from the Privileged Spec, and where the various types of triggers fit in. The first 3 columns come from the Privileged Spec, and the final column shows where triggers fit in. Priorities in the table are separated by horizontal lines, so e.g. etrigger and itrigger have the same priority. If this table contradicts the table in the Privileged Spec, then the latter takes precedence.

This table only applies if triggers are precise. Otherwise triggers will fire some indeterminate time after the event, and the priority is irrelevant. When triggers are chained, the priority is the lowest priority of the triggers in the chain.

Priority	Exception	Description	Trigger
	Code		
Highest	3		etrigger
	3		icount
	3		itrigger
	3		mcontrol after
			(on previous instruction)
	3	Instruction address breakpoint	mcontrol execute address before
	12	Instruction page fault	
	1	Instruction access fault	
	3		mcontrol execute data before
	2	Illegal instruction	
	0	Instruction address misaligned	
	8, 9, 11	Environment call	
	3	Environment break	
	3	Load/Store/AMO address breakpoint	mcontrol load/store address before
	3		mcontrol store data before
	6	Store/AMO address misaligned	
	4	Load address misaligned	
	15	Store/AMO page fault	
	13	Load page fault	
	7	Store/AMO access fault	
	5	Load access fault	
Lowest	3		mcontrol load data before

Table 5.2: Synchronous exception priority in decreasing priority order.

When multiple triggers in the same priority fire at once, (if implemented) is set for all of them. If one of these triggers has the "enter Debug Mode" action (1) and another trigger has the "raise a breakpoint exception" action (0), the preferred behavior is to have both actions take place. It is implementation-dependent which of the two happens first. This ensures both that the presence of an external debugger doesn't affect execution and that a trigger set by user code doesn't affect the external debugger. If this is not implemented, then the hart must enter Debug Mode and ignore the breakpoint exception. In the latter case, of the trigger whose action is 0 must still be set, giving a debugger an opportunity to handle this case. What happens with trace actions when triggers with different actions are also firing is left to the trace specification.

5.4 Native M-Mode Triggers

Triggers can be used for native debugging. On a fully featured system triggers will be set using or , and when firing they can cause a breakpoint exception to trap to a more privileged mode. It is possible to set triggers natively to fire in M mode as well. In that case there is no higher privilege mode to trap to. When such a trigger causes a breakpoint exception while already in a trap handler, this will leave the system unable to resume normal execution.

On full-featured systems this is a remote corner case that can probably be ignored. On systems that only implement M mode, however, it is recommended to implement one of two solutions to this problem. This way triggers can be useful for native debugging of even M mode code.

The simple solution is to have the hardware prevent triggers with action=0 from firing while in M mode and while MIE in mstatus is 0. Its limitation is that interrupts might be disabled at other times when a user might want triggers to fire.

A more complex solution is to implement and in . This solution has the benefit that it only disables triggers during the trap handler.

A user setting M mode triggers that cause breakpoint exceptions will have to be aware of any problems that might come up with the particular system they are working on.

5.5 Trigger Registers

These registers are CSRs, accessible using the RISC-V csr opcodes and optionally also using abstract debug commands.

Almost all trigger functionality is optional. All tdata registers follow write-any-read-legal semantics. If a debugger writes an unsupported configuration, the register will read back a value that is supported (which may simply be a disabled trigger). This means that a debugger must always read back values it writes to tdata registers, unless it already knows already what is supported. Writes to one tdata register may not modify the contents of other tdata registers, nor the configuration of any trigger besides the one that is currently selected.

Chapter 6

Debug Transport Module (DTM)

Debug Transport Modules provide access to the DM over one or more transports (e.g. JTAG or USB).

There may be multiple DTMs in a single platform. Ideally every component that communicates with the outside world includes a DTM, allowing a platform to be debugged through every transport it supports. For instance a USB component could include a DTM. This would trivially allow any platform to be debugged over USB. All that is required is that the USB module already in use also has access to the Debug Module Interface.

Using multiple DTMs at the same time is not supported. It is left to the user to ensure this does not happen.

This specification defines a JTAG DTM in Section 6.1. Additional DTMs may be added in future versions of this specification.

An implementation can be compliant with this specification without implementing any of this section. In that case it must be advertised as conforming to "RISC-V Debug Specification 0.14.0-DRAFT, with custom DTM." If the JTAG DTM described here is implemented, it must be advertised as conforming to the "RISC-V Debug Specification 0.14.0-DRAFT, with JTAG DTM."

6.1 JTAG Debug Transport Module

This Debug Transport Module is based around a normal JTAG Test Access Port (TAP). The JTAG TAP allows access to arbitrary JTAG registers by first selecting one using the JTAG instruction register (IR), and then accessing it through the JTAG data register (DR).

6.1.1 JTAG Background

JTAG refers to IEEE Std 1149.1-2013. It is a standard that defines test logic that can be included in an integrated circuit to test the interconnections between integrated circuits, test the integrated

circuit itself, and observe or modify circuit activity during the components normal operation. This specification uses the latter functionality. The JTAG standard defines a Test Access Port (TAP) that can be used to read and write a few custom registers, which can be used to communicate with debug hardware in a component.

6.1.2 JTAG DTM Registers

JTAG TAPs used as a DTM must have an IR of at least 5 bits. When the TAP is reset, IR must default to 00001, selecting the IDCODE instruction. A full list of JTAG registers along with their encoding is in Table 6.1. If the IR actually has more than 5 bits, then the encodings in Table 6.1 should be extended with 0's in their most significant bits, except for the 0x1f encoding of BYPASS, which must be extended with 1's in the most significant bits. The only regular JTAG registers a debugger might use are BYPASS and IDCODE, but this specification leaves IR space for many other standard JTAG instructions. Unimplemented instructions must select the BYPASS register.

Address Name Description Page **BYPASS** JTAG recommends this encoding 0x000x01**IDCODE** To identify a specific silicon version For Debugging 0x10DTM Control and Status (dtmcs) 58 0x11Debug Module Interface Access (dmi) For Debugging 59 Reserved for future RISC-V debugging Reserved (BYPASS) 0x120x13Reserved (BYPASS) Reserved for future RISC-V debugging Reserved for future RISC-V debugging 0x14Reserved (BYPASS) Reserved (BYPASS) Reserved for future RISC-V standards 0x150x16Reserved (BYPASS) Reserved for future RISC-V standards Reserved (BYPASS) Reserved for future RISC-V standards 0x170x1f**BYPASS** JTAG requires this encoding

Table 6.1: JTAG DTM TAP Registers

6.1.3 IDCODE (at 0x01)

This register is selected (in IR) when the TAP state machine is reset. Its definition is exactly as defined in IEEE Std 1149.1-2013.

This entire register is read-only.

31	28	27	12	11	1	0
Version		PartNumber		Manufld		1
4		1	6	11		1

Field	Description	Access	Reset
Version	Identifies the release version of this part.	R	Preset
PartNumber	Identifies the designer's part number of this part.	R	Preset
Manufld	Identifies the designer/manufacturer of this part.	R	Preset
	Bits 6:0 must be bits 6:0 of the designer/manufac-		
	turer's Identification Code as assigned by JEDEC		
	Standard JEP106. Bits 10:7 contain the modulo-		
	16 count of the number of continuation characters		
	(0x7f) in that same Identification Code.		

6.1.4 DTM Control and Status (dtmcs, at 0x10)

The size of this register will remain constant in future versions so that a debugger can always determine the version of the DTM.

	31	18	17	16	15	14	12	11	10	9	4	3	0	
0		0	dmihardreset	dmireset	0	idle dmistat		abi	ts	vers	sion			
		14	1	1	1	:	3		2	6			4	

Description	Access	Reset
Writing 1 to this bit does a hard reset of the DTM,	W1	-
causing the DTM to forget about any outstand-		
ing DMI transactions, and returning all registers		
and internal state to their reset value. In gen-		
eral this should only be used when the Debugger		
has reason to expect that the outstanding DMI		
transaction will never complete (e.g. a reset con-		
dition caused an inflight DMI transaction to be		
cancelled).		
Writing 1 to this bit clears the sticky error state,	W1	-
but does not affect outstanding DMI transactions.		
This is a hint to the debugger of the minimum	R	Preset
number of cycles a debugger should spend in Run-		
Test/Idle after every DMI scan to avoid a 'busy'		
return code (dmistat of 3). A debugger must still		
check dmistat when necessary.		
0: It is not necessary to enter Run-Test/Idle at		
all.		
1: Enter Run-Test/Idle and leave it immediately.		
2: Enter Run-Test/Idle and stay there for 1 cycle		
before leaving.		
And so on.		
	Writing 1 to this bit does a hard reset of the DTM, causing the DTM to forget about any outstanding DMI transactions, and returning all registers and internal state to their reset value. In general this should only be used when the Debugger has reason to expect that the outstanding DMI transaction will never complete (e.g. a reset condition caused an inflight DMI transaction to be cancelled). Writing 1 to this bit clears the sticky error state, but does not affect outstanding DMI transactions. This is a hint to the debugger of the minimum number of cycles a debugger should spend in Run-Test/Idle after every DMI scan to avoid a 'busy' return code (dmistat of 3). A debugger must still check dmistat when necessary. 0: It is not necessary to enter Run-Test/Idle at all. 1: Enter Run-Test/Idle and leave it immediately. 2: Enter Run-Test/Idle and stay there for 1 cycle before leaving.	Writing 1 to this bit does a hard reset of the DTM, causing the DTM to forget about any outstanding DMI transactions, and returning all registers and internal state to their reset value. In general this should only be used when the Debugger has reason to expect that the outstanding DMI transaction will never complete (e.g. a reset condition caused an inflight DMI transaction to be cancelled). Writing 1 to this bit clears the sticky error state, but does not affect outstanding DMI transactions. This is a hint to the debugger of the minimum number of cycles a debugger should spend in Run-Test/Idle after every DMI scan to avoid a 'busy' return code (dmistat of 3). A debugger must still check dmistat when necessary. 0: It is not necessary to enter Run-Test/Idle at all. 1: Enter Run-Test/Idle and leave it immediately. 2: Enter Run-Test/Idle and stay there for 1 cycle before leaving. And so on.

 $Continued\ on\ next\ page$

Field	Description	Access	Reset
dmistat	0: No error.	R	0
	1: Reserved. Interpret the same as 2.		
	2: An operation failed (resulted in op of 2).		
	3: An operation was attempted while a DMI ac-		
	cess was still in progress (resulted in op of 3).		
abits	The size of address in dmi.	R	Preset
version	0: Version described in spec version 0.11.	R	1
	1: Version described in spec version 0.13.		
	15: Version not described in any available version		
	of this spec.		

6.1.5 Debug Module Interface Access (dmi, at 0x11)

This register allows access to the Debug Module Interface (DMI).

In Update-DR, the DTM starts the operation specified in op unless the current status reported in op is sticky.

In Capture-DR, the DTM updates data with the result from that operation, updating op if the current op isn't sticky.

See Section B.1 for examples of how this is used.

The still-in-progress status is sticky to accommodate debuggers that batch together a number of scans, which must all be executed or stop as soon as there's a problem.

For instance a series of scans may write a Debug Program and execute it. If one of the writes fails but the execution continues, then the Debug Program may hang or have other unexpected side effects.

abits+33	34	33	2	1	Ĺ	0
address			data		ор	
abits			32		2	

Field	Description	Access	Reset
address	Address used for DMI access. In Update-DR this	R/W	0
	value is used to access the DM over the DMI.		
data	The data to send to the DM over the DMI during	R/W	0
	Update-DR, and the data returned from the DM		
	as a result of the previous operation.		

Continued on next page

Field	Description	Access	Reset
ор	When the debugger writes this field, it has the	R/W	0
	following meaning:		
	0: Ignore data and address. (nop)		
	Don't send anything over the DMI during		
	Update-DR. This operation should never result in		
	a busy or error response. The address and data		
	reported in the following Capture-DR are unde-		
	fined.		
	1: Read from address. (read)		
	2: Write data to address. (write)		
	3: Reserved.		
	When the debugger reads this field, it means the		
	following:		
	0: The previous operation completed successfully.		
	1: Reserved.		
	2: A previous operation failed. The data scanned		
	into dmi in this access will be ignored. This status		
	is sticky and can be cleared by writing dmireset in		
	dtmcs.		
	This indicates that the DM itself responded with		
	an error. There are no specified cases in which		
	the DM would respond with an error, and DMI is		
	not required to support returning errors.		
	3: An operation was attempted while a DMI re-		
	quest is still in progress. The data scanned into		
	dmi in this access will be ignored. This status is		
	sticky and can be cleared by writing dmireset in		
	dtmcs. If a debugger sees this status, it needs to		
	give the target more TCK edges between Update-		
	DR and Capture-DR. The simplest way to do that		
	is to add extra transitions in Run-Test/Idle.		

6.1.6 BYPASS (at 0x1f)

1-bit register that has no effect. It is used when a debugger does not want to communicate with this TAP.

This entire register is read-only.



6.1.7 Recommended JTAG Connector

To make it easy to acquire debug hardware, this spec recommends a connector that is compatible with the MIPI-10 .05 inch connector specification, as described in the MIPI Alliance Recommendation for Debug and Trace Connectors, Version 1.10.00, 16 March 2011.

The connector has .05 inch spacing, gold-plated male header with .016 inch thick hardened copper or beryllium bronze square posts (SAMTEC FTSH or equivalent). Female connectors are compatible $20\mu m$ gold connectors.

Viewing the male header from above (the pins pointing at your eye), a target's connector looks as it does in Table 6.5. The function of each pin is described in Table 6.7.

Table 6.5: MIPI-10 Connector Diagram

VREF DEBUG	1	2	TMS
GND	3	4	TCK
GND	5	6	TDO
GND or KEY	7	8	TDI
GND	9	10	nRESET

If a platform requires nTRST then it is permissible to reuse the nRESET pin as the nTRST signal. If a platform requires both system reset and TAP reset, the MIPI-20 connector should be used. Its physical connector is virtually identical to MIPI-10, except that it's twice as long, supporting twice as many pins. Its connector is show in Table 6.6.

Table 6.6: MIPI-20 Connector Diagram

Table 0:0: Will I 20 Conficctor Blagram					
1	2	TMS			
3	4	TCK			
5	6	TDO			
7	8	TDI			
9	10	nRESET			
11	12	RTCK			
13	14	nTRST_PD			
15	16	nTRST			
17	18	DBGRQ			
19	20	DBGACK			
	1 3 5 7 9 11 13 15	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18			

The same connectors can be used for 2-wire cJTAG. In that case TMS is used for TMSC, and TCK is used for TCKC.

Table 6.7: JTAG Connector Pinout

1	VREF DEBUG	Reference voltage for logic high.		
2	TMS	JTAG TMS signal, driven by the debug adapter.		
4	TCK	JTAG TCK signal, driven by the debug adapter.		
6	TDO	JTAG TDO signal, driven by the target.		
7	GND or KEY	This pin may be cut on the male and plugged on the		
		female header to ensure the header is always plugged		
		in correctly. It is, however, recommended to use this		
		pin as an additional ground, to allow for fastest TCK		
		speeds. A shrouded connector should be used to		
		prevent the cable from being plugged in incorrectly.		
8	TDI	JTAG TDI signal, driven by the debug adapter.		
10	nRESET	Active-low reset signal, driven by the debug adapter.		
		Asserting reset should reset any RISC-V cores as well		
		as any other peripherals on the PCB. It should not		
		reset the debug logic. This pin is optional but		
		strongly encouraged.		
		If necessary, this pin could be used as nTRST instead.		
		nRESET should never be connected to the TAP reset,		
		otherwise the debugger might not be able to debug		
		through a reset to discover the cause of a crash or to		
		maintain execution control after the reset.		
12	RTCK	Return test clock, driven by the target. A target may		
		relay the TCK signal here once it has processed it,		
		allowing a debugger to adjust its TCK frequency in		
		response.		
14	$nTRST_PD$	Test reset pull-down (optional), driven by the debug		
		adapter. Same function as nTRST, but with		
		pull-down resistor on target.		
16	nTRST	Test reset (optional), driven by the debug adapter.		
		Used to reset the JTAG TAP Controller.		
18	TRIGIN	Not used, driven low by the debug adapter.		
20	TRIGOUT	Not used, driven by the target.		

Appendix A

Hardware Implementations

Below are two possible implementations. A designer could choose one, mix and match, or come up with their own design.

A.1 Abstract Command Based

Halting happens by stalling the hart execution pipeline.

Muxes on the register file(s) allow for accessing GPRs and CSRs using the Access Register abstract command.

Memory is accessed using the Abstract Access Memory command or through System Bus Access.

This implementation could allow a debugger to collect information from the hart even when that hart is unable to execute instructions.

A.2 Execution Based

This implementation only implements the Access Register abstract command for GPRs on a halted hart, and relies on the Program Buffer for all other operations. It uses the hart's existing pipeline and ability to execute from arbitrary memory locations to avoid modifications to a hart's datapath.

When the halt request bit is set, the Debug Module raises a special interrupt to the selected harts. This interrupt causes each hart to enter Debug Mode and jump to a defined memory region that is serviced by the DM and is only accessible to the harts in Debug Mode. When taking this trap, pc is saved to dpc and cause is updated in dcsr.

The code in the Debug Module causes the hart to execute a "park loop." In the park loop the hart writes its mhartid to a memory location within the Debug Module to indicate that it is halted. To allow the DM to individually control one out of several halted harts, each hart polls for flags in a DM-controlled memory location to determine whether the debugger wants it to execute the

Program Buffer or perform a resume.

To execute an abstract command, the DM first populates some internal words of program buffer according to command. When transfer is set, the DM populates these words with lw <gpr>, 0x400(zero) or sw 0x400(zero), <gpr>. 64- and 128-bit accesses use ld/sd and lq/sq respectively. If transfer is not set, the DM populates these instructions as nops. If is set, execution continues to the debugger-controlled Program Buffer, otherwise the DM causes a ebreak to execute immediately.

When ebreak is executed (indicating the end of the Program Buffer code) the hart returns to its park loop. If an exception is encountered, the hart jumps to a debug trap address within the Debug Module. The code at that address causes the hart to write to an address in the Debug Module which indicates exception. This address is considered I/O for fence instructions (see #9 on page 44). Then the hart jumps back to the park loop. The DM infers from the write that there was an exception, and sets cmderr appropriately.

To resume execution, the debug module sets a flag which causes the hart to execute a dret. When dret is executed, pc is restored from dpc and normal execution resumes at the privilege set by prv.

data0 etc. are mapped into regular memory at an address relative to zero with only a 12-bit imm. The exact address is an implementation detail that a debugger must not rely on. For example, the data registers might be mapped to 0x400.

For additional flexibility, progbuf0, etc. are mapped into regular memory immediately preceding data0, in order to form a contiguous region of memory which can be used for either program execution or data transfer.

A.3 Debug Module Interface Signals

As stated in section 3.1 the details of the DMI are left to the system designer. It is quite often the case that only one DTM and one DM is implemented. In this case it might be useful to comply with the signals suggested in table A.1, which is the implementation used in the open-source rocket-chip RISC-V core.

The DTM can start a request when the DM sets REQ_READY to 1. When this is the case REQ_OP can be set to 1 for a read or 2 for a write request. The desired address is driven with the REQ_ADDRESS signal. Finally REQ_VALID is set high, indicating to the DM that a valid request is pending.

The DM must respond to a request from the DTM when RSP_READY is high. The status of the response is indicated by the RSP_OP signal (see op). The data of the response is driven to RSP_DATA. A pending response is signalled by setting RSP_VALID.

Signal	Width	Source	Description
REQ_VALID	1	DTM	Indicates that the a valid request is pending
REQ_READY	1	DM	Indicates that the DM is able to process a request
REQ_ADDRESS	abits	DTM	Requested address
REQ_DATA	32	DTM	Requested data
REQ_OP	2	DTM	Same meaning as the op field
RSP_VALID	1	DM	Indicates that the a valid respond is pending
RSP_READY	1	DTM	Indicates that the DTM is able to process a respond
RSP_DATA	32	DM	Response data
RSP_OP	2	DM	Same meaning as the op field

Table A.1: Signals for the suggested DMI between one DTM and one DM

Appendix B

Debugger Implementation

This section details how an external debugger might use the described debug interface to perform some common operations on RISC-V cores using the JTAG DTM described in Section 6.1. All these examples assume a 32-bit core but it should be easy to adapt the examples to 64- or 128-bit cores.

To keep the examples readable, they all assume that everything succeeds, and that they complete faster than the debugger can perform the next access. This will be the case in a typical JTAG setup. However, the debugger must always check the sticky error status bits after performing a sequence of actions. If it sees any that are set, then it should attempt the same actions again, possibly while adding in some delay, or explicit checks for status bits.

B.1 Debug Module Interface Access

To read an arbitrary Debug Module register, select dmi, and scan in a value with op set to 1, and address set to the desired register address. In Update-DR the operation will start, and in Capture-DR its results will be captured into data. If the operation didn't complete in time, op will be 3 and the value in data must be ignored. The busy condition must be cleared by writing dmireset in dtmcs, and then the second scan scan must be performed again. This process must be repeated until op returns 0. In later operations the debugger should allow for more time between Capture-DR and Update-DR.

To write an arbitrary Debug Bus register, select dmi, and scan in a value with op set to 2, and address and data set to the desired register address and data respectively. From then on everything happens exactly as with a read, except that a write is performed instead of the read.

It should almost never be necessary to scan IR, avoiding a big part of the inefficiency in typical JTAG use.

B.2 Checking for Halted Harts

A user will want to know as quickly as possible when a hart is halted (e.g. due to a breakpoint). To efficiently determine which harts are halted when there are many harts, the debugger uses the haltsum registers. Assuming the maximum number of harts exist, first it checks haltsum3. For each bit set there, it writes hartsel, and checks haltsum2. This process repeats through haltsum1 and haltsum0. Depending on how many harts exist, the process should start at one of the lower haltsum registers.

B.3 Halting

To halt one or more harts, the debugger selects them, sets haltreq, and then waits for allhalted to indicate the harts are halted. Then it can clear haltreq to 0, or leave it high to catch a hart that resets while halted.

B.4 Running

First, the debugger should restore any registers that it has overwritten. Then it can let the selected harts run by setting resumereq. Once allresumeack is set, the debugger knows the hart has resumed, and it can clear resumereq. Harts might halt very quickly after resuming (e.g. by hitting a software breakpoint) so the debugger cannot use allhalted/anyhalted to check whether the hart resumed.

B.5 Single Step

Using the hardware single step feature is almost the same as regular running. The debugger just sets step in dcsr before letting the hart run. The hart behaves exactly as in the running case, except that interrupts may be disabled (depending on stepie) and it only fetches and executes a single instruction before re-entering Debug Mode.

B.6 Accessing Registers

B.6.1 Using Abstract Command

Read so using abstract command:

Op	Address	Value	Comment
Write	command	aarsize = 2, transfer, regno =	Read s0
		0x1008	
Read	data0	-	Returns value that was in so

Write mstatus using abstract command:

Op	Address	Value	Comment
Write	data0	new value	
Write	command	aarsize = 2, transfer, write,	Write mstatus
		$regno = 0 \mathbf{x} 300$	

B.6.2 Using Program Buffer

Abstract commands are used to exchange data with GPRs. Using this mechanism, other registers can be accessed by moving their value into/out of GPRs.

Write mstatus using program buffer:

Op	Address	Value	Comment
Write	progbuf0	csrw s0, MSTATUS	
Write	progbuf1	ebreak	
Write	data0	new value	
Write	command	aarsize = 2, postexec, transfer,	Write so, then execute pro-
		write, regno = $0x1008$	gram buffer

Read f1 using program buffer:

Op	Address	Value	Comment
Write	progbuf0	fmv.x.s s0, f1	
Write	progbuf1	ebreak	
Write	command	postexec	Execute program buffer
Write	command	transfer, regno = $0x1008$	read s0
Read	data0	-	Returns the value that was in
			f1

B.7 Reading Memory

B.7.1 Using System Bus Access

With system bus access, addresses are physical system bus addresses.

Read a word from memory using system bus access:

Op	Address	Value	Comment
Write	sbcs	sbaccess = 2, $sbreadonaddr$	Setup
Write	sbaddress0	address	
Read	sbdata0	-	Value read from memory

Read block of memory using system bus access:

Op	Address	Value	Comment
Write	sbcs	sbaccess = 2, $sbreadonaddr$,	Turn on autoread and autoincrement
		sbreadondata, sbautoincrement	
Write	sbaddress0	address	Writing address triggers read and increment
Read	sbdata0	-	Value read from memory
Read	sbdata0	-	Next value read from memory
Write	sbcs	0	Disable autoread
Read	sbdata0	-	Get last value read from memory.

B.7.2 Using Program Buffer

Through the Program Buffer, the hart performs the memory accesses. Addresses are physical or virtual (depending on mprven and other system configuration).

Read a word from memory using program buffer:

Op	Address	Value	Comment
Write	progbuf0	lw s0, 0(s0)	
Write	progbuf1	ebreak	
Write	data0	address	
Write	command	write, postexec, regno =	Write so, then execute pro-
		0x1008	gram buffer
Write	command	regno = 0 x 1008	Read s0
Read	data0	-	Value read from memory

Read block of memory using program buffer:

Op	Address	Value	Comment
Write	progbuf0	lw s1, 0(s0)	
Write	progbuf1	addi s0, s0, 4	
Write	progbuf2	ebreak	
Write	data0	address	
Write	command	write, postexec, regno = $0x1008$	Write s0, then execute program buffer
Write	command	postexec, regno = 0x1009	Read s1, then execute program buffer
Write	abstractauto	autoexecdata [0]	Set autoexecdata [0]
Read	data0	-	Get value read from memory, then execute program buffer
Read	data0	-	Get next value read from memory, then execute pro- gram buffer
Write	abstractauto	0	Clear autoexecdata [0]
Read	data0	-	Get last value read from memory.

B.7.3 Using Abstract Memory Access

Abstract memory accesses act as if they are performed by the hart, although the actual implementation may differ.

Read a word from memory using abstract memory access:

Op	Address	Value	Comment
Write	data1	address	
Write	command	cmdtype=2, aamsize =2	
Read	data0	-	Value read from memory

Read block of memory using abstract memory access:

Op	Address	Value	Comment
Write	abstractauto	1	Re-execute the command
			when data0 is accessed
Write	data1	address	
Write	command	cmdtype=2, $aamsize =2$,	
		aampostincrement = 1	
Read	data0	-	Read value, and trigger read-
			ing of next address
Write	abstractauto	0	Disable auto-exec
Read	data0	-	Get last value read from
			memory.

B.8 Writing Memory

B.8.1 Using System Bus Access

With system bus access, addresses are physical system bus addresses.

Write a word to memory using system bus access:

Op	Address	Value	Comment
Write	sbaddress0	address	
Write	sbdata0	value	

Write a block of memory using system bus access:

Op	Address	Value	Comment
Write	sbcs	sbaccess = 2, $sbautoincrement$	Turn on autoincrement
Write	sbaddress0	address	
Write	sbdata0	value0	
Write	sbdata0	value1	
•••			
Write	sbdata0	valueN	

B.8.2 Using Program Buffer

Through the Program Buffer, the hart performs the memory accesses. Addresses are physical or virtual (depending on mprven and other system configuration).

Write a word to memory using program buffer:

Op	Address	Value	Comment
Write	progbuf0	sw s1, 0(s0)	
Write	progbuf1	ebreak	
Write	data0	address	
Write	command	write, regno = $0x1008$ W	Vrite s0
Write	data0	value	
Write	command	write, postexec, regno = W	Write s1, then execute pro-
		0x1009 gr	ram buffer

Write block of memory using program buffer:

Op	Address	Value	Comment
Write	progbuf0	sw s1, 0(s0)	
Write	progbuf1	addi s0, s0, 4	
Write	progbuf2	ebreak	
Write	data0	address	
Write	command	write, regno = $0x1008$	Write s0
Write	data0	value0	
Write	command	write, postexec, regno =	Write s1, then execute pro-
		0x1009	gram buffer
Write	abstractauto	autoexecdata [0]	Set autoexecdata [0]
Write	data0	value1	
Write	data0	valueN	_
Write	abstractauto	0	Clear autoexecdata [0]

B.8.3 Using Abstract Memory Access

Abstract memory accesses act as if they are performed by the hart, although the actual implementation may differ.

Write a word to memory using abstract memory access:

Op	Address	Value			Comment
Write	data1	address			
Write	data0	value			
Write	command	cmdtype=2,	aamsize	=2,	
		write=1			

Write a block of memory using abstract memory access:

Op	Address	Value	Comment
Write	data1	address	
Write	data0	value0	
Write	command	cmdtype=2, $aamsize =2$,	
		write=1, aampostincrement	
		=1	
Write	abstractauto	1	Re-execute the command
			when data0 is accessed
Write	data0	value1	
Write	data0	value2	
•••			
Write	data0	valueN	
Write	abstractauto	0	Disable auto-exec

B.9 Triggers

A debugger can use hardware triggers to halt a hart when a certain event occurs. Below are some examples, but as there is no requirement on the number of features of the triggers implemented by a hart, these examples may not be applicable to all implementations. When a debugger wants to set a trigger, it writes the desired configuration, and then reads back to see if that configuration is supported.

Enter Debug Mode just before the instruction at 0x80001234 is executed, to be used as an instruction breakpoint in ROM:

0x105c	action=1, match=0, m=1, s=1, u=1, execute=1
0x80001234	address

Enter Debug Mode right after the value at 0x80007f80 is read:

0x4159	timing=1, action=1, match=0, m=1, s=1, u=1,	
	load=1	
0x80007f80	address	

Enter Debug Mode right before a write to an address between 0x80007c80 and 0x80007cef (inclusive):

0	0x195a	action=1, chain=1, match=2, m=1, s=1, u=1,
		store=1
0	0x80007c80	start address (inclusive)
1	0x11da	action=1, match=3, m=1, s=1, u=1, store=1
1	0x80007cf0	end address (exclusive)

Enter Debug Mode right before a write to an address between 0x81230000 and 0x8123ffff (inclusive):

0x10da	action=1, match=1, m=1, s=1, u=1, store=1
0x81237fff	16 bits to match exactly, then 0, then all ones.

Enter Debug Mode right after a read from an address between 0x86753090 and 0x8675309f or between 0x96753090 and 0x9675309f (inclusive):

0	0x41a59	timing=1, action=1, chain=1, match=4, m=1, s=1,	
		u=1, load=1	
0	0xfff03090	Mask for low half, then match for low half	
1	0x412d9	timing=1, action=1, match=5, m=1, s=1, u=1,	
		load=1	
1	0xefff8675	Mask for high half, then match for high half	

B.10 Handling Exceptions

Generally the debugger can avoid exceptions by being careful with the programs it writes. Sometimes they are unavoidable though, e.g. if the user asks to access memory or a CSR that is not implemented. A typical debugger will not know enough about the platform to know what's going to happen, and must attempt the access to determine the outcome.

When an exception occurs while executing the Program Buffer, cmderr becomes set. The debugger can check this field to see whether a program encountered an exception. If there was an exception, it's left to the debugger to know what must have caused it.

B.11 Quick Access

There are a variety of instructions to transfer data between GPRs and the data registers. They are either loads/stores or CSR reads/writes. The specific addresses also vary. This is all specified in hartinfo. The examples here use the pseudo-op transfer dest, src to represent all these options.

Halt the hart for a minimum amount of time to perform a single memory write:

Op	Address	Value	Comment
Write	progbuf0	transfer arg2, s0	Save s0
Write	progbuf1	transfer s0, arg0	Read first argument (address)
Write	progbuf2	transfer arg0, s1	Save s1
Write	progbuf3	transfer s1, arg1	Read second argument (data)
Write	progbuf4	sw s1, 0(s0)	
Write	progbuf5	transfer s1, arg0	Restore s1
Write	progbuf6	transfer s0, arg2	Restore s0
Write	progbuf7	ebreak	
Write	data0	address	
Write	data1	data	
Write	command	0x10000000	Perform quick access

This shows an example of setting the bit in to enable a hardware breakpoint in M-mode. Similar quick access instructions could have been used previously to configure the trigger that is being enabled here:

Op	Address	Value	Comment
Write	progbuf0	transfer arg0, s0	Save s0
Write	progbuf1	li s0, (1 << 6)	Form the mask for bit
Write	progbuf2	csrrs x0, , s0	Apply the mask to
Write	progbuf3	transfer s0, arg2	Restore s0
Write	progbuf4	ebreak	
Write	command	0x10000000	Perform quick access

Appendix C

Change Log

Revision	Date	Author(s)	Description
09788a8	2020-07-29	Paul Donahue	Build draft PDF
cdd6c80	2020-07-29	Paul Donahue	Restore accidental whitespace changes
09cadd 9	2020-07-29	Paul Donahue	Add dmcontrol.relaxedpriv
2210002	2020-07-07	Tim Newsome	Rebuild PDF.
b9959e5	2020-06-30	Tim Newsome	Make explicit that aampost increment is optional. $(\#532)$
67fed8f	2020-06-19	Tim Newsome	Explicitly allow uni-directional external triggers. (#526)
9c69bf3	2020-06-09	Tim Newsome	Rebuild PDF.
85bf 4 df	2020-05-21	Tim Newsome	Add Kai Meinhard to contributors list.
2f1c133	2020-05-21	Kai Meinhard	Appendix B suggests signals for a DMI with one DTM connected to one DM (#524)
708b1e0	2020-04-10	Tim Newsome	Add Larry Madar.
e02a8b6	2020-04-07	Tim Newsome	Rebuild PDF.
372b27f	2020-03-23	Tim Newsome	All tdata functionality is optional (#444)
50f5c8f	2020-03-11	Tim Newsome	Explicitly allow hard-coded halt/resume groups. (#517)
f4794bb	2020-03-10	Tim Newsome	Rebuild PDF.
e3ec24e	2020-02-13	bdwyatt	Adding version encoding for 0.14 spec. (#512)
cf9a884	2020-02-11	Tim Newsome	Rebuild PDF.
fdd5ad6	2020-02-11	Philipp Wagner	dcsr.prv should be WARL, not R/W (#498)
38b2794	2020-02-11	Tim Newsome	sizehi only exists if Xlen¿64. (#514)
5a54283	2020-01-16	Tim Newsome	Use exception, trap, and interrupt as in ISA spec (#511)
a989a71	2020-01-13	Tim Newsome	Clarify dmireset/dmihardreset. (#508)
d10d8d0	2020-01-06	Tim Newsome	Rebuild PDF.
efc0143	2020-01-06	Tim Newsome	Clarify action=1 (enter Debug Mode) with dmode=0 (#501)
439fb93	2020-01-06	Tim Newsome	Fix conflict in sbdata0/sbautoincrement definition. (#507)
d35ce10	2019-12-10	Tim Newsome	Add resume groups. (#506)

0796690	2010 12 06	T: N	D -1:1.1 DDE
2726f30	2019-12-06	Tim Newsome	Rebuild PDF.
a310a37	2019-12-04	Tim Newsome	Make haltsum0 optional if there is only one hart.
			(#505)
349c826	2019-11-26	Tim Newsome	Halt state may not be preserved across reset. (#504)
4ab79d7	2019-11-26	Tim Newsome	Clear MPRV when resuming into lower privilege
			mode. $(#503)$
c9c286b	2019-11-22	Tim Newsome	Time may pass before dmactive becomes high.
			(#500)
9d55a57	2019-11-21	Megan Wachs	Make the emitted registers chisel3
014505f	2019-10-08	Tim Newsome	Rebuild PDF.
62c63b8	2019-10-04	Tim Newsome	Document forward progress guarantees in Debug
			Mode. (#496)
d933bec	2019-10-02	Tim Newsome	Rewrite/clarify DM Reset Control (#494)
039 bd5a	2019-09-23	Philipp Wagner	Fix wrong table reference (#484)
106b4f2	2019-09-16	Tim Newsome	DM reset must also reset all the DM's harts. (#493)
8bfcd17	2019-09-13	Tim Newsome	Explicitly list cmderr=6 (reserved). (#491)
448 de 85	2019-09-12	Philipp Wagner	dmcontrol.hartreset is WARL, not R/W (#490)
8637b3c	2019-09-10	Tim Newsome	Rebuild PDF.
f00f436	2019-09-10	Philipp Wagner	Tiny style fix for email "link" on title page (#486)
3646788	2019-09-10	Philipp Wagner	Fix page references in cmdtype table (#487)
99ae160	2019-09-09	Megan Wachs	Update implementations.tex (#482)
f9c9ed4	2019-09-04	Philipp Wagner	Update registers.py to use Python 3 (#483)
37d8ee1	2019-09-03	Philipp Wagner	Git ignore intermediate and output files (#485)
1e99ce7	2019-08-13	Tim Newsome	Tighten up trigger specification. (#478)
a121ee1	2019-08-13	Tim Newsome	Rebuild PDF.
7d126a9	2019-07-16	Tim Newsome	Mention the scontext reg number isn't conventional
1412040	2010 01 10	Tim Ivewbolile	(#474)
b5df5bd	2019-07-16	Tim Newsome	Explicitly document confstrptr[1-3]. (#475)
e6311af	2019-07-12	Tim Newsome	Change R/W1C to reduce requirements on hardware.
coorrar	2019-01-12	Tim ivewsome	(#472)
178e749	2019-07-11	Tim Newsome	Define what we mean by virtual address. (#473)
340c302	2019-07-09	Tim Newsome	Rebuild PDF.
77d58e6	2019-07-09	Tim Newsome Tim Newsome	Numerous tweaks, responding to Marc Gauthier
77036e0	2019-07-08	I IIII Newsome	(#463)
ab89a86	2019-07-04	Tim Newsome	Addressing more feedback from Marc Gauthier.
abogaou	2019-07-04	I IIII Newsome	Addressing more reedback from ware Gautiner. $(#465)$
624a6b8	2019-06-26	Tim Newsome	
0248000	2019-00-20	1 mi Newsome	Without S-mode, textra.svalue and .sselect should be
1077166	2010 06 11	T: N	0 (#469) Rebuild PDF.
1977166	2019-06-11	Tim Newsome	
b06eb70	2019-06-06	Tim Newsome	Clarify moontrol.size. (#460)
165f120	2019-05-29	Tim Newsome	Fully qualify register/field macro names. (#457)
c47f0a0	2019-05-29	Paul Donahue	Fix #452 (#459)
633ee13	2019-05-28	Paul Donahue	Fixed #453 (#458)
96ef519	2019-05-20	Tim Newsome	The *external* debugger must restore tselect.
C	2010 07 00	TT: N	(#456)
e11f777	2019-05-08	Tim Newsome	Rebuild PDF.
034d0d6	2019-04-30	Tim Newsome	Clarify that debuggers should honor maskmax.
			(#440)

4369 eb8	2019-04-30	pdonahue-	Finesse ligatures to work with Adobe Acrobat Reader
		ventana	search and cut-and-paste (#442)
d125b9b	2019-04-30	pdonahue-	sberror and sbbusyerror don't both have to be non-
		ventana	zero to prevent (#447)
859e167	2019-04-30	Tim Newsome	Tweak address matches. (#449)
96b2b28	2019-04-25	Tim Newsome	Clarify not supported cmderr. (#446)
658417f	2019-04-16	Tim Newsome	When extending IR, BYPASS still is all ones. (#437)
2e24bab	2019-04-16	Tim Newsome	JTAG does not suggest any specific IDCODE encod-
			ing (#439)
c50efcb	2019-04-09	Tim Newsome	Rebuild PDF.
281e4ad	2019-03-21	Tim Newsome	Don't run text off a page when longtable is used.
			(#434)
76874e9	2019-03-20	Tim Newsome	Explain how to detect the version. (#433)
a543b76	2019-03-12	Tim Newsome	Rebuild PDF.
a686747	2019-02-21	Tim Newsome	All trigger registers are optional (#431)
d6e4cd8	2019-02-19	Josh Scheid	Fix typo. (#426)
e773936	2019-02-19	Tim Newsome	Try to get travis to build the release branch. (#430)
3621456	2019-02-19	Tim Newsome	Abstract memory accesses use the low bits of arg0.
			(#429)
94a5f9c	2019-02-12	Tim Newsome	Clarify that harts halt out of reset if haltreq=1
			(#419)
518e732	2019-02-12	Tim Newsome	Rebuild PDF.
62 f 36 e 1	2019-02-11	Tim Newsome	Errata go in 0.13.x, this is 0.14. (#424)
66c3117	2019-01-31	Tim Newsome	Address triggers may fire on any accessed address.
			(#421)
6102412	2019-01-31	Tim Newsome	\Faamsize does not affect Argument Width. (#420)
1ea 1 a 9 b	2019-01-09	Tim Newsome	Add nmi bit to etrigger. (#408)
d1c7a3f	2019-01-09	Tim Newsome	Reserve trigger types for non-standard use. (#417)
83b12fb	2019-01-08	Tim Newsome	Rebuild PDF.
b4b3b5c	2019-01-07	Tim Newsome	\Fversion may be invalid when \Factive=0 (#414)
800450f	2019-01-01	Tim Newsome	mte only applies when action=0 (#411)
67c7fe2	2018-12-13	Tim Newsome	Add pre-built PDF of the 0.13 release.
$5\mathrm{e}7\mathrm{cb}72$	2018-12-12	Tim Newsome	Stopcount only applies to hart-local counters. (#405)
e5902fc	2018-12-12	Tim Newsome	Reserve some DMI space for non-standard use.
			(#406)
3c0dc6a	2018-12-11	Tim Newsome	Rebuild PDFs.
aeee8f3	2018-12-04	Tim Newsome	Add halt groups and external triggers. (#404)
814406d	2018-11-13	Tim Newsome	Clarify what the 4 states are. $(#403)$
cb64db0	2018-11-06	Tim Newsome	Rebuild PDFs.
70 da 60 c	2018-11-05	Tim Newsome	sselect applies to svalue. $(#402)$
66 fe 38 e	2018-11-05	Tim Newsome	Fix trigger example value. (#401)
688ccaf	2018-11-05	Tim Newsome	Resume ack is set after resume. (#400)
553dda 7	2018-11-05	Tim Newsome	Fix sbdata0 read order of operations. (#392)
b864f54	2018-10-31	Tim Newsome	Add Compatibility section to the introduction.
			(#399)
0b205b1	2018-10-31	Tim Newsome	Create errata document. (#398)
5390063	2018-10-26	Tim Newsome	Bump version to $0.13.1.~(#391)$
e46c2db	2018-10-08	bdwyatt	Fix link to PDF (#387)

ed66f39	2018-10-02	Tim Newsome	Rebuild PDF.
f2873e7	2018-10-02	Tim Newsome	Run/Halt figure applies only to single-hart systems.
			(#385)
a79945f	2018-10-02	Tim Newsome	Add ASID and context compare for triggers (#363)
9bb7da6	2018-10-02	Tim Newsome	Clean up language of #383. (#384)
fce4da5	2018-10-02	Tim Newsome	Make haltreq and resumereq proper write-only.
			(#383)
e5da11e	2018-10-02	Tim Newsome	Minimal implementations can't access all registers
			(#381)
e1be8f4	2018-10-02	Tim Newsome	Format quotes correctly. (#382)
e9103ba	2018-10-02	Tim Newsome	Change from AVR debug connector to MIPI-10,20.
			(#375)
8841a7a	2018-10-02	Tim Newsome	Abstract reg access is independent of run/halt.
			(#380)
71c54bb	2018-10-02	Tim Newsome	Explicitly state what's required for compliance.
			(#379)
4edb285	2018-10-01	Tim Newsome	Rebuild PDF.
b0420b3	2018-10-01	Tim Newsome	Final cleanups! Mostly table formatting. (#377)
d43f5a4	2018-10-01	Tim Newsome	Clarify W1. (#372)
72618f3	2018-10-01	Tim Newsome	Leave space for trace, but don't specify anything.
			(#376)
b7db4ce	2018-10-01	Tim Newsome	Add dcsr.cause for being halted out of reset. (#370)
42ab2a1	2018-09-28	Tim Newsome	Clean up language, formatting, consistency. (#371)
7801874	2018-09-28	Tim Newsome	Little language and formatting cleanups. (#366)
38ae12f	2018-09-27	Tim Newsome	Reset dmi.op to 0 instead of 2. $(#369)$
b50dc0d	2018-09-27	Tim Newsome	Formatting, language, consistency. (#373)
425e9b1	2018-09-27	Tim Newsome	Distinguish draft and release builds. (#364)
c7b4e1c	2018-09-26	Tim Newsome	Stepping over wfi does not enter wait state. (#368)
4725879	2018-09-25	Tim Newsome	Language, formatting, and abstract cmd arguments.
			(#367)
62bf89d	2018-09-25	Tim Newsome	Rebuild PDF.
10dfa65	2018-09-24	Tim Newsome	Allow global reset to reset the DM. $(#350)$
84ec8a5	2018-09-18	Tim Newsome	Harts can be in exactly 1 of 4 states. $(\#354)$
308eaf 6	2018-09-17	Tim Newsome	Mostly match "official" style for credits. (#362)
b6187ff	2018-09-17	Tim Newsome	Specify ackhavereset as W1. $(#361)$
41d9f06	2018-09-14	Tim Newsome	Abstract commands might work on a hung hart.
			(#360)
fa561bd	2018-09-14	Tim Newsome	Can't change harts during operations, and the cur-
			rent hart becoming unavailable may terminate the
			abstract command with error. $(\#322)$
900cdbf	2018-09-11	Tim Newsome	Rebuild PDF.
514ef6f	2018-09-07	Tim Newsome	Clarify lack of notification for other reset harts
			(#349)
e0ff31e	2018-09-07	Tim Newsome	Clarify postexec when there is no Program Buffer
			(#352)
3 dacc 00	2018-09-07	Florian Zaruba	Move regno table to the actual access reg command
			(#345)

5d25cd5	2018-09-06	Tim Newsome	don't set most bits of DMCONTROL during abstract
12655e0	2018-09-06	Tim Newsome	commands (#324)
1205560	2010-09-00	1 m Newsome	Document breakpoint exception $+$ enter debug mode $(\#299)$
6894f4b	2018-09-05	Tim Newsome	Define DXLEN as the widest supported XLEN. (#298)
114a208	2018-09-04	Tim Newsome	Restrict how many bits may be set in dmcontrol. (#348)
4cd1563	2018-09-03	Tim Newsome	Don't change selected harts during hart reset. (#337)
1529c26	2018-09-03	Tim Newsome	On trigger chains, only the last action is taken.
10.0501	2010 00 01	m: N	(#341)
18a3531	2018-08-31	Tim Newsome	Authdata is bidirectional. (#347)
7d14f95	2018-08-27	Tommy Thorn	m "LaTeX/english issues: eg; e.g., etc" (#342)
0fb41b9	2018-08-27	Tim Newsome	Don't change step/stepie while running. (#340)
ff09418	2018-08-21	Tim Newsome	Rebuild PDF.
6bd15ac	2018-08-20	Tim Newsome	Be more clear about running signal. (#338)
e967b3b	2018-08-20	Tim Newsome	mprven may be tied high or low. (#339)
0f120c0	2018-08-20	Tim Newsome	Solution to native triggers in M mode only systems (#309)
13d5c08	2018-08-17	Tim Newsome	Thank John Hauser.
b52d9fe	2018-08-17	Tim Newsome	Allow control xfers in progbuf to act as illegal.
			(#331)
19058ef	2018-08-17	Tim Newsome	Clarify that resumered is not level-sensitive. (#321)
497352c	2018-08-16	Tim Newsome	Side effects happen for abstract register accesses
			(#334)
fd5cf62	2018-08-15	Tim Newsome	Triggers do not fire in Debug Mode. (#335)
762d308	2018-08-15	Tim Newsome	Add aarpostincrement to abstract register access. (#333)
45b7636	2018-08-14	Tim Newsome	Clearing hasel does not clear the ha mask reg. (#327)
	2018-08-14	Tim Newsome Tim Newsome	9 (,, ,
2ca20aa		Tim Newsome Tim Newsome	clrresethaltreq trumps setresethaltreq (#332)
57df3f3	2018-08-10 2018-08-10	Tim Newsome Tim Newsome	Recommand is not readable. (#328)
81df032			Explain what we mean by Preset. (#323)
b51c6db	2018-08-10	Tim Newsome	Clarify ebreak behavior when ebreak* are 0. (#311)
a14d868	2018-08-10	Tim Newsome	Allow extra harts to be reset. (#330)
6d60ad9	2018-08-07	Tim Newsome	Rebuild PDF
f4bd15f	2018-08-02	Tim Newsome	Define cmderr for non-existent register access. (#325)
2d7d3d0	2018-07-20	Tim Newsome	Fix typo in data0 definition.
c8a64d1	2018-07-19	Tim Newsome	Rebuild PDF.
9d2944f	2018-07-18	Tim Newsome	Add size to mcontrol. (#310)
6bd1a4c	2018-07-16	Tim Newsome	Put the description of dmstatus first. (#303)
25e81e5	2018-07-12	Tim Newsome	Fix typo in trigger example. (#308)
8462c94	2018-07-09	Tim Newsome	Rebuild pdf.
38fde94	2018-07-09	Tim Newsome	datacount cannot be 0 (#286)
800ca8d	2018-07-06	Tim Newsome Tim Newsome	Clarifications requested by Jeremy Bennett (#280)
b363afa	2018-07-06	Tim Newsome Tim Newsome	Add missing .tex file to dependencies. (#302)
93340e4	2018-07-06	Tim Newsome	Clarify that trigger registers are WARL. (#306)
95af58a	2018-07-06	Tim Newsome Tim Newsome	Force the register-address in place. (#304)
2001000	2010-01-00	IIII I TO WOOTH	1 of the frequent address in place. (#901)

d83039d	2018-07-06	Tim Newsome	\Fcause priority numbers: higher means higher (#307)
921c6a3	2018-07-03	Tim Newsome	Completing progbuf exec is I/O for fence insts. (#305)
99e01fa	2018-06-27	Tim Newsome	Add target-specific bits to abstract access memory. (#295)
4a0152d	2018-06-19	Tim Newsome	Only write busy to \Fcmderr if \Fcmderr is 0. (#296)
b0dc615	2018-06-16	Tim Newsome	Rebuild the PDF.
90873eb	2018-06-16	Tim Newsome	Fix typo in abstract access memory examples. $(#297)$
$5 \mathrm{fe} 8 \mathrm{e} 08$	2018-06-16	Tim Newsome	dret is a section, not a subsection of reset $(#294)$
abfd8a0	2018-06-14	Tim Newsome	Revert "Only write busy to \Fcmderr if \Fcmderr is 0."
7c66968	2018-06-14	Tim Newsome	Only write busy to \Fcmderr if \Fcmderr is 0.
0f28f27	2018-06-08	Tim Newsome	Abstract memory (#283)
7c840dd	2018-06-08	Tim Newsome	Specify an Exception Trigger (#266)
9d0d8af	2018-06-06	Tim Newsome	Clarify what address space these registers are in $(#281)$
a7f293d	2018-06-03	Tim Newsome	Add missing dependency to Makefile $(#285)$
37893aa	2018-05-30	Tim Newsome	Make trigger types writable. (#279)
6730cc0	2018-05-29	Tim Newsome	Explain priority assignment rationale. $(#277)$
b6d5d66	2018-05-25	Tim Newsome	Prevent M mode triggers affecting D mode ones (#282)
08ee84f	2018-05-22	Tim Newsome	Reading tselect doesn't guarantee a valid trigger. (#271)
6dfe375	2018-04-18	Megan Wachs	Debug Module should be capitalized
dac2120	2018-04-11	Megan Wachs	resethaltreq: Proposal for forcing a hart into debug mode out of reset
3b6442f	2018-05-16	Tim Newsome	tdata2 need only hold valid addresses if select=0 (#278)
68501cb	2018-04-26	mwachs5	mprven: Add a bit to enable MPRV to take effect in debug mode
9fcabe0	2018-05-03	Megan Wachs	Appendix: correct and clarify what debugger vs DM does
30773fd	2018-05-03	Tim Newsome	Debuggers must not write sbcs while sbbusy is set $(\#270)$
50d8cd8	2018-05-03	Megan Wachs	Remove merge commits from the changelog
3b7a296	2018-05-02	Tim Newsome	Fix typo.
b26072b	2018-05-02	Tim Newsome	Explain that 1 in hart array mask means selected
41f6026	2018-05-02	Megan Wachs	Examples: Give an example of CSR access with Quick Access (#268)
675bb14	2018-05-01	Tim Newsome	Replace XLEN with MXLEN. #257
848cca1	2018-04-30	Megan Wachs	Overview Diagram: increase number of Progbuf words (#267)
a719ee6	2018-04-25	Megan Wachs	fix misspelled name
097c701	2018-04-23	Tim Newsome	Fix typo.
01 dabd5	2018-04-23	Tim Newsome	Incorporate review feedback.

7 0 10	2010 04 10	m. N	
ca7a9d0	2018-04-18	Tim Newsome	Add trigger examples for match types 1, 4, and 5
cd5a15c	2018-04-16	Tim Newsome	Give a few trigger examples.
4375927	2018-04-12	Tim Newsome	Clarify that maskmax applies only to NAPOT trigger
acadfe9	2018-04-13	Megan Wachs	NMI: debugging may not be possible if an NMI hap-
0.00	2010 01 10	m. 37	pens
8fb190c	2018-04-12	Tim Newsome	Another attempt at SBA errors.
714c5d1	2018-04-11	Megan Wachs	Core Debug: all interrupts are masked includes NMI
56fbd9d	2018-04-11	Megan Wachs	DCSR: add nmip bit to indicate NMI is pending
fffe3c2	2018-04-10	Tim Newsome	Clarify SBA unsupport access size error.
b4006ac	2018-04-10	Tim Newsome	Clarify high bits of sbdata in narrow reads.
4ca83dd	2018-03-28	Tim Newsome	Clarify progbuf=1 some more
3b62243	2018-03-26	Tim Newsome	Clarify debugger requirements when progbufsize=1
ffba4d0	2018-03-26	Tim Newsome	Explain why progbufsize=1 is special
6b88905	2018-03-19	Megan Wachs	haltsum1: correct its address to be BWC and not
			overlap with ABSTRACTAUTO
2382e2e	2018-03-06	Megan Wachs	Correct some inaccuarices in the chisel generated files
3e88e11	2018-03-06	Megan Wachs	travis: add 'make chisel' target to regression
32cbb 9 b	2018-03-19	Tim Newsome	Nonexistent/unavailable harts are not halted.
f8a7bb7	2018-03-19	Tim Newsome	More clarification.
e21ae4c	2018-03-16	Tim Newsome	Allow any bit in hart array mask to be tied to 0
efb7e45	2018-03-15	Tim Newsome	Change dcsr.prv reset value to 3
f19946b	2018-03-15	Tim Newsome	Clarify hart array mask register size.
ddec145	2018-03-14	Tim Newsome	Be more precise about core vs hart
4e5f4ad	2018-03-14	Tim Newsome	Review feedback.
8ac9273	2018-03-14	Tim Newsome	Be more precise about processor vs hart
83c9774	2018-03-14	Tim Newsome	Clarify abstract command errors.
$4 \mathrm{ebc} 177$	2018-03-14	Tim Newsome	hawindowsel can be smaller, depends on # of harts
11e1b5c	2018-03-14	Tim Newsome	Split future ideas section into a notes doc
bafeeaa	2018-03-13	Tim Newsome	Rebuild PDF
6a85d53	2018-03-13	Tim Newsome	Incorporate review feedback.
f213315	2018-03-09	Tim Newsome	Clarify user responsibilities when debugging lr/sc
3641305	2018-03-09	Tim Newsome	Remove implemented features from Future Ideas.
1135bf3	2018-03-06	Tim Newsome	Incorporate feedback.
8f35e7e	2018-03-05	Megan Wachs	gt_1024: Clarify that some registers may not be
		_	present for small numbers of harts
683ae37	2018-02-14	Megan Wachs	hartsum-¿haltsum
ee51758	2018-02-14	Megan Wachs	Modification of ¿ 1024 hart proposal that maintains
		g	backwards compatibility
370d222	2018-03-05	Tim Newsome	Rephrase description of hit bit.
eee5e0c	2018-03-05	Tim Newsome	Clarify multiple DMs/harts
4d5acef	2018-02-28	Tim Newsome	Clarify what happens when \Fauthenticated is clear
6a0c9ec	2018-02-27	Tim Newsome	Move hit bit per review feedback.
097 bd8e	2018-02-21	Tim Newsome	Fix link to pre-built pdf
d21774b	2018-02-21	Omer Faruk IR-	Python interpreter to be used should default to
		MAK	Python2
a8c10cf	2018-02-20	Tim Newsome	Incorporate review feedback.
a0f947c	2018-02-20	Tim Newsome	Make trigger hit bit optional.
77e4634	2018-02-08	Tim Newsome	Add hit bit to hardware triggers.
1101001	_010 02 00		1199 1110 010 00 110119 110110 01188010.

140390a	2018-02-05	Tim Newsome	Better wording.
e35b1ff	2018-02-05	Tim Newsome	Move Reg Access Abbrev table after sample register
e887433	2018-02-05	Tim Newsome	Use longtable instead of xtabular.
5c84437	2018-01-31	Tim Newsome	Abstract Command data usage depends on the com-
			mand
3d508ea	2018-01-25	Tim Newsome	HARTSELBITS-¿HARTSELLEN and other feed-
			back
eb653f7	2018-01-24	Tim Newsome	Be explicit about the size of \Fhartsel.
822 bd81	2018-01-24	Tim Newsome	Revert incrementing version number.
4c755af	2018-01-24	Tim Newsome	\Fsbbusyerror also inhibits new accesses.
457413d	2018-01-24	Tim Newsome	Update how to enumerate all harts.
2180801	2018-01-18	Tim Newsome	Fix ambiguity in busy error reporting.
3140efa	2018-01-09	Tim Newsome	$Re-apply\ e698a5001aa4583d31dde484d78f4f10e4e3148f$
			. No need to list out all the consecutive registers.
390 daa7	2018-01-18	mwachs5	sbaddress: Only writes to address will actually cause
			an error. Reads while busy are permitted.
5c820f3	2018-01-18	Megan Wachs	Remove reference to "caches"
4533648	2018-01-18	Megan Wachs	correct access spelling
d37c1ac	2018-01-16	Tim Newsome	Fix table column overruns by going full manual
e9100ea	2018-01-16	Tim Newsome	Correct when sbbusy error is set for being busy.
c029cc7	2018-01-16	Tim Newsome	Complete partial sentence.
494338a	2018-01-15	Tim Newsome	Add clarifications about error handling.
e14c34e	2018-01-15	Tim Newsome	Incorporate review feedback.
68720e5	2018-01-15	Tim Newsome	Remove H bits from triggers.
b8eb62a	2018-01-15	Tim Newsome	Clarify when sbaccess is checked for validity
8b50d29	2018-01-12	Tim Newsome	Add \Fsbbusy, to avoid race clearing \Fsberror
50b1b41	2018-01-12	Tim Newsome	Clarify: writes to \Rsbdata0 write the new data
7f26759	2018-01-12	Tim Newsome	Clarify exactly which bits are used for SB access.
47a019c	2018-01-11	Tim Newsome	Fix typo.
a49d6ad	2018-01-11	Tim Newsome	sbreadonaddr is R/W
42195c2	2018-01-11	Tim Newsome	Fix cut-and-paste error.
6c95235	2018-01-11	Tim Newsome	Add sbaddress3, for future proofing.
e3345ea	2018-01-11	Tim Newsome	Incorporate review feedback.
6da48f8	2018-01-11	Tim Newsome	Remove dmerr.
e99c092	2018-01-10	Tim Newsome	Add system bus version field.
a6aa531	2018-01-10	Tim Newsome	Talk about all data and progbuf regs in first reg
af272db	2018-01-09	Megan Wachs	Update dret font
3d579d8	2018-01-09	Tim Newsome	Explicitly list data[1-10] and progbuf[1-15]
c6481ae	2018-01-09	Tim Newsome	Revert "Explicitly list data[1-10] and progbuf[1-15]"
e698a50	2018-01-09	Tim Newsome	Explicitly list data[1-10] and progbuf[1-15]
e547ed5	2018-01-09	Tim Newsome	Clarify that we deal in physical addresses only.
b377b89	2018-01-09	Tim Newsome	Revert "Clarify that we deal in physical addresses only."
f7da066	2018-01-09	Tim Newsome	Clarify that we deal in physical addresses only.
99a1599	2018-01-09	Tim Newsome	Clarify that \Fdatasize contains at most 12.
ae6e88a	2018-01-09	mwachs5	dret: Legal only in Debug Mode
18f392d	2017-11-24	Tim Newsome	Get rid of sbsingleread in favor of sbreadonaddr
5754a3b	2018-01-05	Megan Wachs	Use a different word than "clobbered"

7 01	0010 01 00	3.6 337 1	A 11
aca7e0b	2018-01-03	Megan Wachs	Add missing "to"s to abstractauto description
d59ddf3	2018-01-03	Megan Wachs	Correct plurality of halted harts in haltsum
57c53ed	2017-12-22	Tim Newsome	Put parens around all macros that need it.
7 ded 846	2017-12-18	Tim Newsome	Refer to existing hart instead of "valid"
68b8ac8	2017-12-15	Tim Newsome	Make \Fhaltsel WARL.
6a72f45	2017-12-18	Tim Newsome	Mark this as a draft, which it is.
dd8d871	2017-12-18	Tim Newsome	Properly deal with \ chars in the changelog.
42f920c	2017-12-18	Tim Newsome	Deal with \setminus chars in the changelog.
b13891c	2017-12-15	Tim Newsome	Revert "Make \Fhaltsel WARL."
26d76a0	2017-12-15	Tim Newsome	Make \Fhaltsel WARL.
afda8d7	2017-11-28	mwachs5	update PDF
134d310	2017-11-28	Megan Wachs	Correct compressed version of ebreak
caa1258	2017-11-27	Megan Wachs	badaddr -¿ tval (Priv Spec 1.9 -¿ 1.9.1)
32b0f08	2017-11-22	Tim Newsome	Incorporate feedback.
2 f7 aa 54	2017-11-22	Tim Newsome	Simplify, and explain trigger behavior.
3e5887f	2017-11-21	Tim Newsome	Clarify some single step corner cases.
f4b9ae2	2017-11-21	Tim Newsome	Make ackhavereset write-only. (#178)
efe3dc8	2017-11-21	Tim Newsome	Make hartreset R/W (#177)
ce1b359	2017-11-17	Megan Wachs	Reset clarifications (#172)
852a70d	2017-11-16	Megan Wachs	icount: remove warning (#173)
363348f	2017-11-16	Tim Newsome	Explain cache coherency wrt to system bus access
0000101	2011 11 10	Tim rewsome	(#171)
26ea898	2017-11-15	Tim Newsome	Refer to ISA and priv docs.
ffc8c62	2017-11-03	Tim Newsome	Mention the index in "about this doc"
a4257ef	2017-11-02	Tim Newsome	Add an index to the document.
f5f45a5	2017-10-30	Megan Wachs	Add 'has reset' status and control (#168)
46f3f54	2017-10-25	Tim Newsome	Incorporate review feedback.
104247f	2017-10-24	Megan Wachs	Update README.md
6dd5c80	2017-10-24	Megan Wachs	Update README.md
cb1a847	2017-10-24	Megan Wachs	Add a note to the README about the built PDF
e00625f	2017-10-18	Tim Newsome	Include pdf.
c23e729	2017-10-18	Tim Newsome	Clarify more.
83f9faf	2017-10-11	Tim Newsome	Clarify what \Fimpebreak does.
78082b5	2017-10-11	Tim Newsome	Mention \Fimpebreak in Program Buffer description.
0378324	2017-10-11	mwachs5	Add legend and update some transitions on the Ab-
			stract Command State Machine diagram
fa2b600	2017-10-11	Megan Wachs	add missing period
0610630	2017-10-11	Megan Wachs	Just do simple hmode -; dmode replacement
16e11f3	2017-10-11	Tim Newsome	Remove hmode reference, to fix build.
84b9a6a	2017-10-11	Tim Newsome	Add \Fimpebreak, to support of implicit ebreak.
cc90b77	2017-10-11	mwachs5	Remove reference to 'H' mode from the figure
cc6a9de	2017-10-11	Megan Wachs	Change old reference to 'hmode' to 'dmode'
ea2877d	2017-10-11	Tim Newsome	Move how-to-debug into the relevant section.
		Tim Newsome Tim Newsome	
486ecc6	2017-10-05		Refuse unsupported bus accesses.
6ca221d	2017-10-05	Tim Newsome	haltreq, resumereq, hartreset are per-hart bits
d4118ab	2017-09-30	Tim Newsome	ndmreset can't reset logic required to access DM.
c6bd8d1	2017-09-29	Tim Newsome	and -; or
58c2441	2017-09-29	Tim Newsome	Mention \Fstepie in Single Step

94c5f78	2017-09-29	Tim Newsome	Clarify ndmreset.
12810b4	2017-09-29	Tim Newsome	Clarify that sbaddress is physical.
5862 fdf	2017-09-29	Tim Newsome	Unify M mode and mprv comment.
aea1bd5	2017-09-29	Tim Newsome	Define behavior when haltreq and resumereq are set
146b348	2017-09-28	Megan Wachs	remove superflous 'an'
a5d16c4	2017-09-28	Megan Wachs	remove superfluous 'a'
052a8ab	2017-09-28	Tim Newsome	Clarify that a debugger can lose hart control.
cc52cff	2017-09-28	Tim Newsome	Add \Fdmerr.
25685eb	2017-09-28	Tim Newsome	Explain that bus master or progbuf is required.
f75ee7d	2017-09-28	Tim Newsome	Clarify debugger can discover "almost" everything
71e6788	2017-09-27	Tim Newsome	Remove description of manual stepping.
9aea347	2017-09-27	Tim Newsome	Move Running/Single Step near Halting.
2090d9b	2017-09-27	Tim Newsome	data0 should be sbdata0 in this table.
5858cfe	2017-09-27	Tim Newsome	Clarify why \Rpriv exists.
bc3c2aa	2017-09-27	Tim Newsome	Mention where priv encoding comes from.
ef77cc4	2017-09-27	Tim Newsome	One more attempt to clarify DPC after single step.
80a288e	2017-09-27	Tim Newsome	Clarify instret not incrementing on ebreak.
c163d22	2017-09-20	Tim Newsome	Remove ebreakh.
9971075	2017-09-20	Tim Newsome	Clarify we're talking about privilege
3 fbe 495	2017-09-20	Tim Newsome	Clarify that we're talking about *implementation*
3684854	2017-09-20	Tim Newsome	Use steps environment in sbdata0.
d4eda18	2017-09-20	Tim Newsome	Explain that only sbdata0 has side effects.
ae781c6	2017-09-20	Tim Newsome	Don't refer to internal system bus registers.
875922e	2017-09-20	Tim Newsome	Explain sbdata0 being stale a bit more.
cd44fd5	2017-09-20	Tim Newsome	Clarify autoread
194484b	2017-09-20	Tim Newsome	Clarify hawindow.
02f1aac	2017-09-20	Tim Newsome	Clarify that \Fdataaddr is relative to \Rzero.
0e 9 b 6 ae	2017-09-20	Tim Newsome	Clarify nonexistent vs unavailable.
b55ff41	2017-09-20	Tim Newsome	Fix devtreevalid.
2eccb 86	2017-09-20	Tim Newsome	Explicitly state which registers are read-only.
4af505c	2017-09-20	Tim Newsome	Show section numbers for registers.
cbd5573	2017-09-20	Tim Newsome	Thank Nikhil
19c206f	2017-09-20	Tim Newsome	Clarify how to determine whether progbuf is RAM
$0651 \mathrm{f7d}$	2017-09-20	Tim Newsome	Explain what happens if ebreak is missing.
e889dae	2017-09-20	Tim Newsome	Move figure of states into its own section.
cff7b80	2017-09-20	Tim Newsome	Explain when \Ftransfer might be used.
6b2ee61	2017-09-20	Tim Newsome	Explain where \Fsize encoding came from.
c9f3b73	2017-09-14	Tim Newsome	Fix typo.
4b25400	2017-09-13	Tim Newsome	Mention dpc in CSRs abstract register numbers.
c3ee426	2017-09-13	Tim Newsome	Move abstract regno table closer to its reference.
111b9a3	2017-09-13	Tim Newsome	cycle -¿ operation
994afdc	2017-09-13	Tim Newsome	Account for multiple selected harts.
aa4a297	2017-09-13	Tim Newsome	Halt Control -; Run Control
e97c821	2017-09-13	Tim Newsome	continuous -¿ contiguous
97f73ff	2017-09-13	Tim Newsome	Clarify ndmreset behavior.
6078220	2017-09-13	Tim Newsome	Explain ndmreset
a3d4f30	2017-09-13	Tim Newsome	Describe 'halt region'
272b3d9	2017-09-13	Tim Newsome	Clarify accessing unimplemented DM DMI regs

3e91f1b	2017-09-13	Tim Newsome	Clarify either Prog Buf or Sys Bus Acc is required
e8a6145	2017-09-13	Tim Newsome	Clarify CSR access; remove serial port
ce20766	2017-09-13	Tim Newsome	Remove section referencing itself.
1195a61	2017-09-18	Tim Newsome	Generate constants to be unsigned for clang.
8967b0a	2017-08-16	Megan Wachs	Compressed instructions are c.foo, not foo.c
b5698a9	2017-08-16	Megan Wachs	clarify progbufsize description
d221bab	2017-08-16	Megan Wachs	Remove progbufsize enums from register description
0498102	2017-08-16	Megan Wachs	appendix: Use standard assembly format for sw
4456d99	2017-08-09	Tim Newsome	Rename progsize to progbufsize.
55d5b66	2017-08-09	Tim Newsome	Clarify that trigger comparisons are unsigned.
21e35ef	2017-08-09	Tim Newsome	Configuration String -; Device Tree
f044f45	2017-08-02	Tim Newsome	Don't require a target to provide 25mA on VCC.
c883943	2017-08-02	Tim Newsome	Add table of Abstract Command Types
985a3df	2017-08-02	Tim Newsome	Fix and speed up build.
95b9108	2017-08-02	mwachs5	DTM: Clarify that there are no cases when DMI
3003100	2017-00-02	mwaciiso	would actually return an error.
9c9e0c0	2017-08-02	mwachs5	SystemBus: No longer returns error. So DMI has no
3636060	2011 00 02	mwacii59	'error' return code.
5ba18f9	2017-07-27	Tim Newsome	Fix more typos.
dbc65bf	2017-07-26	Tim Newsome	Fix typos.
bba0ad9	2017-07-26	Tim Newsome	Tighten up introduction lists.
e22d5eb	2017-07-26	Tim Newsome	Add version constants for "not compatible".
c79038e	2017-07-26	Tim Newsome	Small clarification.
9df0411	2017-07-20	Tim Newsome	Incorporate review feedback.
d67419c	2017-07-21	Tim Newsome	Clarify dpc contents.
9f50c05	2017-07-21	Tim Newsome	Use LL instead of L for 64-bit constant suffix.
23 fd 24 a	2017-07-11	Megan Wachs	Cleaning up whitespaces
c5ab04c	2017-07-10	Megan Wachs	Update abstract_commands.xml
6e8cdf1	2017-07-10	Megan Wachs	Update abstract_commands.xml
cf6e3f2	2017-07-10	Megan Wachs	clarify DCSR.cause
79ffbb9	2017-07-10	Megan Wachs	Clarify implications of CSR read, write, halt
013e191	2017-07-10	Megan Wachs	Clarify when you would get error halt/resume
231e457	2017-07-10	Megan Wachs	Quick Access error clarification
c54c2f2	2017-07-10	mwachs5	serial: add the XML file, not the TEX file
ac77477	2017-07-03	mwachs5	serial: Add the AML me, not the TEA me serial: Fix compile errors after moving serial port to
ac11411	2017-07-03	mwachso	appendix
6defcb8	2017-07-03	mwachs5	
odercoo	2017-07-03	mwachso	serial: Move serial ports out of main spec and into
a28f639	2017-06-30	mwachs5	Future Work appendix remove trace dependencies from Makefile
52a122b	2017-06-30	mwachs5	remove trace dependencies from wakeme remove trace section
d9e166b	2017-06-30	mwachs5	
	2017-06-30		remove trace registers
7caf4e5		mwachs5 mwachs5	remove trace appendix DCSP: define a 'atania' bit which may be hard wired
4688988	2017-06-29	mwachs9	DCSR: define a 'stepie' bit which may be hard-wired
0.0400.	2017 06 12	Moren Washa	to 0. Add missing period and some other small text edits
9a0492c	2017-06-13	Megan Wachs	Add missing period and some other small text edits
13ccdbf	2017-06-13	Megan Wachs	fix typo in ProgBuf register macro
b01f989	2017-06-13	mwachs5	implementations: be a bit more concrete about the
			one example implementation we have.

a7b5f83	2017-06-13	mwachs5	jtagdtm: Move it out of the appendix as it is really
			part of the specification
87aceb0	2017-06-13	Megan Wachs	remove "spontaneous"
50b9950	2017-06-13	Megan Wachs	Forward reference for any nonexistent
adea3e2	2017-06-13	Megan Wachs	More clarifications on dret
1b8dd0e	2017-06-13	Megan Wachs	Define DRET instruction
617 da4c	2017-06-08	Megan Wachs	Update description of R/W1C
de2c56b	2017-06-08	Megan Wachs	Clarify that DCSR is also not updated on ebreak
efa615d	2017-06-07	Tim Newsome	Increase xdebugver field size to 4 bits. (#92)
a0e147a	2017-06-07	Tim Newsome	Address some review comments.
89 ffe 50	2017-06-06	mwachs5	NDMRESET: Clarify what it may and may not do
1932 da0	2017-06-06	mwachs5	DPC: Clarifications on its meaning
$6470 \mathrm{fdb}$	2017-06-06	mwachs5	ABSTRACTCS: Correct inconsistency on the num-
			ber of data words.
3ca82b4	2017-06-06	Megan Wachs	More corrections for R vs R/W1C on SERCS
9705fb8	2017-06-06	Megan Wachs	Correct a bunch of W0 registers
1347371	2017-06-05	Tim Newsome	Add intdisable to dcsr.
989c60d	2017-06-05	Tim Newsome	Fix language. We can only halt harts, not cores.
517a08b	2017-06-05	Tim Newsome	Incorporate review feedback.
802 be 28	2017-06-05	Tim Newsome	Clarify/fix Quick Access example.
b8cc523	2017-06-02	Tim Newsome	Add included tex files as dependencies. (#78)
15f864a	2017-06-01	Tim Newsome	Language cleanups, consistency and typo fixes.
4ecae86	2017-06-01	Tim Newsome	Add page numbers to list-of-register tables.
59b3e4a	2017-05-19	Megan Wachs	Setting up a Travis regression to check for build errors
		O	(#72)
124bf44	2017-05-17	mwachs5	Debug Module: CMDERR is Write-1-to clear, not
			R/W0
bb6c7f0	2017-05-17	mwachs5	SW Registers file should be XML, not TEX
d360358	2017-05-10	Megan Wachs	Remove virtual register from core_registers.xml
		(Temporary	
		Acct.)	
bfc64fb	2017-05-10	Megan Wachs	Add missing sw_registers.tex file
		(Temporary	
		Acct.)	
0512f5d	2017-05-06	mwachs5	Move virtual 'prv' register to a seperate section to
			make it more clear it is not a real register.
6b3c9d7	2017-05-06	mwachs5	Clarify haltreq/resumereq/resumack
0a487eb	2017-04-26	mwachs5	jtag: Change specified JTAG pinout from Coretex to
00.20.			AVR, to provide for TRSTn option.
93cdfaf	2017-04-26	mwachs5	DM : Clarify that DATA/PROGBUF can't be writ-
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0			ten while busy.
ef98f23	2017-04-19	mwachs5	jtag: Make it clear that a NOP is really a NOP.
a6f8efa	2017-04-17	mwachs5	single_step: Exceptions count as the 'step' comple-
0 0 - 00			tion.
bf11e9e	2017-04-17	mwachs5	resumeack: fix some LaTeX cross references
4afa081	2017-04-11	mwachs5	halt/resumereq: Clarify what setting them to 0 or 1
1010001	201. 01 11	11111001100	does
297a39b	2017-04-06	mwachs5	fix chisel build
_0.000	_01.0100		

082c499	2017-04-06	mwachs5	Rename resumed to resumeack, and add more text about what these bits mean.
909d617	2017-04-06	mwachs5	Correct some cross references after removing all the multiply listed registers
dd09914	2017-04-06	mwachs5	Add 'resumedall' and 'resumedany' bits to avoid race condition on about to resume and just halted
feb88fc	2017-04-05	mwachs5	JTAG DTM: Clarify that leading bits are 0 for more than 5-bit IR
75b96ea	2017-04-04	mwachs5	use renamed dm_registers file
9f3ec7e	2017-04-04	mwachs5	debugger_implementation: remove some old TODO
			and commentary.
45 dd5 b5	2017-04-04	mwachs5	Don't list out every single DM register for those that
			are just indexed versions
b8b3aa2	2017-04-04	mwachs5	remove core-side register definitions from Debug
			Module. Rename dm1 to dm
d979a13	2017-04-04	mwachs5	remove core-side serial port specification, as these
			should look like implementation-specific devices with
			appropriate drivers.
b56870b	2017-04-04	mwachs5	Remove the wording about 'debug exception', as it is
			called breakpoint exception in the RISC-V Spec.
1e9347d	2017-04-03	mwachs5	Add description of hasel
0 dda 84 d	2017-04-03	mwachs5	JTAG DTM: Clean up TAP register descriptions
82ccde 5	2017-04-03	mwachs5	JTAG DTM: Add a hard DMI bit which cancels the
			outstanding DMI transaction
bd2a3d1	2017-04-03	mwachs5	remove preexec
02c733a	2017-04-03	mwachs5	remove preexec from Abstract State diagram.
1e271d6	2017-04-03	mwachs5	Update Debugger implementation for DMI register access, and fix tex compile issues.
155 dda4	2017-04-03	mwachs5	Rewrite HW Implementation examples to describe a
			pure abstract command approach, and to not rely
			on harts executing every instruction which is fetched
			from the Debug Module
556c2be	2017-04-03	mwachs5	minor wording edits about RISC-V core registers
523c64a	2017-04-03	mwachs5	Edits to the Debug Module section.
b9a371f	2017-04-03	mwachs5	add missing trace.tex file.
58b2396	2017-04-03	mwachs5	Re-order the JTAG DTM Sections
a8827e2	2017-04-03	mwachs5	Edits to the System Overview.
c5417ce	2017-04-03	mwachs5	add more sections as seperate files.
287d5c6	2017-04-03	mwachs5	moving more files to seperate tex files.
9e873f4	2017-04-03	mwachs5	move trigger info into seperate file.
2c89a86	2017-04-03	mwachs5	move risc-v core debug info into seperate file.
e676491	2017-04-03	mwachs5	Move System Overview to seperate file
03df6ee	2017-04-03	mwachs5	Move Debug Module description to a seperate file.
5faa430	2017-04-03	mwachs5	add back in JTAG DTM in appendix
7b28b11	2017-04-03	mwachs5	Move jtag DTM to appendix. Move some text to
1091	0017 04 00		commentary.
cc183ba	2017-04-03	mwachs5	move introduction to a seperate file. Comment out
			reading order.

f727d14	2017-04-03	mwachs5	Use Chapters vs Sections Needs reorganization
815951d	2017-04-03	mwachs5	Use Chapters vs Sections. Needs reorganization. Formatting updates. Make this look more like the
019991d	2017-04-03	mwachso	RISC-V specs. Need to use chapter vs. section
69ffaf8	2017-03-31	mwachs5	Move XML files into a subdirectory.
b276384	2017-03-31	mwachs5	Remove debug_rom.S
112bbac	2017-03-31	mwachs5	9
			figures: reorganize the figures into directories. Add LICENSE
1e5c068	2017-03-27	Megan Wachs	
fc17730	2017-03-22	Po-wei Huang	Change some halt mode into debug mode.
8ccf029	2017-03-22	Po-wei Huang	All halt mode changed to debug mode to synchronize with the priv spec.
f143d9e	2017 - 03 - 21	mwachs5	Correct duplicated progbuf register names
0797ec1	2017 - 03 - 17	mwachs5	autoexec: make autoexec bits match the number of
			data words there really are.
8e76d93	2017-03-17	mwachs5	dm1_registers: move a few more things around. Re-
			duce abstract data words back to 12.
f8bf292	2017-03-17	mwachs5	dm1_registers: resolve some address conflicts and in-
			consistencies
a74dff9	2017-03-17	mwachs5	access_register: some small bit changes
2e6b0ca	2017-03-15	mwachs5	config string: Fix LaTeX compile errors.
f83260a	2017-03-10	mwachs5	Abstract Commands: clarify that 32-bit reads should
			always work. This allows reading MISA.
6f9347a	2017-03-10	mwachs5	Config String: change the Abstract Command to
0-00-0-0			DMI registers. Allow the same registers to be used
			for unspecified identifier information.
4ea10ff	2017-03-10	mwachs5	abstract: Make autoexec apply to all data and prog-
1001011	201. 00 10	111.11.0011.50	buf words. Make a seperate register which is optional.
5008436	2017-03-10	mwachs5	abstract: Allow up to 16 progbuf and/or data words.
0000100	201. 00 10	111	Inform debugger about dscratch registers available
			for its use.
aaa13e5	2017-03-06	mwachs5	Command: use the name 'cmdtype' not 'type' to al-
aaaiscs	2017-05-00	iiiwaciiso	low easier auto-generation of Scala code.
e9bb72c	2017-03-06	mwachs5	Hart Array: Add registers for hart array.
5d17a35	2017-03-06	mwachs5	DM: Move addresses around for better separation of
5017a55	2017-03-00	iiiwaciisə	functionalities in HW
25ccaa8	2017-03-06	mwachs5	
25CCaao	2017-03-00	mwachs5	CONTROL: Rename control and status registers to
			CS for consistency and to accurately reflect their
45 CC 0	2017 02 06	1 5	functionality.
45cf6c2	2017-03-06	mwachs5	Errors: fix up the bit assignments in SERSTATUS
00.15.0	2017 02 04	1 -	with the addition of error bit.
38cb5a0	2017-03-06	mwachs5	Errors: Make errors write-1-to-clear.
b436d77	2017-03-03	mwachs5	triggers: Clarify that matches are against virtual ad-
-001107	201-02-02	, .	dresses.
793bb85	2017-03-03	mwachs5	triggers: Add suggested timings for best user experi-
			ence.
2669866	2017-03-03	mwachs5	stoptime/stopcycle: Make their functionality match
			their name. Allow any reset value.
c85a1cf	2017-03-01	mwachs5	config_string: Simplify the Config String Address ab-
			stract command.

- 202 - 61-	2017 02 02	M XX71	II. J. 4. DEADME J
a303a6b	2017-03-02 2017-03-01	Megan Wachs mwachs5	Update README.md serial: tweak addresses.
92a4923 b09f460	2017-03-01	mwachs5	serial: tweak addresses. serial: tweak addresses.
6477837	2017-03-01	mwachs5	chisel: tweaks to class names.
be83e3e	2017-02-28	Tim Newsome	Clarify stoptime, stopcycle.
c17c17c	2017-02-27	Tim Newsome	Abstract command that returns config string addr.
096dfbc	2017-02-27	Tim Newsome	Acknowledge Alex.
c0253ab	2017-02-24	Tim Newsome	Explain tdata1 type a bit more.
e43ac2e	2017-02-24	Tim Newsome	Clarify how to enumerate triggers again.
c6e3e20	2017-02-23	Tim Newsome	Revert previous commit.
ef770bf	2017-02-23	Tim Newsome	mcontrol and icount mask tdata2, not tdata1.
27806f2	2017-02-23	mwachs5	rename 'type' to 'cmdtype' purely so my auto-
			generation scripts work.
e46798d	2017-02-22	mwachs5	Add Abstract Commands to automatic chisel
b3bb939	2017-02-21	mwachs5	Generate Chisel headers as well for Debug Module.
c9db98c	2017-02-22	Tim Newsome	Simplify description of op statuses.
bda39cc	2017-02-22	mwachs5	Add explicit type field to Abstract Command.
f83a1ca	2017-02-22	mwachs5	Finish up replacement of ibuf-¿progbuf
9666e51	2017-02-22	mwachs5	IBUF-¿PROGBUF
5308ecd	2017-02-22	mwachs5	Remove last references to "Instruction Supply"
f6ebde9	2017-02-22	Tim Newsome	Move authentication to a serial protocol.
0f079c8	2017-02-22	Tim Newsome	Reserve bit for per-hart reset.
f2c93ac	2017-02-22	Tim Newsome	Clarify that dmactive resets authentication.
f5e7b1c	2017-02-22	Alex Bradbury	Clarify that the halt state of all harts is maintained
			through reset
3dfe8fd	2017-02-22	Tim Newsome	More Debug Mode -; Halt Mode.
d29fc1f	2017-02-22	Tim Newsome	Debug Mode -; Halt Mode
55d6030	2017-02-21	Tim Newsome	Generate debug_defines.h as part of normal make
b0e6a7f	2017-02-21	Tim Newsome	Minor clarifications.
0f 9 8 85 c	2017-02-20	Tim Newsome	Various clarifications.
0802d5a	2017 - 02 - 15	mwachs5	Use consistent 'Control and Status' naming for CS
			registers.
$5 \operatorname{accc7d}$	2017-02-15	Tim Newsome	Change all the "other" JTAG IRs to just reserved.
bcbd7da	2017-02-15	mwachs5	sm_diagram: Show using resumereq bit to resume.
18f6e55	2017-02-14	Tim Newsome	Introduce resumered command, similar to haltred.
4b62c40	2017-02-14	mwachs5	SystemBus: Clean up some formatting and error
			specification notes.
bc97723	2017-02-14	mwachs5	quick-access: Update SM Diagram for Quick Access
d27066e	2017-02-14	Tim Newsome	Clarify haltreq bit.
6f8ec43	2017-02-14	Tim Newsome	Always generate long constants when required.
c6ac6bc	2017-02-13	Tim Newsome	Include field descriptions in C header file.
b849213	2017-02-13	Tim Newsome	Fix the build.
1cf8033	2017-02-12	mwachs5	jtag: More clarifications
6203bd 6	2017-02-12	Megan Wachs	Update requirements— W GPRs Required
f2b43a7	2017-02-12	Megan Wachs	Remove double 'the'
2c64ef1	2017-02-12	Megan Wachs	Remove comma
f84abce	2017-02-12	Megan Wachs	Whitespace edits and address come comments
23c2648	2017-02-11	mwachs5	jtag_dtm: ask for clarification on TAP sharing.
			0 0

7020d23	2017-02-11	mwachs5	jtag_dtm: Clarifications, DBUS-¿DMI
292d49c	2017-02-11	Megan Wachs	fix indentation
b879b86	2017-02-11	Megan Wachs	Add missing period
bbe0521	2017-02-11	$\overline{\text{mwachs}5}$	Make comments on program buffer size match the
			address map.
4ceaa 37	2017-02-11	mwachs5	Flesh out and edit the introduction/background Add
			a description of use cases this spec has in mind, and
			what it doesn't cover.
cbf89d6	2017-02-11	Tim Newsome	Rewrite Quick Access.
170bff1	2017-02-10	Megan Wachs	Allow size 4 for the program buffer
c911e6e	2017-02-10	Tim Newsome	Clarify use of dmactive.
2ca296f	2017-02-09	Tim Newsome	Reserve command register space for custom use.
e49666e	2017-02-09	Tim Newsome	Clarify hart index change per Megan's comments.
84865e9	2017-02-09	Tim Newsome	Add header prefix for abstract commands.
2434f4f	2017-02-09	Tim Newsome	Select harts by index instead of hart ID.
7 bf 112 a	2017-02-09	Tim Newsome	Generate correct headers for ¿32-bit registers.
7f0f09a	2017-02-08	Tim Newsome	Reset dbus status to "failure" to avoid confusion.
8b1c6f0	2017-02-08	Megan Wachs	Fix line wrap issue
345c33f	2017-02-08	Megan Wachs	Call out "arg0" specifically.
9f080f5	2017-02-08	Megan Wachs	Clarify "arguments" to commands
259badd	2017-02-08	Tim Newsome	Make haltsum/halt registers mandatory.
eb0f1d3	2017-02-07	Tim Newsome	Allow for early abstract command failures.
bb49bd1	2017-02-07	Tim Newsome	Clarify error handling a little.
3 fc 0a 97	2017-02-07	Tim Newsome	Explain when abstract data regs may be clobbered.
c37167e	2017-02-07	Tim Newsome	Fix old language in description of halt registers.
6943c96	2017-02-07	Tim Newsome	Generate more useful C header files from reg defs
98639df	2017-02-05	mwachs5	Include the SM Diagram as a figure. Also some minor
			capitalization fixes.
a95e4c3	2017-02-05	mwachs5	Update State Machine diagram to show uncertainty
			of halt bit during auto halt/resume.
ba76744	2017-02-05	Tim Newsome	Combine loabits and hiabits.
02b1d92	2017-02-05	Tim Newsome	DMI can get away with just 6 address bits.
35d6e33	2017-02-05	mwachs5	Update State machine diagram to show BUSY with-
			out HALTED
f511b05	2017-02-04	Tim Newsome	Clarify command busy bit.
d0f8961	2017-02-03	mwachs5	Update figures
e18a68d	2017-02-03	Tim Newsome	Clarify prehalt/postresume failure.
ac3e2a9	2017-02-02	Tim Newsome	Clarify abstract command failure behavior.
ce4baee	2017-02-02	Tim Newsome	Add Quick Access section.
0490377	2017-02-02	Tim Newsome	Add prehalt and postresume to reg command.
67515bd	2017-02-02	Tim Newsome	Deal with a few minor TODOs.
96456fc	2017-02-02	Tim Newsome	Turn register names into links.
317cd98	2017-02-02	Tim Newsome	Explain what register access is required.
f3ad2f2	2017-02-01	Tim Newsome	Revert Plain Exception implementation to be simple
a0ad281	2017-02-01	Tim Newsome	execb -; preexec, execa -; postexec
1d4a2c3	2017-02-01	Tim Newsome	Limit Program Buffer sizes to 0, 1, 8.
cc40815	2017-02-01	Tim Newsome	Incorporate Po-wei's feedback.
c8b45d6	2017-02-01	Tim Newsome	Clarify how all autoexec bits work.

dbb1deb	2017-02-01	Tim Newsome	Remove stale TODO.
c5f8f59	2017-02-01	Tim Newsome	Explain why cmderr inhibits starting new commands.
5c69194	2017-02-01	Tim Newsome	Fix editing error.
50f7c48	2017-02-01	Tim Newsome	Remove empty hart info register.
781c68e	2017-02-01	Megan Wachs	Update README.md
f46b32e	2017-02-01	mwachs5	Add a diagram of Abstract Command flow.
633 bd 63	2017-02-01	Tim Newsome	Move Reading Order into About This Document
51ec 4 d 1	2017-02-01	Tim Newsome	Add reading order section.
03d20ad	2017-02-01	Tim Newsome	autoexec0 applies to data0, not inst0.
c302353	2017-01-31	Tim Newsome	Don't rely on hart fetching instructions once.
2558c25	2017-01-31	Tim Newsome	Change how exceptions in Halt Mode are handled.
a36ddce	2017-01-31	Tim Newsome	Add size to abstract register command.
64 de 458	2017-01-31	Tim Newsome	Detail bus master reads.
c08486f	2017-01-31	Megan Wachs	reset: Add some comments (#5)
1558049	2017-01-30	Tim Newsome	Automate Change Log.
51525a4	2017-01-29	Tim Newsome	Update System Overview
7d39ac0	2017-01-29	Tim Newsome	Update Supported Features.
9e7cbea	2017-01-29	Tim Newsome	Update RISC-V Core section.
515188d	2017-01-29	Tim Newsome	Update Hardware Implementations section.
4b19ed8	2017-01-29	mwachs5	system_bus: be consistent and always call it 'System
			Bus'. Even if some dislike the name, we should be
			consistent and clear in the spec.
9ccef3d	2017-01-29	Tim Newsome	Fleshed out some debugger implementation.
04b9176	2017-01-28	Tim Newsome	Rename debug exception to breakpoint exception.
5ac4ea1	2017 - 01 - 27	Tim Newsome	WIP on big update on instruction supply.
2d9c3e2	2017-01-27	Tim Newsome	Reorganize dm registers.
de50ba8	2017 - 01 - 27	Tim Newsome	Abstract command support is already addressed.
5085046	2017-01-26	mwachs5	Rename registers and fields like 'access' that were
			confusingly the same name.
10bbf6f	2017-01-26	Tim Newsome	Fix #2: DM address space table
a05c582	2017-01-26	Tim Newsome	Add debugger inspection as a feature.
4062681	2017-01-24	Tim Newsome	Add publish target.
5c8bb83	2017-01-24	Tim Newsome	Clarify use of data registers.
1504 da6	2017-01-24	Tim Newsome	Replace manual date with automatic git hash/date.
997f2a0	2017-01-23	Tim Newsome	Deal with unsupported abstract commands.
cb6f2b8	2017-01-23	Tim Newsome	Renumber registers to prevent duplicates.
8b4db96	2017-01-23	Tim Newsome	Don't print out addresses if they're not provided.
b00cd21	2017-01-23	Tim Newsome	Add an abstract command.
675b556	2017-01-23	Tim Newsome	Reorganize DM bits into functional group regs.
5 fc 7512	2017-01-23	Tim Newsome	Remove bits 33:32 from sbdata[23].
ceb5d66	2017-01-20	Tim Newsome	Starting point for a comprehensive spec