RAK19001 WisBlock Dual IO Base Board Software Configuration

Software Configuration

The WisBlock Base Board itself does not require software configuration. To use connected sensors, displays, and interface modules, upload application code to the installed WisBlock Core. Before proceeding, set up the RAKwireless Arduino BSP or PlatformIO, and refer to the WisBlock Examples Repository for sample code.

Shenzhen RAKwireless Technology Co., Ltd.
Room 506, Bldg B, New Compark, Pingshan First Road, Taoyuan Street, Nanshan District, Shenzhen, Guandong Province, The People's Republic of China

www.RAKwireless.com
+86-755-86108311
inquiry@RAKwireless.com