



KasKold User Guide

Hardware, Vault, watch-only Companion, backup/recovery, signing, and maintenance

Authorization rule: Companion is watch-only. Wallet creation/restoration and transaction signing occur only in KasKold Hardware or KasKold Vault.

1. Product family

Application	Purpose
KasKold Hardware	Purpose-built create/restore/review/sign device
KasKold Vault Web	Browser create/restore/review/sign application without blockchain watcher
KasKold Vault Android / iOS	Dedicated native create/restore/review/sign applications
KasKold Companion Web / Android / iOS	Watch-only kpub/network/transaction/broadcast applications

2. Wallet lifecycle and recovery

- Create or restore supported wallet sources only in Hardware/Vault.
- Use mnemonic + optional passphrase as the durable cross-device recovery path.
- Export the public kpub to Companion; never import a mnemonic/private key into Companion.

3. Companion workflow

- Start with kpub management; Broadcast TX and Multisig remain directly available.
- Use Companion for online observation, transaction construction, signing-request transport, finalization, and broadcast.
- There is no Companion hot-wallet or local-signing mode.

4. Hardware and Vault signing

- Scan/import the complete signing request and independently verify recipient, amount, fee, change, network and advanced context.
- Approve only on the signer. Return the signed response to Companion.
- Vault Web/Android/iOS and Hardware share the hardened Rust signing/protocol implementation rather than reimplementing cryptography in UI code.

5. Hardware and qualification

Target	Support
M5Stack CoreS3	Hardware-qualified
M5Stack CoreS3 Lite	Shared CoreS3 adapter/profile; build-supported; qualification pending

6. Security habits

- Keep multiple tested recovery backups and start with small amounts after workflow changes.
- Use a trusted/private node when address-query privacy matters.
- Treat CoreS3 Lite as qualification-pending until physical HIL evidence exists.