
Helio board :Power supply to HSMC

> Now(V1.1 and V1.2)



There is some possibility to cause device destruction on the Helio / daughter cards in the following situation.

- Customer connects AC adaptor Helio and electric point, but power switch position is "OFF"
- When customer connects daughter card to Helio's HSMC, daughter card doesn't connect securely
- In this situation, there is possibility that electlic current flows between Helio and daughter card, and device on the board may become destroyed.



Short term fix plan



Remove this switch
This means that Helio is powered
on when customer will connect
power cable to Helio.

