

17.9 Common Commands for All Languages

EPC/TID Return Request(UHF)			DC2+PK
Command	DC2	PK	Parameter
HEX code	<12> ₁₆	<50> ₁₆ <4B> ₁₆	None
Default value	None		

Valid range and term of command	When turning off the power switch	
	Valid range	
	Printer operation in progress	The command cannot be received during the printer operation. ([NAK] return)
	Error	Commands can be received even if an error is occurring.

[Function]

Returns the status of RFID tag write by <IP0> command and EPC/TID.

[Format]

[DC2]PK

[[DC2]PK return data format (normal)]

[STX]a...a,b,c,d...d[CR][LF] [ETX]

[Return data]

Symbol	Parameter name	Valid range
a	Total number of data byte * This is the total number of bytes after parameter b. The delimiting comma between parameters a and b, and the ETX are not included.	Data size from the first write result status until before [ETX] Maximum 5 digits
b	Write result status *Text format	0: Write failure 1: Write success Note: Specified in text format.
c	Error symbol	N : No error E : EPC write error T : TID read error M : MCS error (Chip inconsistent or not supported) A : All errors Note: Specified in text format
d	EPC/TID return data	Refer to 【EPC/TID return data】 as below Note: Specified in text format

[Format of EPC/TID return data]

"Specify memory"+"."+ "Data"+"Line feed(0DH、0AH)"

ee:f...f(,gg:h...h)

Specifying the memory to be record

Parameters of the IF: RFID settings section of the [DC2]PA-Printer settings

DATA_TO_RECODE: The data to be read differs according to the settings of the RFID data record.

"0": BOTH (EPC and TID are returned)

"1": EPC (only EPC is returned)

"2": TID (only TID is returned)

A setup example of [DC2]PA is shown below.

[DC2]PA,24,IF,18, DATA_TO_RECODE:0[CR][LF]

To set the above from settings menu, you can do the same from "Interface"->"RFID"->"Data to Record"

[EPC/TID return data]

Symbol	Parameter name	Valid range
e(g...)	Specify memory	EP:EPC ID:TID
f(h...)	Data *Text format	Maximum 256 digits

Data sample)

EP:E0123456789ABCDEF0123456,ID:E200680612345678

[Return data format (when a command error occurs)]

[NAK]<15>₁₆

[Exception processing]

Parameter name	Exception condition	
	A value outside the range is specified	The specified size and received size are different
Identifier	Command error	Invalid receive data

Terminology	Description
Command error	The data received after a command error is determined is not considered as a parameter of this command.
Invalid receive data	The data corresponding to byte 2 and thereafter of the identifier is ignored.

[Coding sample]

<A>

<RU>01

<IP0>e:h,epc:E0123456789ABCDEF0123456;

<XM>E0123456789ABCDEF0123456

<Z>

[Sample of status reply]

When [DC2]PK is received using a tag with E200680612345678 for TID specified to return TID only.

■ Write successful (TID read successful)

[STX]25,1,N,ID:E200680612345678[CR][LF][ETX]

■ Write successful(TID read fail)

[STX]9,1,T,ID:[CR][LF][ETX]

■ Write fail (EPC write failed)

[STX]9,0,E,ID:[CR][LF][ETX]

[Supplemental explanation]

1. The write status and EPC/TID is returned when [DC2]PK is received after RFID write.
2. Although write is successful status will be returned without data if you fail to read EPC/TID since EPC/TIC read will be done separately from write.
3. If the command has only EPC code write and does not have print data, the "Write status" in return data will be "0: Write failure" with "Error symbol" as "A: All errors".
4. For details on the return sequence, refer to 16.10 ESC+RU EPC/TID return.