

12.19 System

Print Mode		ESC+PM	
Hexadecimal code	ESC <1B> ₁₆	PM <50> ₁₆ <4D> ₁₆	Parameter a
Initial value	a=0		

Valid range and term of command	When the power switch is OFF	The set parameter is maintained.
	Valid range within items	The set parameter is valid until the next valid setting.
	Valid range between items	The set parameter is valid until the next valid setting.

[Function]

Specifies print mode.

[Format]

<PM>a

•Parameter

a Print mode	=	0	:	Continuous
		1	:	Tear-off
		2	:	Cutter (Head position)
		3	:	Cutter (Cutter position)
		4	:	Cutter (No back feed)
		5	:	Linerless cutter motion (Cutter position)
		7	:	Dispenser (Head position)
		8	:	Dispenser (Dispenser position)
		B	:	Cutter (Cut position + Cut while printing)

[Coding Example]

```
<A>
<PM>0
<Z>
```

[Supplementary Explanation]

- Settable operation modes are different depending on the installed options.

Options	Operation mode
None	Continuous, Tear-off
Dispenser	Continuous, Tear-off, Dispenser(Head position), Dispenser(Dispenser position)
Cutter	Continuous, Cutter (Head position), Cutter (Cut position), Cutter (No backfeed)
Linerless cutter	Linerless cutter (Cut position)

Setting other than above operation modes doesn't go to the specified mode.

- General description of each mode :

(0) Continuous

The printer stays still after printing.

(1) Tear-off

The media will be fed up to the tear-off edge after printed. Then the printer, after receiving next print data, will back feed the next label to the print head position.

(2) Cutter (Head position)

The printer back feed the label up to the print head position immediately after the last label is cut.

(3) Cutter (Cutter position)

The printer, after receiving the next print data, will back feed the media to the print head position.

(4) Cutter (No back feed)

No back feed.

(5) Linerless cutter operation (cutting position)

The mode performing following operation that receive print data, then backfeed to the printhead position, after that print and cut the label after completing printing.

(6) Dispenser (Head position)

Back feeds the labels to head position after dispensing.

(7) Dispenser (Dispenser position)

The media will be fed up to the head position after data receiving and the label will be fed to the dispenser position after printing.

(8) Cut (Cut position + Cut during print)

When receiving print data, the printer cuts the last label while printing a label.