```
ESP-Ariane first-stage boot loader

Scanning device tree...
[probe] sld,mriq_stratus.0 registered
        Address   : 0x60010000
        Interrupt : 6
*************** sld,mriq_stratus.0 ***************
  memory buffer base-address = 0xa0100b60
  ptable = 0xa0100d10
  nchunk = 1
  ----------------------
  Generate input...
  -> Non-coherent DMA
  Start...
  Done
  validating...
  ... PASS
```